

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tupperware](#) /

› [Tupperware SS 4L Plastic Serving and Storage Bowl Instruction Manual \(Model: TwS.SBowl4LSETOF1\)](#)

## Tupperware TwS.SBowl4LSETOF1

# Tupperware SS 4L Plastic Serving and Storage Bowl Instruction Manual

Model: TwS.SBowl4LSETOF1

## INTRODUCTION

This manual provides essential instructions for the proper use, care, and maintenance of your Tupperware SS 4L Plastic Serving and Storage Bowl. Designed for versatility, this container is suitable for storing and serving various food items, ensuring freshness and convenience. Please read this manual thoroughly before first use to ensure optimal performance and longevity of your product.

## SAFETY INFORMATION

- Do not use in a microwave oven. This product is not microwave safe.
- Avoid direct heat sources, such as stovetops or ovens, as this can damage the plastic.
- Do not use abrasive cleaners or scouring pads, which can scratch the surface.
- Keep out of reach of small children when not in use, especially if containing hot food.
- Ensure the lid is properly sealed before transporting liquids to prevent spills.

## PRODUCT COMPONENTS

The Tupperware SS 4L Plastic Serving and Storage Bowl consists of two main components:

- **Bowl:** A 4-liter capacity plastic bowl, typically white or light-colored.
- **Lid:** A brown, airtight, and liquid-tight plastic lid designed to fit securely onto the bowl.



This image displays the Tupperware SS 4-liter plastic serving and storage bowl. The bowl is white, and it features a brown, airtight, and liquid-tight lid.

## SETUP

1. **Unpacking:** Carefully remove the bowl and lid from their packaging.
2. **Initial Cleaning:** Before first use, wash both the bowl and lid thoroughly with warm soapy water. Rinse completely and allow to air dry, or dry with a clean cloth.
3. **Inspection:** Inspect the bowl and lid for any signs of damage or defects. Do not use if damaged.

## OPERATING INSTRUCTIONS

### Filling the Bowl

- Place the bowl on a stable, flat surface.
- Fill the bowl with your desired food item. Avoid overfilling to ensure the lid can be sealed properly.

### Sealing the Lid

1. Place the lid onto the rim of the bowl.
2. Press down firmly on the center of the lid.
3. Work your way around the edge of the lid, pressing down to ensure a complete seal. You may hear a slight "click" as the air is expelled and the seal is formed.
4. To verify the seal, gently lift the bowl by the lid. If the lid remains attached, the seal is secure.

### Opening the Bowl

- To open, lift one edge of the lid gently to break the airtight seal.
- Continue lifting around the perimeter until the lid detaches completely.

## Storage and Serving

- The bowl is suitable for refrigerator storage.
- It can be used for serving various dishes at room temperature or chilled.
- When not in use, bowls can be nested to save space. Lids can be stacked separately.

## CARE AND MAINTENANCE

- **Cleaning:** The bowl and lid are dishwasher safe. For hand washing, use warm water and mild dish soap. Rinse thoroughly.
- **Drying:** Ensure all components are completely dry before storing to prevent odors or mildew.
- **Stain Removal:** For stubborn food stains, create a paste of baking soda and water, apply to the stain, let sit for a few hours, then wash as usual.
- **Odor Removal:** To remove lingering odors, wash thoroughly and then place a crumpled piece of newspaper inside the bowl with the lid on for a day or two. Alternatively, a mixture of water and white vinegar can be used for soaking.
- **Storage:** Store with lids slightly ajar or removed to allow air circulation and prevent odors from developing.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lid does not seal properly.	Food overfill; lid or rim is dirty; lid is warped.	Reduce food quantity; clean lid and rim thoroughly; if warped, contact customer support.
Lingering food odors.	Strong-smelling food stored for extended periods.	Refer to "Odor Removal" in the Care and Maintenance section.
Stains on the bowl.	Contact with highly pigmented foods (e.g., tomato sauce, turmeric).	Refer to "Stain Removal" in the Care and Maintenance section.

## SPECIFICATIONS

**Product Type:** Serving and Storage Bowl

**Brand:** Tupperware

**Model Number:** TwS.SBowl4LSETOF1

**Material:** Plastic

**Capacity:** 4 Liters (4000 ml)

**Dimensions:** Approximately 11.81 x 11.81 x 7.87 inches (L x W x H)

**Weight:** Approximately 1.41 pounds

**Color:** White bowl with Brown lid

**Features:** Airtight, Leak Resistant, Dishwasher Safe, Refrigerator Safe

**Microwave Safe:** No

## WARRANTY INFORMATION

Tupperware products are known for their durability and quality. For specific warranty details, please refer to the warranty information provided at the time of purchase or visit the official Tupperware website. Keep your proof of purchase for any warranty claims.




## CUSTOMER SUPPORT


For further assistance, questions, or to report any issues with your Tupperware product, please contact Tupperware customer service through their official website or the contact information provided with your purchase. Please have your model number (TwS.SBowl4LSETOF1) and purchase details ready when contacting support.

You can visit the official Tupperware store for more information: [Tupperware Store on Amazon](#)

© 2023 Tupperware. All rights reserved.

## Related Documents - TwS.SBowl4LSETOF1

	<p><a href="#">Tupperware Collapsible Cake Taker - Usage Instructions</a></p> <p>Learn how to use the Tupperware Collapsible Cake Taker. This guide provides step-by-step instructions for expanding and collapsing the cake carrier for optimal storage and transport.</p>
	<p><a href="#">Tupperware Micro Healthy Delight: Microwave Cookware Guide</a></p> <p>Discover how to prepare healthy and delicious meals with the Tupperware Micro Healthy Delight. This guide provides essential cooking instructions, safety precautions, and warranty information for optimal use in your microwave.</p>
	<p><a href="#">CheeSmart Food Storage Container Instructions   Tupperware</a></p> <p>Official instructions for the Tupperware CheeSmart container, detailing how to use, clean, and store cheese and cold meats for optimal freshness. Learn about CondensControl technology.</p>
	<p><a href="#">Tupperware WOW POP Microwave Popcorn Maker: Instructions and Safety Guide</a></p> <p>Comprehensive guide for the Tupperware WOW POP Microwave Popcorn Maker, covering usage, safety instructions, quantity guide, and warranty information. Learn to make perfect popcorn.</p>
	<p><a href="#">Tupperware TCare Bowl Anti-Skid User Manual and Care Guide</a></p> <p>Learn how to use and care for your Tupperware TCare Bowl Anti-Skid. This guide provides instructions on features, benefits, safety, cleaning, and warranty information for this baby feeding bowl.</p>



## [Tupperware TCare Sip N Care Tumbler: User Guide, Safety, and Care Instructions](#)

Official user manual for the Tupperware TCare Sip N Care Tumbler. Includes detailed cleaning instructions, essential safety warnings for children, and information on the Tupperware warranty. Learn how to use, clean, and care for your sippy cup.