

[Manuals.plus](#) /

› [Fisher-Price](#) /

› Fisher-Price DJ Bouncin' Beats Learning Toy (Model HFT76) Instruction Manual

Fisher-Price HFT76

Fisher-Price DJ Bouncin' Beats Learning Toy (Model HFT76) Instruction Manual

For Ages 9-36 Months

1. PRODUCT OVERVIEW

The Fisher-Price DJ Bouncin' Beats is an interactive musical learning toy designed to engage babies and toddlers with its unique bouncing action, colorful lights, and educational content. It features multiple play modes to support developmental milestones.



Figure 1: Fisher-Price DJ Bouncin' Beats toy in action with a child.

2. SETUP

2.1 Battery Installation

1. Locate the battery compartment on the underside of the toy.
2. Using a Phillips head screwdriver, loosen the screw and remove the battery compartment cover.
3. Insert 4 AA (LR6) alkaline batteries, ensuring correct polarity (+/-).
4. Replace the cover and tighten the screw.

2.2 Power and Volume Control

On the back of the toy, locate the power switch and volume control. Slide the switch to the 'On' position. Adjust the volume to your preferred level using the volume settings.



Press for 75+ songs, sounds & phrases

Figure 2: Close-up view of the toy's face and Smart Stages selector switch.

3. OPERATING INSTRUCTIONS

The DJ Bouncin' Beats toy features 3 Smart Stages learning levels and multiple interactive buttons for engaging play.

3.1 Smart Stages Levels

Select a learning level using the Smart Stages switch located on the side of the toy:

- **Level 1 (Explore):** Introduces basic concepts through simple songs and phrases.
- **Level 2 (Encourage):** Expands on learning with prompts and questions.
- **Level 3 (Pretend):** Encourages imaginative play and role-playing.

3.2 Interactive Buttons

Press the buttons on the toy's head to activate different features:

- **Music Button:** Plays various songs and musical tunes.
- **Learning Button (ABC/123):** Teaches the alphabet, counting 1-10, colors, and opposites.

- **Mic Button (Record & Remix):** Press and hold to record a short phrase. The toy will then play it back with fun remix effects and bouncing action.



Figure 3: A child pressing the interactive buttons on the toy.



3 Smart Stages[®] levels teach ABCs, 123s, colors & more

Figure 4: A child using the record and remix feature.

3.3 Bouncing Action and Lights

The toy features a motorized spring action that makes it bounce as it plays music and phrases. Its face lights up in multiple colors, adding to the engaging experience.

3.4 Demonstration Videos

Your browser does not support the video tag.

Video 1: Demonstration of the toy's engaging and entertaining features, including lights and bouncing action.

Your browser does not support the video tag.

Video 2: Overview of the Fisher-Price DJ Bouncin' Beats toy, highlighting its various functions and interactive elements.

Your browser does not support the video tag.

Video 3: A detailed look at the toy's features, including sound, lights, and the record/remix function.

4. MAINTENANCE

4.1 Cleaning

To clean the toy, wipe its surface with a damp cloth. Do not immerse the toy in water. Ensure the toy is completely dry before further use.

4.2 Battery Care

- Remove batteries if the toy is to be stored for an extended period.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

5. TROUBLESHOOTING

5.1 Toy Not Turning On

- Check that the power switch is in the 'On' position.
- Ensure batteries are correctly installed with proper polarity.
- Replace old or depleted batteries with new ones.

5.2 Sound or Light Issues

- Verify the volume control is not set to the lowest setting.
- If lights or sounds are intermittent, replace batteries.

6. SPECIFICATIONS

Feature	Detail
Brand	Fisher-Price
Model Number	HFT76
UPC	194735043484
Age Range	9-36 Months
Material Type	Plastic
Item Dimensions (L x W x H)	6.65 x 11.65 x 12.99 inches
Item Weight	3.57 Pounds
Number of Batteries	4 AA batteries (included)
Educational Objective	Color Recognition, Alphabet, Counting, Opposites

12.99"



11.65"

Figure 5: Product dimensions for the DJ Bouncin' Beats toy.

7. WHAT'S IN THE BOX

- 1 Fisher-Price DJ Bouncin' Beats Toy

8. WARRANTY AND SUPPORT

This product comes with no stated manufacturer warranty. For any product-related inquiries or support, please refer to the contact information provided on the product packaging or the official Fisher-Price website.

