

[manuals.plus](#) /

› [Faber](#) /

› [Faber Remo 3BB BK 3-Burner Gas Stove User Manual](#)

Faber HOB COOKTOP REMO 3BB BK

Faber Remo 3BB BK 3-Burner Gas Stove User Manual

Model: HOB COOKTOP REMO 3BB BK

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your new Faber Remo 3BB BK 3-Burner Gas Stove. Please read all instructions carefully before installation and operation. Keep this manual for future reference.

Presenting the sleekest cooktop with maximum performance

Remo Cooktop



Image 1.1: Faber Remo 3BB BK 3-Burner Gas Stove, showcasing its sleek design and three burners.

2. SAFETY INFORMATION

WARNING: Improper installation, adjustment, alteration, service, or maintenance can cause property damage, injury, or death. Read the installation, operating, and maintenance instructions thoroughly before installing or servicing this equipment.

- Ensure proper ventilation in the kitchen area.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Keep children away from the appliance during operation.
- Always use appropriate cookware for the burner size.
- Do not leave the appliance unattended while cooking.
- In case of a gas leak, immediately turn off the gas supply, open windows, and do not operate any electrical switches or appliances. Contact a qualified technician.

3. SETUP AND INSTALLATION

3.1 Unpacking

1. Carefully remove the gas stove from its packaging.
2. Inspect the appliance for any damage. Do not install if damaged.
3. Remove all packing materials, including protective films and tapes.

3.2 Placement

Place the gas stove on a stable, level, and heat-resistant surface. Ensure adequate clearance from walls and overhead cabinets. The product dimensions are approximately 38D x 77W x 11H Centimeters.

3.3 Gas Connection

Gas connection must be performed by a qualified technician in accordance with local regulations. Ensure the gas hose is securely connected and free from kinks or leaks. Use only approved gas regulators and hoses.




Image 3.1: Underside of the gas stove, illustrating the gas inlet and internal connections.

3.4 Burner Assembly

1. Place the burner caps correctly on the burner bases.

2. Position the pan supports securely over each burner.




Image 3.2: Close-up view of a burner, showing the brass burner cap and powder-coated pan support.

4. OPERATING INSTRUCTIONS

4.1 Burner Types

Your Faber Remo 3BB BK gas stove features three burners:

- **1 Jumbo Burner:** For large utensils and faster cooking.
- **1 Medium Burner:** For standard cooking needs.
- **1 Small Burner:** Ideal for simmering and smaller pots.



JUMBO BURNER

Image 4.1: Detailed view of the jumbo burner, designed for high heat output.

4.2 Manual Ignition

1. Ensure the gas supply is open.
2. Push and turn the desired burner knob counter-clockwise to the 'ON' position.
3. Immediately bring a lit matchstick or a gas lighter to the burner to ignite the flame.
4. Once the flame is lit, adjust the knob to achieve the desired flame intensity.
5. To turn off, rotate the knob clockwise to the 'OFF' position.



MANUAL IGNITION

Image 4.2: Illustration of manual ignition using a gas lighter.

4.3 Flame Control

The control knobs allow you to adjust the flame size. Turn the knob towards the '+' symbol for a larger flame and towards the '-' symbol for a smaller flame. Always ensure the flame is stable and blue.



Image 4.3: View of the premium quality control knobs for flame adjustment.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance ensure the longevity and efficient operation of your gas stove.

5.1 Cleaning the Glass Ceramic Cooktop

The cooktop features a toughened glass body for durability and easy cleaning.

1. Allow the cooktop to cool completely before cleaning.
2. Wipe the glass surface with a soft cloth dampened with mild soap and water.
3. For stubborn stains, use a non-abrasive cleaner specifically designed for glass cooktops.
4. Dry thoroughly with a clean, soft cloth to prevent water spots.



Image 5.1: Detail of the toughened glass body, highlighting its smooth, easy-to-clean surface.

5.2 Cleaning Burners and Pan Supports

1. Remove the pan supports and burner caps/bases once they are cool.
2. Wash them with warm soapy water. For stubborn food residue, soak them before scrubbing.
3. Ensure all parts are completely dry before reassembling to prevent corrosion and ensure proper ignition.
4. The pan supports are powder-coated round type, which can be cleaned with a damp cloth.

6. TROUBLESHOOTING

If you encounter issues with your gas stove, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Burner does not ignite	No gas supply, clogged burner holes, wet burner parts.	Check gas cylinder/line. Clean burner holes. Ensure burner parts are dry.
Irregular flame	Clogged burner holes, improper burner assembly.	Clean burner holes. Reassemble burner parts correctly.
Low flame even at maximum setting	Low gas pressure, partially clogged burner.	Check gas regulator. Clean burner thoroughly.
Gas smell	Gas leak.	Immediately turn off gas supply, ventilate area, and contact a qualified technician.

If the problem persists after attempting these solutions, contact customer support.

7. SPECIFICATIONS

Feature	Specification
Brand	Faber
Model Number	HOB COOKTOP REMO 3BB BK
Colour	Black
Material	Glass
Heating Elements	3
Burner Type	1 Jumbo Burner + 1 Small Burner + 1 Medium Burner
Pan Support	Powder coated round type
Ignition Type	Manual Ignition
Product Dimensions (LxWxH)	770x380x55 mm (77D x 38W x 5.5H Centimeters)
Item Weight	8 kg
Included Components	1 Gas stove & user manual

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your Faber Remo 3BB BK Gas Stove comes with the following warranty:

- **2-year comprehensive warranty** on the product.
- **5-year warranty** on Glass and burners.
- **2-year warranty** on the Valve.

Please retain your purchase receipt for warranty claims. The warranty covers manufacturing defects under

normal use conditions.

8.2 Customer Support

For service, technical assistance, or warranty claims, please contact Faber customer service. Refer to the contact information provided with your product packaging or visit the official Faber website for the most up-to-date support details.

© 2026 Faber. All rights reserved.