

[Manuals.plus](#) /

› [Goshyda](#) /

› Goshyda Portable Bluetooth Speaker User Manual

## Goshyda Goshyda5odgvwh6ur2674

# Goshyda Portable Bluetooth Speaker User Manual

Model: Goshyda5odgvwh6ur2674

## INTRODUCTION

---

This manual provides detailed instructions for the safe and efficient use of your Goshyda Portable Bluetooth Speaker. This device features crystal-clear stereo sound, Bluetooth 5.2 connectivity, multiple playback modes, and integrated LED lighting. Please read this manual thoroughly before operating the speaker and retain it for future reference.

## SETUP

---

### Package Contents

- Goshyda Portable Bluetooth Speaker
- USB Charging Cable
- User Manual



The speaker and included USB charging cable.

## Charging the Speaker

1. Connect the small end of the USB charging cable to the charging port on the speaker.
2. Connect the larger end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging. Once fully charged, the light may change color or turn off, depending on the model.
4. A full charge provides approximately 4 hours of playback time.



Illustration of the speaker's 1200mAh battery capacity and usage times.

## Powering On/Off

- To power on, press and hold the power button (often combined with play/pause) for a few seconds until you hear an audible prompt or see the indicator light.
- To power off, press and hold the power button again for a few seconds.

## OPERATING INSTRUCTIONS

---

### Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED light).
2. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "Goshyda Speaker" (or similar name) from the list of devices.
4. Once connected, the speaker will provide an audible confirmation, and the LED light will stop flashing.
5. The speaker supports Bluetooth 5.2 for a stable connection up to 66 feet (20 meters).

### True Wireless Stereo (TWS) Pairing

To achieve a stereo sound experience, you can connect two identical Goshyda Portable Bluetooth Speakers together.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker, double-press the power/play button. It will enter TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. You will hear a confirmation tone once paired.
4. Once TWS paired, connect your device to one of the speakers via Bluetooth as described above. The audio will now play in stereo across both speakers.

# TWS Double Speaker Tandem, Ultimate Listening



Illustration of two speakers connected in TWS mode for left and right stereo channels.

## Playback Modes

The speaker supports three playback modes:

- **Bluetooth Mode:** Connect wirelessly to your Bluetooth-enabled device.
- **TF Card Mode:** Insert a TF (MicroSD) card loaded with audio files into the designated slot. The speaker will automatically play music from the card.
- **AUX Mode:** Connect an audio device using a 3.5mm AUX cable (not included) to the AUX input port.



The speaker's AUX, TF card, and USB charging ports.

## Controls

The speaker features intuitive buttons for control:

- **Power/Play/Pause Button:** Press and hold to power on/off. Short press to play/pause music.
- **Volume Up (+) Button:** Short press to increase volume.
- **Volume Down (-) Button:** Short press to decrease volume.
- **Light Mode Button ( ):** Short press to cycle through the 3 lighting modes.



The control panel of the Goshyda Portable Bluetooth Speaker.

## LED Lighting Modes

The speaker includes 3 dynamic lighting modes that can be cycled through by pressing the light mode button ( ).



Press the light button to change lighting modes.

## Hands-Free Calling

With its built-in microphone, the speaker allows for hands-free calls when connected to your smartphone via Bluetooth.

- **Answer Call:** Short press the power/play button.
- **End Call:** Short press the power/play button during a call.
- **Reject Call:** Press and hold the power/play button.



The speaker supports hands-free calling with a built-in microphone.

## MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.
- **Water Resistance:** The speaker is rated as waterproof. However, avoid submerging it in water for prolonged periods or exposing it to high-pressure water jets. Ensure charging port covers are securely closed when near water.

## TROUBLESHOOTING

---

Problem	Solution
---------	----------

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB cable. Press and hold the power button for a few seconds.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode (flashing LED). Make sure your device's Bluetooth is enabled and within range (up to 66 feet). Forget the speaker from your device's Bluetooth list and try pairing again. Restart both the speaker and your device.
No sound or low volume.	Increase the volume on both the speaker and your connected device. Ensure the speaker is properly connected to your device. If using AUX mode, ensure the cable is fully inserted and functional.
TWS pairing fails.	Ensure both speakers are identical models and fully charged. Disconnect both speakers from any other Bluetooth devices before attempting TWS pairing. Ensure both speakers are close to each other.

## SPECIFICATIONS

Feature	Detail
Model Number	Goshyda5odgvwh6ur2674
Brand	Goshyda
Connectivity Technology	Bluetooth 5.2, Auxiliary
Bluetooth Range	Up to 66 feet (20 meters)
Audio Output Mode	Stereo
Maximum Speaker Output Power	8 Watts
Battery Capacity	1200 mAh
Average Battery Life	4 hours
Charging Source	USB Powered (DC5V/2A)
Special Features	Built-in Microphone, USB Port, 3 Lighting Modes, TWS Function
Material	ABS (Acrylonitrile Butadiene Styrene)
Dimensions (L x W x H)	Approximately 8.55 cm (diameter) x 11.2 cm (height)
Weight	360 grams
Waterproof	Yes
Control Method	Button/Touch

Feature	Detail
Compatible Devices	Desktop, Laptop, Smartphone, Tablet



Dimensions of the Goshyda Portable Bluetooth Speaker.

## WARRANTY INFORMATION

This product is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your package or contact your retailer for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

## CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your Goshyda Portable Bluetooth Speaker that are not addressed in this manual, please contact the retailer where you purchased the product or the manufacturer's customer support. You may find contact information on the product packaging or the brand's official website.

