

Livoccur Li-SB-1114

Livoccur 11x14 Shadow Box Frame Instruction Manual

Model: Li-SB-1114

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Livoccur 11x14 Shadow Box Frame. Please read these instructions carefully before use to ensure safe and optimal performance. This shadow box is designed to display and preserve your cherished keepsakes, memorabilia, photos, and more.

SAFETY INFORMATION

- Handle the glass window with care to prevent breakage and injury.
- Ensure the shadow box is securely mounted or placed on a stable surface to prevent falling.
- Keep out of reach of children to avoid accidents with glass or small parts.
- Do not expose the shadow box to extreme temperatures or direct sunlight for prolonged periods, as this may damage the wood and contents.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly or setup.

- 1 x Livoccur 11x14 Shadow Box Frame
- 5 x Fixing Nails (Pushpins)
- 2 x Screws
- 2 x Plastic Anchors




Image: The shadow box frame with its dimensions (11 inches wide, 13.9 inches high, 2.6 inches deep) and the included hardware: 5 fixing nails, 2 screws, and 2 plastic anchors.

SETUP

1. Unpacking

Carefully remove the shadow box from its packaging. Inspect for any damage during transit. Remove any protective films from the glass surface.

2. Inserting Items

The Livoccur Shadow Box offers two methods for inserting items:

Method A: Top Loading Slot

For smaller, loose items such as wine corks, ticket stubs, or small tokens, use the top loading slot. Simply drop items into the opening at the top of the frame.



Image: A hand is shown dropping a wine cork into the designated top opening of the shadow box, which is partially filled with other corks.

Method B: Rear Access

For larger items, photos, or arrangements that require secure placement on the linen backing, open the back panel of the shadow box. The back panel is secured by a vintage lock on the side. Unlatch the lock and gently open the back panel using the full open metal hinge. Arrange your items on the linen backing, using the provided fixing nails (pushpins) if needed. Once items are arranged, close the back panel and secure the vintage lock.



Image: A collage of four close-up images showing key features: the real glass cover, the vintage lock mechanism, a metal sawtooth hanger for wall mounting, and a full open metal hinge for accessing the back panel.

3. Mounting Options

The shadow box can be displayed in two ways:

Tabletop Display

Place the shadow box on any flat, stable surface such as a table, shelf, or mantelpiece. Ensure it is positioned where it will not be easily knocked over.



Image: A Livoccu shadow box is shown on a wooden shelf, displaying photos and small statues, alongside a potted plant and other home decor.

Wall Mounting

The back of the shadow box is equipped with 4 hooks, allowing for both horizontal and vertical wall display. Use the provided screws and plastic anchors for secure installation. Mark the desired positions on the wall, drill pilot holes, insert anchors, and then screw in the screws, leaving a small portion exposed to hang the hooks.



Image: A close-up of the back of the shadow box, highlighting the four hooks positioned for versatile horizontal or vertical wall mounting. Another shadow box is shown mounted on a wall in the background.

OPERATING

Once your items are placed inside and the shadow box is positioned, no further operation is typically required. To change or add items, follow the 'Inserting Items' instructions in the Setup section.

MAINTENANCE

Cleaning the Glass

Use a soft, lint-free cloth and a standard glass cleaner to wipe the glass surface. Spray cleaner onto the cloth first, then wipe the glass to avoid excess liquid seeping into the frame.

Cleaning the Frame

Wipe the wooden frame with a dry or slightly damp soft cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the distressed finish.

Linen Backing Care

The linen backing can be gently dusted with a soft brush or a vacuum cleaner with a brush attachment. Avoid getting it wet.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Items do not fit through the top slot.	Item is too large for the slot opening.	Use the rear access method to place larger items.
Shadow box is unstable on a surface.	Surface is uneven or not sturdy.	Relocate the shadow box to a flat, stable surface.
Difficulty closing the back panel.	Items inside are too bulky or misaligned.	Adjust the arrangement of items to ensure they do not obstruct the back panel.
Glass appears dirty or streaky after cleaning.	Improper cleaning technique or cloth.	Use a clean, lint-free microfiber cloth and a streak-free glass cleaner. Wipe in one direction.

SPECIFICATIONS

- **Model:** Li-SB-1114
- **Dimensions:** 14"L x 11"W x 14"H (Overall), 8.9"W x 11.8"H (Interior Display Area)
- **Weight:** 2.55 pounds
- **Frame Material:** Wood, Glass
- **Backing Material:** Linen
- **Mounting Type:** Tabletop or Wall Mount (Horizontal/Vertical)
- **Color:** Colour-392 (Distressed White)

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the purchase documentation or contact Livoccur customer service through the retailer where the product was purchased. Please have your model number (Li-SB-1114) and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question