

VASAGLE RGR116B01

VASAGLE Clothes Rail Clothes Rack with Shoe Rack Instruction Manual

Model: RGR116B01

1. INTRODUCTION

Thank you for choosing the VASAGLE Clothes Rail Clothes Rack with Shoe Rack. This multi-functional storage solution is designed to organize your clothing, shoes, and accessories efficiently. It features a hanging bar, a shoe rack, five storage shelves, and six S-shaped side hooks, providing ample open storage for various items, including long coats. Constructed from quality chipboard and a sturdy steel frame, this unit is built for stability and durability. This manual provides detailed instructions for assembly, usage, and maintenance to ensure optimal performance and longevity of your product.



Figure 1.1: Fully assembled VASAGLE Clothes Rail Clothes Rack with Shoe Rack, showcasing its storage capabilities for clothes, shoes, and accessories.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.

- Assemble the product on a clean, flat, and stable surface to prevent scratches or damage.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum load capacities: The entire unit supports up to 220 kg, and the hanging rail supports up to 40 kg. Overloading can cause the unit to tip or collapse.
- Distribute weight evenly across the hanging rail and shelves to maintain stability.
- Do not climb on or hang from the unit.
- If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. Refer to the parts list provided in your assembly guide. All parts are typically numbered for easy identification.



- Chipboard shelves
- Hanging rail
- S-shaped hooks
- Assembly hardware (screws, bolts, Allen key)
- Instruction manual

4. SETUP (ASSEMBLY)

Assembly is designed to be straightforward with numbered parts and clear instructions. While it can be assembled by one person, having assistance may ease the process, especially with heavier components.

1. **Prepare the Area:** Clear a spacious, flat area for assembly. Lay out all parts and hardware, matching them to the numbered list in your assembly guide.
2. **Assemble the Frame:** Begin by connecting the main steel frame components according to the diagrams. Ensure all connections are firm but do not fully tighten screws until the entire frame is assembled.
3. **Install Shelves:** The five storage shelves can be installed on either the left or right side of the clothes rail, depending on your preference and space requirements. Follow the specific instructions for attaching the shelves securely to the frame.
4. **Attach Hanging Rail:** Secure the main hanging rail to the designated points on the frame.
5. **Add S-Hooks:** Place the six S-shaped hooks onto the side bars as desired for additional hanging storage.
6. **Final Tightening:** Once all components are in place and the unit stands upright, systematically tighten all screws and fasteners. Ensure the unit is stable and level. Adjustable feet are included to help stabilize the unit on uneven floors.



Figure 4.1: The flexible design allows shelves to be installed on either the left or right side of the unit.



Figure 4.2: Adjustable feet ensure stability on various floor surfaces.

5. OPERATING (USAGE)

The VASAGLE Clothes Rail is designed for versatile storage in various rooms such as bedrooms,

hallways, or living rooms.

- **Hanging Rail:** Use the sturdy hanging rail for coats, shirts, dresses, and other garments. Its generous height accommodates long items.
- **Storage Shelves:** The five shelves provide ample space for folded clothes, bags, decorative items, plants, or storage boxes.
- **Shoe Rack:** The bottom shelf serves as a convenient shoe rack, keeping your footwear organized and accessible.
- **Side Hooks:** Utilize the six S-shaped hooks for hanging smaller items like hats, scarves, belts, or handbags.



Figure 5.1: The clothes rail provides comprehensive storage for a tidy living space.



Figure 5.2: The included S-hooks offer convenient hanging for smaller items.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your clothes rail.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Dusting:** Regularly dust the shelves and frame to prevent buildup.
- **Hardware Check:** Periodically inspect all screws and connections to ensure they remain tight. Retighten if any looseness is detected.
- **Avoid Moisture:** Do not expose the unit to excessive moisture or direct sunlight, which can cause warping or discoloration of the chipboard.

7. TROUBLESHOOTING

If you encounter any issues with your VASAGLE Clothes Rail, refer to the following common solutions:

Problem	Possible Cause	Solution
Unit is wobbly or unstable.	Loose screws; uneven floor; uneven weight distribution.	Ensure all screws are fully tightened. Adjust the leveling feet at the base. Redistribute items evenly on the shelves and hanging rail.
Difficulty during assembly.	Incorrect part orientation; screws not aligning.	Review the instruction manual diagrams carefully. Ensure parts are oriented correctly before tightening. Do not fully tighten screws until all components are loosely assembled. Consider having a second person assist.
Missing or damaged parts.	Packaging error; transit damage.	Do not proceed with assembly. Contact VASAGLE customer support with your purchase details and a description of the issue.

8. SPECIFICATIONS

Attribute	Detail
Model	RGR116B01
Brand	VASAGLE
Product Dimensions	45D x 120W x 160H cm
Item Weight	16.4 kg
Material	Wood material: alloy steel
Colour	Rustic Brown + Black
Style	Industrial
Installation Method	Free Standing
Maximum Load Capacity (Total)	220 kg
Maximum Load Capacity (Hanging Rail)	40 kg

9. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact VASAGLE customer service. Keep your purchase receipt and model number (RGR116B01) handy for faster service. You can visit the official VASAGLE store for more information and products:[VASAGLE Store on Amazon](#)

