



Manuals.plus /

› Roomie Tec /

› Roomie Tec Alpha Upright Cordless Vacuum Cleaner User Manual

Roomie Tec SL597

Roomie Tec Alpha Upright Cordless Vacuum Cleaner User Manual

Brand: Roomie Tec | **Model:** SL597

1. INTRODUCTION

The Roomie Tec Alpha Upright Cordless Vacuum Cleaner is designed for versatile and powerful cleaning across various surfaces. Its lightweight, cordless design, combined with strong suction and specialized attachments, makes it ideal for tackling everyday messes, pet hair, and hard-to-reach areas. This manual provides essential information for safe and effective use, setup, maintenance, and troubleshooting.

2. SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust bag and/or filters in place.
- Turn off all controls before unplugging.
- Store the appliance indoors. Put away after use to prevent accidents.
- Use only on dry surfaces.
- Do not use for any purpose other than described in this user's guide.

3. PACKAGE CONTENTS

Your Roomie Tec Alpha Upright Cordless Vacuum Cleaner package includes the following components:

- ALPHA Cordless Upright Vacuum
- Floor Brush
- Crevice Tool
- Dusting Brush
- Motorized Pet Brush
- Auto Charging Base
- HEPA Filter
- Power Adaptor
- User Manual



Image: The Roomie Tec Alpha vacuum with its main body, floor brush, various attachments, and charging dock.

4. SETUP

Follow these steps to assemble your Roomie Tec Alpha vacuum cleaner:

1. Unpack all components from the box.
2. Connect the main vacuum body to the extension wand.
3. Attach the desired floor brush (multi-surface or specialized) to the bottom of the extension wand.
4. For upright use, ensure the handle is securely attached.

5. Place the auto charging base in a convenient location near a power outlet.
6. Plug the power adaptor into the charging base and then into a wall outlet.
7. Rest the vacuum on the charging base to begin charging. The battery indicator lights will show charging progress.



Image: The Roomie Tec Alpha vacuum standing upright next to its automatic charging base, highlighting its self-standing design.

Setup Video Guide

Your browser does not support the video tag.

Video: A user demonstrates the unboxing and assembly process of the Roomie Tec Alpha vacuum cleaner, showing how to connect the main components and prepare it for first use.

5. OPERATING INSTRUCTIONS

Power Modes


The Roomie Tec Alpha offers three power modes to suit different cleaning needs:

- **ECO Mode:** Provides up to 40 minutes of runtime for light cleaning and extended use.
- **MID Mode:** Offers up to 25 minutes of runtime for moderate cleaning tasks.
- **MAX Mode:** Delivers 22Kpa suction power for deep cleaning and stubborn dirt, with up to 10 minutes of runtime.

Switch between modes using the control buttons on the main unit.

Upright Vacuum Use

For general floor cleaning, use the vacuum in its upright configuration. The advanced microfiber roller and LED headlights ensure thorough cleaning on various surfaces, including hardwood, tile, and carpet.



EX WIDE
ENHANCED ROLLER
BRUSH & LED LIGHTS.

Image: A close-up of the vacuum's floor brush, showing the enhanced roller and illuminated LED headlights, designed for effective cleaning and visibility.

Handheld Vacuum Use

Detach the main unit from the extension wand to use it as a handheld vacuum. Attach the motorized pet brush, crevice tool, or dusting tool for specialized cleaning of furniture, stairs, car interiors, and tight corners.




Image: The Roomie Tec Alpha vacuum detached from its main body, demonstrating its use as a handheld unit for cleaning elevated surfaces.

PET FRIENDLY TURBO BRUSH INCLUDED.

ALSO WORKS FOR
SOFA, BED & OTHER FURNITURE.



Image: A close-up of the motorized pet brush attachment being used on upholstery, with a golden retriever observing in the background, highlighting its pet-friendly features.

Operation Video Guide

Your browser does not support the video tag.

Video: An official product video showcasing the Roomie Tec Alpha Cordless Upright Vacuum Cleaner in action, demonstrating its various features and cleaning capabilities on different surfaces.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying the Dustbin

To empty the dustbin, press the release button on the main unit to detach it. Open the bottom flap of the dustbin to release collected debris into a trash can. For thorough cleaning, the dustbin can be fully disassembled.

Cleaning the HEPA Filter and Stainless Steel Cyclone System

The HEPA filter and stainless steel cyclone system are designed for durability and easy maintenance. Remove the filter components from the dustbin. Rinse them under running water until clean. Allow all parts to air dry completely before reassembling and placing them back into the vacuum. This captures and contains 99% of dust, preventing re-entry into the air.



Image: A close-up of the HEPA filter, indicating its role in capturing dust and allergens for cleaner air.

Maintenance Video Guide

Your browser does not support the video tag.

Video: A user demonstrates how to empty the dustbin and clean the filter components of the Roomie Tec Alpha vacuum, highlighting the steps for proper maintenance.

7. TROUBLESHOOTING

- **No Power:** Ensure the battery is fully charged. Check if the power adaptor is correctly plugged into the charging base and wall outlet.
- **Reduced Suction:** Empty the dustbin. Clean the HEPA filter and stainless steel cyclone system. Check for any blockages in the floor brush or extension wand.
- **Brush Roll Not Spinning:** Check for tangled hair or debris around the brush roll. Ensure the brush roll is properly installed.
- **Unusual Noise:** Turn off the vacuum immediately. Check for any foreign objects caught in the brush roll or air pathways.

If issues persist after following these steps, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Roomie Tec
Model Name	ALPHA
Special Feature	22KPa Strong Suction, 7 lbs Lightweight Design, ECO Mode: up to 40 minutes, MAX Mode: up to 10 minutes, Upright Vacuum & Handheld Vacuum 2 in 1, Motorized Pet Brush, Auto Charging Base, Stainless Steel + HEPA Filtration System, Replacement Parts Readily Available
Filter Type	HEPA Filter + Stainless Steel Filtration System
Included Components	ALPHA Cordless Upright Vacuum, Floor Brush, Crevice Tool, Dusting Brush, Motorized Pet Brush, Auto Charging Base, HEPA Filter, Power Adaptor, User Manual
Is Cordless?	Yes
Capacity	1 Liters
Wattage	300 watts
Runtime	40 minutes
Maximum Suction	1.42 Inches
Recommended Uses For Product	For bigger space, longer cleaning time, home with pets or kids, stronger suction for deep cleaning, grab and go for quick jobs, lightweight for going up and down stairs.
Form Factor	Upright Cordless Vacuum, Stick Vacuum, Handheld Vacuum
Color	Gray
Product Dimensions	10.47"L x 11.89"W x 43.94"H
Battery Description	Lithium-Ion
Noise Level	68 dB
Item Weight	7 pounds

9. WARRANTY AND SUPPORT

Roomie Tec offers a 90-day money-back guarantee and a 2-year factory warranty for your product. For any concerns or assistance, please feel free to contact us via Amazon message or through our toll-free hotline.

Toll-Free Hotline: 1-888-262-2211

Our dedicated support team is based in Seattle and is ready to help you with any questions or issues you may have. We also store replacement parts in our California warehouse to ensure quick service.