

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOCHIC](#) /

› [TOCHIC 3-Light Brushed Gold Vanity Light with Capiz Shell Shade \(23" W\) Instruction Manual](#)

**TOCHIC d77e67f6-0499-4ce3-aabe-43e9d081c43a**

# TOCHIC 3-Light Brushed Gold Vanity Light with Capiz Shell Shade (23" W) Instruction Manual

Model: d77e67f6-0499-4ce3-aabe-43e9d081c43a

## 1. INTRODUCTION

---

Thank you for choosing the TOCHIC 3-Light Brushed Gold Vanity Light. This fixture features natural capiz shell shades and a brushed gold finish, designed to enhance various indoor spaces such as bathrooms, powder rooms, bedrooms, and living rooms. This manual provides essential information for safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.



Image 1.1: The TOCHIC 3-Light Brushed Gold Vanity Light with natural capiz shell shades.



Image 1.2: The vanity light showcased in different interior environments.

## 2. SAFETY INFORMATION

**WARNING:** To avoid the risk of electrical shock, always disconnect power at the main circuit breaker or fuse box before beginning installation or performing any maintenance. This fixture must be installed in accordance with all applicable local installation codes by a person familiar with the construction and operation of the product and the hazards involved. If you are unsure about the installation process, consult a qualified electrician.

- Ensure the mounting surface can support the weight of the fixture.
- Use only the specified bulb type and wattage (E12 base, Max 60W per bulb).
- Do not connect this fixture to an ungrounded electrical system.
- Do not attempt to alter the wiring or modify the fixture in any way.
- Keep flammable materials away from the light bulbs.
- This fixture is designed for indoor use only and is not water-resistant.

### 3. PACKAGE CONTENTS

---

Carefully unpack your fixture and check that all parts are included. If any parts are missing or damaged, do not attempt to assemble or install the fixture. Contact customer service for assistance.

- Light Fixture Body (Brushed Gold)
- Natural Capiz Shell Shades (pre-assembled or requiring attachment)
- Mounting Hardware (mounting plate, screws, wire nuts)
- Instruction Manual
- *Note: E12 bulbs are not included and must be purchased separately.*

### 4. SPECIFICATIONS

---

<b>Brand</b>	TOCHIC
<b>Model Number</b>	d77e67f6-0499-4ce3-aabe-43e9d081c43a
<b>Product Dimensions</b>	23.3" L x 4.92" W x 8.07" H
<b>Color</b>	Brushed Gold
<b>Material</b>	Alloy Steel, Metal, Natural Capiz Shell
<b>Number of Lights</b>	3
<b>Bulb Base</b>	E12
<b>Max Wattage per Bulb</b>	60W
<b>Voltage</b>	110 Volts
<b>Dimmable</b>	Yes (with compatible dimmable bulbs and dimmer switch)
<b>Installation Type</b>	Wall Mount, Hardwired
<b>Indoor/Outdoor Usage</b>	Indoor Use Only




Image 4.1: Product dimensions for planning installation.

## 5. INSTALLATION INSTRUCTIONS (SETUP)

Before you begin, ensure you have the necessary tools (screwdriver, wire strippers, electrical tape, safety glasses) and that the power supply is turned off at the circuit breaker.

- 1. Turn Off Power:** Locate the circuit breaker controlling the light switch for the installation area and turn it OFF. Verify power is off using a voltage tester.
- 2. Prepare Mounting Surface:** If replacing an existing fixture, remove it. Ensure the junction box is securely mounted and accessible.
- 3. Attach Mounting Plate:** Secure the mounting plate (included in hardware) to the junction box using the provided screws. Ensure it is level and stable.
- 4. Wire Connections:**
  - Connect the **black** wire from the fixture to the **black** (hot) wire from the junction box.
  - Connect the **white** wire from the fixture to the **white** (neutral) wire from the junction box.
  - Connect the **ground** wire (bare copper or green) from the fixture to the **ground** wire from the junction box and to the mounting plate.
  - Secure all connections with wire nuts and wrap with electrical tape for added safety.
- 5. Mount the Fixture:** Carefully align the fixture body with the mounting plate and secure it using the decorative nuts or screws provided. Ensure no wires are pinched.
- 6. Install Bulbs:** Screw three E12 base bulbs (Max 60W each, not included) into the sockets.

7. **Attach Capiz Shells (if not pre-assembled):** If the capiz shells are not pre-attached, carefully hook each shell onto the designated rings on the fixture frame.

8. **Restore Power:** Turn the power back ON at the circuit breaker. Test the light fixture.



Image 5.1: Detail of the natural capiz shells on the fixture.

## 6. OPERATING INSTRUCTIONS

---

The TOCHIC Vanity Light operates like a standard wall-mounted light fixture. It is designed to be dimmable, offering flexibility in lighting ambiance.

- **Turning On/Off:** Use your existing wall switch to turn the light fixture on or off.
- **Dimming Function:** If you have installed dimmable E12 bulbs and connected the fixture to a compatible dimmer switch (not included), you can adjust the brightness level by operating the dimmer switch. Ensure both the bulbs and the switch are rated for dimming.



Image 6.1: The vanity light illuminated with different color temperatures.

Your browser does not support the video tag.

Video 6.1: A demonstration of the Tochic shell vanity light in gold, showcasing its appearance and illumination.

## 7. MAINTENANCE

---

Regular maintenance will help preserve the appearance and functionality of your TOCHIC Vanity Light.

- **Cleaning:** Before cleaning, ensure the power is turned off. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or the natural capiz shells.
- **Bulb Replacement:** Always turn off the power before replacing bulbs. Allow bulbs to cool completely before touching them. Replace with E12 base bulbs, not exceeding 60W per bulb.
- **Shell Care:** The capiz shells are natural and delicate. Handle them with care during cleaning or if re-attaching.

## 8. TROUBLESHOOTING

---

If you encounter issues with your vanity light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	<ul style="list-style-type: none"><li>Power is off at the circuit breaker.</li><li>Loose wire connections.</li><li>Faulty bulb(s).</li><li>Faulty wall switch.</li></ul>	<ul style="list-style-type: none"><li>Check circuit breaker and ensure power is on.</li><li>Turn off power, check all wire connections.</li><li>Replace bulb(s) with new ones.</li><li>Test wall switch or consult an electrician.</li></ul>
Light flickers or dims improperly.	<ul style="list-style-type: none"><li>Incompatible bulbs or dimmer switch.</li><li>Loose wire connections.</li></ul>	<ul style="list-style-type: none"><li>Ensure both bulbs and dimmer switch are compatible for dimming.</li><li>Turn off power, check all wire connections.</li></ul>
Capiz shells are damaged or detached.	<ul style="list-style-type: none"><li>Accidental impact or improper handling.</li></ul>	<ul style="list-style-type: none"><li>Carefully re-attach detached shells to their hooks.</li><li>Contact customer service for replacement shells if severely damaged.</li></ul>

## 9. WARRANTY AND SUPPORT

For any questions, concerns, or issues regarding your TOCHIC Vanity Light, please contact our customer support. While specific warranty details are not provided in this manual, we are committed to ensuring your satisfaction with our products.

Please have your model number (d77e67f6-0499-4ce3-aabe-43e9d081c43a) and purchase information ready when contacting support.

You can visit the TOCHIC Store for more information or to contact support:

[Visit the TOCHIC Store on Amazon](#)