

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [vidaXL](#) /

› [vidaXL Automatic Folding Umbrella Model 149143 Instruction Manual](#)

## vidaXL 149143

# vidaXL Automatic Folding Umbrella Instruction Manual

Model: 149143

## INTRODUCTION

Thank you for choosing the vidaXL Automatic Folding Umbrella. This manual provides essential information for the safe and effective use, maintenance, and care of your umbrella. Please read these instructions carefully before first use and retain them for future reference.

## PRODUCT OVERVIEW

The vidaXL Automatic Folding Umbrella is designed for convenience and durability, offering protection from rain and sun. Its compact, foldable design makes it ideal for travel and daily use.

## Key Features:

- Automatic Open/Close Function:** Effortless operation with a single button.
- Water-Repellent Coating:** Ensures quick drying and effective rain protection.
- Foldable Design:** Compact for easy storage and portability.
- Rib Reinforcement:** Enhanced stability and resistance against wind.
- Multicolored Design:** A vibrant and stylish accessory.

## Components:

- Canopy (Multicolored fabric)
- Shaft (Metal)
- Handle (Ergonomic grip with automatic button)
- Ribs and Stretchers (Internal frame)
- Wrist Strap



Image: The vidaXL Automatic Folding Umbrella fully open, displaying its multicolored canopy and overall dimensions (75 cm height, 124 cm width).



Image: Underside view of the umbrella, highlighting the robust internal rib structure designed for wind resistance.

## SETUP

---

The vidaXL Automatic Folding Umbrella requires no assembly. It comes ready for immediate use.

### First Use:

1. Remove the umbrella from its packaging.
2. Unfasten the securing strap around the folded canopy.
3. The umbrella is now ready for operation.



Image: The umbrella in its compact, folded state, demonstrating its portability. One view shows it with the protective sleeve, the other without.

## OPERATING INSTRUCTIONS

---

This umbrella features an automatic open and close mechanism for ease of use.

### To Open the Umbrella:

1. Ensure the umbrella is pointing away from yourself and others.
2. Press the button located on the handle firmly. The canopy will automatically extend and lock into place.

## To Close the Umbrella:

1. Ensure the umbrella is pointing away from yourself and others.
2. Press the same button on the handle. The canopy will automatically retract.
3. Once the canopy is retracted, manually push both ends of the umbrella together until it clicks into its fully closed position. This step is crucial for the automatic mechanism to reset for the next opening.
4. Wrap the securing strap around the folded canopy and fasten it.



Image: A detailed view of the umbrella's handle, highlighting the automatic open/close button for convenient operation.

## MAINTENANCE

---

Proper care will extend the life of your vidaXL Automatic Folding Umbrella.

- **Drying:** Always allow the umbrella to dry completely in an open position before folding and storing it. This prevents mildew and preserves the fabric.
- **Cleaning:** If the canopy becomes dirty, wipe it gently with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the umbrella in a cool, dry place when not in use. Ensure it is fully dry before storing to prevent damage.

- **Avoid Force:** Do not force the umbrella open or closed manually if the automatic mechanism is engaged. Always use the button.

## TROUBLESHOOTING

---

### Umbrella does not open automatically:

- Ensure the umbrella was fully closed manually after its last use. The automatic mechanism requires the shaft to be fully retracted and clicked into place to reset.
- Check for any obstructions in the canopy or frame.

### Umbrella does not close automatically:

- Ensure the button is pressed firmly.
- Check for any obstructions preventing the canopy from retracting.

If you experience persistent issues, please contact customer support.

## SPECIFICATIONS

---

<b>Model Number</b>	149143
<b>Shape</b>	Round
<b>Material</b>	Fabric Polyester
<b>Finish</b>	Matte
<b>Dimensions (H x W x L)</b>	75 x 124 x cm (approximately 29.5 x 48.8 inches)
<b>Weight</b>	Approximately 0.46 kg (1.01 lbs)
<b>Color</b>	Multicolored

## WARRANTY AND SUPPORT

---

For information regarding warranty coverage or to obtain customer support, please refer to the purchase documentation or visit the official vidaXL website. Keep your proof of purchase for any warranty claims.

**Manufacturer:** vidaXL

**Website:** [www.vidaxl.com](http://www.vidaxl.com)