

NORTHCLAN NORTHCLAN

NORTHCLAN Ice Maker User Manual

Model: NORTHCLAN

1. INTRODUCTION

Thank you for choosing the NORTHCLAN Ice Maker. This manual provides important information regarding the safe operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before using the ice maker and keep it for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Ensure the appliance is placed on a stable, level surface to prevent tipping.
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Keep children and pets away from the appliance during operation.
- Use only potable water in the water tank.
- Unplug the appliance before cleaning or when not in use for extended periods.
- Ensure adequate ventilation around the appliance. Do not block air vents.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your NORTHCLAN Ice Maker:



Image: The NORTHCLAN Ice Maker in purple, showing the main unit, control panel, and an ice scoop with bullet-shaped ice cubes. The control panel features LED indicators for 'Ice Making', 'Ice Full', and 'Add Water', along with a power button.

- **Control Panel:** Features LED indicators and a power button.
- **Ice Making Indicator:** Snowflake icon, illuminates when ice is being produced.
- **Ice Full Indicator:** Three dots icon, illuminates when the ice basket is full.
- **Add Water Indicator:** Water drop icon, illuminates when the water tank needs refilling.
- **Water Tank:** Internal reservoir for water supply.
- **Ice Basket:** Removable basket to collect ice cubes.
- **Ice Scoop:** Included for convenient ice retrieval.
- **Air Vents:** Located on the side for heat dissipation.

4. SETUP

1. **Unpack:** Carefully remove the ice maker from its packaging. Remove all packing materials, including any tape or protective film.
2. **Placement:** Place the ice maker on a flat, stable, and level surface away from direct sunlight and heat sources. Ensure there is at least 10 cm (4 inches) of space around the unit for proper ventilation.
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the 'Maintenance' section for

detailed cleaning instructions.

4. **Fill Water Tank:** Open the lid and fill the water tank with potable water up to the MAX fill line. Do not overfill.
5. **Connect Power:** Plug the power cord into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

Follow these steps to operate your ice maker:

1. **Power On:** Press the power button on the control panel. The 'Ice Making' indicator (snowflake icon) will illuminate, and the ice making cycle will begin.
2. **Ice Production:** The first batch of ice cubes will be ready in approximately 5-8 minutes. The ice maker will continue to produce ice until the ice basket is full or the water tank is empty.
3. **LED Indicators:**
 - **Ice Making (Snowflake):** Lit when the machine is actively making ice.
 - **Ice Full (Three Dots):** Lit when the ice basket is full. The machine will pause ice production until ice is removed.
 - **Add Water (Water Drop):** Lit when the water level in the tank is low. The machine will pause. Refill the water tank to resume operation.
4. **Harvesting Ice:** Once ice cubes are formed, they will be dropped into the ice basket. Use the provided ice scoop to remove ice as needed.
5. **Power Off:** Press the power button again to turn off the ice maker.

6. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your ice maker.

Daily Cleaning:

- Unplug the appliance.
- Remove the ice basket and empty any remaining ice.
- Drain any remaining water from the water tank.
- Wipe the interior and exterior surfaces with a soft cloth and mild detergent. Rinse thoroughly with clean water.

Deep Cleaning (Monthly or as needed):

- Prepare a cleaning solution of water and vinegar (10:1 ratio) or a citric acid solution.
- Pour the solution into the water tank.
- Run a few ice making cycles (without consuming the ice) to circulate the cleaning solution.
- Drain the solution completely.
- Rinse the water tank and interior thoroughly with clean water multiple times to remove any residue or odor.
- Dry all parts before reassembling or storing.

Storage:

If the ice maker will not be used for an extended period, drain all water, clean the unit thoroughly, and store it in a dry, well-ventilated area.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice maker not working / No ice production	No power; Water tank empty; Ambient temperature too high.	Check power connection; Refill water tank; Ensure proper ventilation and cooler environment.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the secti

Submit question

Open the live page

<https://manuals.plus/asin/B09PFYT7YC>

More documents and user manuals: <https://manuals.plus/>