Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NUTRI FIT EB5681

NUTRI FIT Digital Bathroom Scale EB5681 User Manual

Model: EB5681

Introduction

Thank you for choosing the NUTRI FIT Digital Bathroom Scale. This manual provides essential information for the proper setup, operation, and maintenance of your scale. Please read it thoroughly before use to ensure accurate measurements and safe operation.

Safety Information

- Place the scale on a hard, flat surface. Avoid carpets or soft surfaces, as this can affect accuracy.
- The scale surface is made of tempered glass. It can be slippery when wet. Ensure the surface is dry before stepping on it.
- Do not jump on the scale or use it for purposes other than weighing.
- Keep the scale away from water and extreme temperatures.
- Do not attempt to disassemble or repair the scale yourself. Contact customer support for assistance.

Setup

1. **Unpack the Scale:** Carefully remove the scale from its packaging.
2. **Install Batteries:** Open the battery compartment on the underside of the scale. Insert the three AAA batteries provided, ensuring correct polarity. Remove any plastic isolation sheet if present.
3. **Placement:** Place the scale on a firm, flat, and stable surface. Avoid placing it on uneven floors or carpets, as this can lead to inaccurate readings.
4. **Unit Conversion:** To switch between pounds (lb) and kilograms (kg), locate the UNIT button on the back of the scale. Press it to toggle between the measurement units.




Image: Underside of the scale, highlighting the battery compartment and non-slip feet.

Video: Official NUTRI FIT video demonstrating unboxing, battery installation, and initial setup of the scale.

Operating Instructions

1. **Step-On Technology:** Gently step onto the center of the scale. The scale will automatically turn on and begin measuring your weight.
2. **Reading the Display:** Stand still on the scale. The LED display will show your weight. Once the reading stabilizes, it will flash a few times before locking the final weight.
3. **Auto-Off:** The scale will automatically turn off after a few seconds of inactivity to conserve battery life.
4. **Re-Test Function:** If you step off the scale and then back on quickly, the scale may display 'RE-TEST' or a similar prompt. This indicates that the scale is ready for another measurement.



Image: A person standing on the NUTRI FIT digital scale, demonstrating proper usage for weighing.



Image: A close-up view of the clear LED display on the NUTRI FIT scale, showing a weight measurement.

Maintenance

- **Cleaning:** Wipe the scale surface with a damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals. Ensure the scale is dry after cleaning.
- **Battery Replacement:** When the 'Lo' indicator appears on the display, it's time to replace the batteries. Open the battery compartment and replace all three AAA batteries with new ones.
- **Storage:** Store the scale in a cool, dry place. Its slim design allows for easy storage under furniture or in tight spaces.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
'Lo' Display	Low battery power.	Replace all three AAA batteries.
'Err' Display	Scale overload or unstable reading.	Ensure weight is within capacity (330 lb/150 kg). Step off, wait for the display to clear, then step on again. Ensure stable placement.
Inaccurate Readings	Scale not on a hard, flat surface; movement during measurement; initial calibration needed.	Place the scale on a hard, flat floor. Stand still during measurement. For initial use or after moving, step on the scale briefly to turn it on, let it display '0.0', then step off. Wait for it to turn off, then step on again for an accurate reading.
No Display	Batteries incorrectly installed or dead.	Check battery polarity. Replace batteries if necessary.



Image: Visual representation of the scale's display icons for low battery, overload, and auto-calibration.

Specifications

Feature	Detail
Brand	NUTRI FIT
Model Number	EB5681
Color	Normal Black
Weight Limit	330 Pounds (150 kg)
Readout Accuracy	0.2 Pounds (100g)
Display Type	LED
Material	Tempered Glass
Power Source	3 x AAA batteries (included)
Product Dimensions	10.2 x 10.2 x 0.8 inches (approx.)
Special Feature	Step-On Technology, Auto-Off, Auto-Zero, Unit Conversion

Warranty and Support

Your NUTRI FIT Digital Bathroom Scale comes with lifetime support. If you encounter any issues or have questions regarding your product, please contact NUTRI FIT customer service for assistance. Refer to the contact information provided in your product packaging or on the official NUTRI FIT website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09PG16MQT

More documents and user manuals: **https://manuals.plus/**