

[Manuals.plus](#) /

› [HORLAT](#) /

› HORLAT T01 5G WiFi Bluetooth Projector User Manual

HORLAT T01

HORLAT T01 5G WiFi Bluetooth Projector User Manual

Model: T01 | Brand: HORLAT

1. INTRODUCTION

The HORLAT T01 projector is a versatile 5G WiFi Bluetooth projector designed for home theater and outdoor video projection. It features a native 1080P resolution with 4K support, 360 ANSI lumens brightness, and a wide color gamut. The projector offers flexible connectivity options including 2.4G/5G WiFi screen synchronization, Bluetooth 5.1 for audio devices, and various wired inputs. It is capable of projecting a large display size from 25 to 250 inches, providing an immersive viewing experience.

2. PACKAGE CONTENTS

Please check the package carefully to ensure all items are present:

- HORLAT T01 Projector
- HDMI Cable
- Audio Cable
- Remote Control
- User Manual
- Setting Instruction Page

3. PRODUCT OVERVIEW

The HORLAT T01 projector is compactly designed in black, weighing approximately 3.56 pounds with dimensions of 8.74 x 10 x 4.52 inches. It features a prominent lens at the front and various input/output ports on the rear and sides for comprehensive connectivity.



Figure 3.1: Front view of the HORLAT T01 Projector with a smartphone displaying content.

3.1. Ports and Controls

The projector is equipped with multiple ports to connect various devices:

- **HDMI Ports (x2):** For connecting laptops, gaming consoles (PS5), TV sticks, and other HDMI-enabled devices.
- **USB Port:** For playing media directly from USB flash drives.
- **AV Port:** For connecting older devices using an AV cable.
- **Audio Out (3.5mm):** For connecting external speakers or headphones.



Figure 3.2: Rear view of the HORLAT T01 Projector highlighting its connectivity options.

4. SETUP

4.1. Basic Placement and Power

Place the projector on a stable, flat surface. Ensure adequate ventilation around the unit. Connect the power cable to the projector and then to a power outlet. Press the power button on the projector or remote control to turn it on.

4.2. Focus and Keystone Adjustment

To achieve a clear and rectangular image, adjust the focus and keystone correction:

- **Focus:** Use the front roller (focus ring) near the lens to sharpen the image until it appears clear.
- **Keystone:** Use the keystone adjustment wheel to correct any trapezoidal distortion, ensuring the projected image is rectangular. The projector supports up to 15 degrees keystone correction.



Figure 4.1: Adjusting focus and keystone for optimal image quality.

4.3. Connectivity

The HORLAT T01 offers multiple ways to connect your devices:

4.3.1. Wireless Screen Mirroring (2.4G/5G WiFi)

The projector adapts the latest WIFI smart phone synchronize screen technology to easily connect your iOS/Android device by simply connecting your WiFi. Ultra-fast 5G WiFi offers a much smoother and lag-free online video streaming experience.

2.4G+5G

Wireless Screening



Figure 4.2: Wireless screen mirroring via 2.4G and 5G WiFi.

4.3.2. Bluetooth Connection (5.1)

Utilize Bluetooth 5.1 to connect external audio devices such as Bluetooth headsets, speakers, or AirPods for enhanced sound. The projector can also function as a Bluetooth speaker when connected to your phone.

Bluetooth 5.1

Enjoy a Better Audio Experience



Figure 4.3: Bluetooth 5.1 connectivity for audio devices.

4.3.3. Wired Connections

Connect devices using the HDMI, USB, or AV ports as described in Section 3.1. Select the corresponding input source from the projector's menu.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

Press the power button on the projector's control panel or the remote control to turn the unit on or off.

5.2. Menu Navigation

Use the directional buttons (Up, Down, Left, Right) on the projector's control panel or the remote control to navigate through the on-screen menu. Press the "OK" button to confirm selections. The "Home" button returns to the main menu, and the "Back" button returns to the previous screen.

5.3. Media Playback

Select the desired input source (HDMI 1, HDMI 2, AV, USB, Mirroring) from the main menu. Once the source is selected, the projector will display content from the connected device. For USB playback, navigate to the "Movie," "Music," or "Photo" sections to browse files.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your projector:

- **Lens Cleaning:** Gently wipe the projector lens with a soft, lint-free cloth designed for optical surfaces. Do not use abrasive cleaners.
- **Ventilation:** Ensure the projector's ventilation openings are clear and unobstructed to prevent overheating. Do not place the projector on soft surfaces that may block airflow.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, ideally in its original packaging or a protective case.

7. TROUBLESHOOTING

If you encounter issues with your HORLAT T01 projector, refer to the following common solutions:

Problem	Possible Cause	Solution
No image/signal	Incorrect input source selected; loose cable connection; device not powered on.	Verify the input source matches the connected device. Check all cable connections (HDMI, USB, AV). Ensure the source device is powered on.
Blurry image	Focus not adjusted; incorrect projection distance.	Adjust the focus ring until the image is clear. Ensure the projector is at an appropriate distance from the screen/wall.
Image is trapezoidal	Keystone not adjusted.	Adjust the keystone correction wheel until the image is rectangular.
No sound	Volume too low; external audio device not connected or selected; audio format not supported.	Increase projector volume. Check external audio connections. Ensure audio format is supported.
Wireless mirroring issues	Weak WiFi signal; device compatibility; network interference.	Ensure strong WiFi signal. Check device compatibility. Try restarting both projector and source device.

8. SPECIFICATIONS

Feature	Detail
Brand	HORLAT
Model Number	T01
Display Resolution	Native 1920 x 1080 (Supports 4K)
Brightness	360 ANSI Lumens
Connectivity Technology	Wi-Fi (2.4G/5G), Bluetooth 5.1, HDMI (x2), USB, AV, Audio Out (3.5mm)
Projection Size	25" - 250" (63.5 cm - 635 cm)

Feature	Detail
Aspect Ratio	4:3 / 16:9
Speaker Type	Built-In Stereo (3W HiFi with Dolby Sound system)
Item Weight	3.56 pounds
Product Dimensions	8.74 x 10 x 4.52 inches
Color	Black



Figure 8.1: Brightness comparison of HORLAT T01.

9. WARRANTY AND SUPPORT

For detailed warranty information and technical support, please refer to the official HORLAT website or contact their customer service. You may also find additional resources and FAQs on the product's Amazon listing page.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question