

[Manuals.plus](#) /

› [WOWOW](#) /

› WOWOW Widespread 2-Handle Bathroom Faucet (Oil Rubbed Bronze) - Instruction Manual

WOWOW 2320500RB-AMUS

WOWOW Widespread 2-Handle Bathroom Faucet

INSTRUCTION MANUAL - MODEL: 2320500RB-AMUS

1. Safety Information

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in property damage or personal injury. Always turn off the main water supply before beginning any plumbing work. If you are unsure about any step, consult a qualified plumber.

2. Package Contents

Verify that all components are present before beginning installation. The package should include:

- Main Faucet Body (Spout)
- Hot and Cold Handles
- Pop-Up Drain Stopper
- Quick Connect Hose (Y-shaped)
- 2 x Water Supply Hoses (23.6-inch, cUPC-certified)
- Teflon Tape
- Wrench
- Pair of Gloves
- 2 x Aerators (1.2 GPM & 2.2 GPM)

600,000+ Cycle Test

THE BRASS + CERAMIC CARTRIDGE
HAS PASSED TESTING OF OVER

↑ Smooth
37%

↑ Avoid leakage
35%

↑ Stability
30%



Figure 2.1: All components included in the faucet package.



Figure 2.2: Exploded view of faucet components.

3. Product Dimensions

The faucet is designed for a 3-hole widespread installation, with adjustable spacing for the handles. Refer to the diagram below for detailed measurements.



Figure 3.1: Faucet dimensions and hole size requirements.

4. Installation Instructions

Follow these steps for a smooth installation. Ensure the main water supply is turned off before starting.

4.1. Preparation

1. Turn off the main water supply to your bathroom.
2. Remove your old faucet and clean the sink surface thoroughly.
3. Ensure the mounting holes on your sink or countertop match the faucet's requirements (1.1 to 1.5 inches for handles, 1.1 to 2.5 inches for spout).

4.2. Mounting the Faucet Components

1. Insert the hot and cold handles and the main spout body into their respective holes on the sink/countertop.
2. From underneath the sink, secure each component with the provided washers and mounting nuts. Hand-tighten first, then use the included wrench for a snug fit. Do not overtighten.

4.3. Connecting Water Hoses

1. Connect the hot and cold water supply lines to the corresponding hot (red label) and cold (blue label) inlets on the faucet handles. Use Teflon tape on the threads for a watertight seal.
2. Connect the unique 'Y' shaped quick connect hose to the hot and cold outlets from the handles and the main spout inlet. Push firmly until a 'click' is heard to ensure a secure connection.
3. Connect the other ends of the water supply hoses to your hot and cold water shut-off valves.



Figure 4.1: Quick connect hose installation.

4.4. Installing the Pop-Up Drain

1. Place the pop-up drain body into the sink drain hole.
2. From underneath, secure the drain body with the provided gasket and nut. Ensure a tight seal to prevent leaks.
3. Connect the drain assembly to your existing P-trap.

4.5. Final Steps

1. Turn on the main water supply.
2. Check all connections for leaks. Tighten any leaking connections as needed.
3. Remove the aerator from the spout and turn on both hot and cold water to flush out any debris for a few minutes. Reinstall the aerator.

Your browser does not support the video tag.

Video 4.1: Installation guide for the WOWOW Widespread Bathroom Faucet (Black finish shown).

5. Operation

Your WOWOW faucet is designed for ease of use and durability.

5.1. Water Flow and Temperature Control

The two lever handles control the hot and cold water flow. Turn the left handle for hot water and the right handle for cold water. Adjust both to achieve your desired water temperature and flow rate.




Figure 5.1: Hot and cold water control.

5.2. Swivel Spout

The high-arc spout features a 360-degree swivel function, providing greater flexibility and access to your sink. This is particularly useful for washing larger items or for multi-tasking.



Figure 5.2: Faucet with 360-degree swivel spout.

5.3. Pop-Up Drain

The included pop-up drain stopper allows for easy filling and draining of your sink. Simply press down on the stopper to close the drain and press again to open it.



Figure 5.3: Pop-up drain stopper operation.

6. Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your faucet.

6.1. Cleaning the Faucet

Clean the faucet regularly with a soft cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the oil rubbed bronze finish.

6.2. Aerator Maintenance

If water flow decreases or becomes irregular, the aerator may be clogged. Unscrew the aerator from the tip of the spout, clean any debris, and rinse thoroughly before reattaching. The faucet comes with two aerators (1.2 GPM and 2.2 GPM) to suit your water flow preferences.

7. Troubleshooting

If you encounter any issues, refer to the common problems and solutions below.

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator or partially closed water supply valve.	Clean the aerator. Ensure water supply valves are fully open.
Leaks from Faucet Base	Loose mounting nuts or worn gaskets.	Tighten mounting nuts. Check and replace gaskets if necessary.
Leaks from Connections	Loose connections or insufficient Teflon tape.	Tighten all hose connections. Reapply Teflon tape if needed.
Water Temperature Issues	Incorrect hot/cold hose connection or issues with water heater.	Verify hot and cold lines are connected correctly. Check water heater settings.

8. Specifications

- **Brand:** WOWOW
- **Model Name:** 2320500RB-AMUS
- **Finish Type:** Oil Rubbed Bronze
- **Material:** Metal (Brass connectors)
- **Mounting Type:** Deck Mount, Widespread (3-Hole)
- **Number of Handles:** 2 (Lever Type)
- **Spout Design:** High Arc, Standard
- **Spout Height:** 4.1 Inches
- **Spout Reach:** 4.7 Inches
- **Special Feature:** 360° Swivel Spout
- **Included Components:** Faucet, Pop Up Drain, Supply Hoses, Instruction Manual
- **Item Weight:** 3.72 Pounds

9. Warranty Information

This WOWOW faucet comes with a **5-year limited warranty** from the manufacturer. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included in your package or contact customer support.

10. Customer Support

If you have any questions, require assistance with installation, or need to report a problem, please contact WOWOW customer support through their official website or the contact information provided in your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question