

RYGHT R480491

RYGHT Jam True Wireless Earbuds User Manual

Model: R480491

INTRODUCTION

Welcome to your RYGHT Jam True Wireless Earbuds. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and a clear audio experience. Please read this guide thoroughly before using your earbuds.





RYGHT Jam True Wireless Earbuds and charging case.

PACKAGE CONTENTS

The RYGHT Jam True Wireless Earbuds package typically includes the following items:

- RYGHT Jam True Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your RYGHT Jam earbuds for proper handling and use.



RYGH T Jam True Wireless Earbuds, showing the left and right earbuds.





RYGHT Jam True Wireless Earbuds placed inside their charging case.



Diagram illustrating the dimensions of the RYGH T Jam earbuds and charging case in millimeters and inches.

SETUP

Charging the Earbuds and Case

Before initial use, fully charge both the earbuds and the charging case to ensure optimal battery life.

1. Place the earbuds into the charging case. Ensure they are correctly seated in their respective slots.
2. Connect the charging case to a USB power source using the provided USB cable.
3. The indicator light on the case will illuminate to show the charging status. A full charge typically takes approximately 1.5 to 2 hours.



Close-up view of the RYGHT Jam charging case, highlighting the USB charging port.

Pairing with a Bluetooth Device

Follow these steps to connect your RYGHT Jam earbuds to your smartphone or other Bluetooth-enabled audio device.

1. Ensure the earbuds are charged and placed inside the charging case.
2. Open the charging case lid. The earbuds will automatically power on and enter pairing mode, indicated by a flashing light.
3. On your device, navigate to the Bluetooth settings and enable Bluetooth.
4. Select "RYGHT Jam" from the list of available devices.
5. Once connected, you will hear an audible confirmation, and the earbuds will be ready for audio playback.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Open the charging case, or remove the earbuds from the case. They will power on automatically.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically.

Touch Controls

The RYGHT Jam earbuds feature intuitive touch controls for managing audio playback and calls.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.



RYGHT Jam earbuds in their charging case, illustrating the touch control area on the stem of the earbuds.

Making and Receiving Calls

Utilize the integrated microphone for hands-free communication.

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

Voice Assistant

Activate your device's voice assistant (e.g., Siri, Google Assistant) by triple tapping either earbud.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your RYGHT Jam earbuds.

- **Cleaning:** Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using harsh chemicals, abrasive materials, or excessive moisture.
- **Storage:** When not in use, always store the earbuds in their charging case. This protects them from damage and keeps them charged.
- **Water Resistance:** The earbuds are water-resistant. While they can withstand splashes and light rain, avoid submerging them in water or exposing them to high-pressure water jets.
- **Temperature:** Do not expose the product to extreme temperatures (below 0°C or above 45°C) as this can affect battery life and performance.

TROUBLESHOOTING

If you encounter issues with your RYGHT Jam earbuds, refer to the following common solutions.

Earbuds not pairing

- Ensure both earbuds are sufficiently charged.
- Turn off Bluetooth on your device, wait a few seconds, and then turn it back on.
- Forget "RYGHT Jam" from your device's Bluetooth list and attempt to re-pair.
- Place the earbuds back into the charging case, close the lid, wait 10 seconds, then open the lid to re-initiate pairing mode.

No sound or low volume

- Check the volume level on both your connected device and the earbuds.
- Ensure the earbuds are properly connected to your device and not to another nearby device.
- Clean any debris from the earbud speakers that might be obstructing sound.

Charging issues

- Verify that the charging cable and power adapter are functioning correctly.
- Ensure the earbuds are correctly seated in the charging case and that the charging contacts are clean.
- Try using a different USB charging cable or power source.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model	R480491
Connectivity Technology	Bluetooth (Wireless)
Headphones Form Factor	Semi-in-ear
Frequency Range	20 Hz - 20,000 Hz
Water Resistance Level	Water-resistant
Control Method	Touch, Application
Dimensions (Earbuds + Case)	5.3 x 4.7 x 2.4 cm
Weight	37 g
Color	Black
Material	Plastic
Operating System Compatibility	Android (and generally iOS/other Bluetooth devices)

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the RYGHT official website or contact your authorized retailer. It is recommended to retain your proof of purchase for any warranty claims.

For further assistance or to view additional product information, please visit the RYGHT website: www.ryght.com