

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PHI VILLA](#) /

› [PHI VILLA Rattan Dresser Model IF-474 Instruction Manual](#)

PHI VILLA IF-474

PHI VILLA Rattan Dresser Instruction Manual

Model: IF-474

1. INTRODUCTION

Thank you for choosing the PHI VILLA Rattan Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The PHI VILLA Rattan Dresser, a three-drawer unit with natural rattan fronts and a light oak finish, positioned as a nightstand next to a bed.

2. SAFETY INFORMATION

WARNING: Small parts, screws, and accessories could pose a choking hazard for young children. Keep these items out of reach of children to prevent accidental swallowing during assembly and use.

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload drawers. Distribute weight evenly.
- For stability, consider anchoring the dresser to a wall, especially if children are present. Wall anchoring hardware may be sold separately.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components and hardware are present. Refer to the detailed parts list included in your assembly guide. If any parts are missing or damaged, please contact customer support.

- Dresser panels (top, bottom, sides, back)
- Drawer components (fronts with rattan, sides, backs, bottoms)
- Legs and mounting hardware
- Drawer slides and handles
- Assembly hardware (screws, dowels, cam locks, etc.)
- Assembly instructions manual

4. SETUP AND ASSEMBLY

Assembly is required for this product. Please follow the step-by-step instructions provided in the separate assembly guide included in your package. It is recommended to have two people for assembly to ensure stability and ease of handling larger components.



Image 4.1: A diagram illustrating the dimensions of the PHI VILLA Rattan Dresser: 31.5"W x 15.7"D x 35.4"H, with a leg height of 6.9" and drawer height of 8.9". It also indicates the material as Premium MDF with Rattan and capacity of 110 lbs for the countertop and 25 lbs per shelf/drawer.

Assembly Tips:

- Organize all parts and hardware before starting.

- Use the correct tools as specified in the assembly guide.
- Do not overtighten screws, as this can damage the material.
- If you encounter any difficulties, refer to the troubleshooting section or contact customer support.

5. OPERATING INSTRUCTIONS

The PHI VILLA Rattan Dresser features three smooth-gliding drawers for storage. To operate:

- **Opening Drawers:** Gently pull the drawer handle outwards to open.
- **Closing Drawers:** Push the drawer inwards until it is fully closed and flush with the dresser frame.
- Avoid forcing drawers open or closed if they encounter resistance. Check for obstructions.



Image 5.1: A close-up view of the top drawer of the PHI VILLA Rattan Dresser, shown partially open, revealing the interior storage space and the light wood grain finish.

6. MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe with a dry cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the

finish and rattan.

- **Spills:** Immediately blot any spills with a clean, dry cloth.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading of the wood finish and rattan.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of wood components.

7. TROUBLESHOOTING

Common Issues and Solutions:

- **Drawers do not slide smoothly or get stuck:**
 - Check if the drawer slides are correctly aligned and securely attached to both the drawer and the dresser frame.
 - Ensure no objects are obstructing the drawer's path inside the dresser.
 - Verify that the drawer is assembled correctly and not warped.
- **Dresser feels wobbly:**
 - Ensure all assembly screws and fasteners are fully tightened.
 - Check that the dresser is placed on a level surface. Adjust leg levelers if applicable.
 - Consider using wall anchoring hardware for added stability.
- **Missing parts during assembly:**
 - Carefully re-check all packaging materials.
 - Contact PHI VILLA customer support with your model number and a description of the missing part.

8. SPECIFICATIONS

Feature	Detail
Brand	PHI VILLA
Model Number	IF-474
Product Dimensions	15.7"D x 31.5"W x 35.5"H
Color	Rattan
Furniture Finish	Oak
Material	MDF board and Rattan
Item Weight	68.3 Pounds
Number of Drawers	3
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth

9. WARRANTY AND SUPPORT

PHI VILLA offers a **Limited Warranty** for this product. For specific details regarding warranty coverage and duration, please refer to the warranty card included with your purchase or contact PHI VILLA customer service.

Customer Support:

PHI VILLA is committed to providing excellent customer experience. We offer a **365-Day Service** period. If you have any questions, suggestions, or require support, please do not hesitate to contact us directly. Our team is ready to assist you with any issues or concerns.


For assistance, please visit the official PHI VILLA store or contact us through the platform where you made your purchase.

[Visit the PHI VILLA Store](#)

© 2023 PHI VILLA. All rights reserved.

Related Documents - IF-474

	<p>PHI VILLA Furniture Use and Care Instructions</p> <p>Comprehensive guide to using and caring for PHI VILLA furniture, including tips for wood, leather, granite, faux wood/marble, metal, and fabric materials to ensure longevity and beauty.</p>
	<p>PHI VILLA Use and Care Guide for Outdoor Furniture (E02GF119, PV-432-4)</p> <p>Comprehensive use and care guide for PHI VILLA outdoor furniture, including assembly instructions, safety information, and warranty details for models E02GF119 (round table) and PV-432-4 (wicker chairs).</p>
	<p>PHI VILLA Patio Dining Set Assembly and Care Guide PV-201</p> <p>Comprehensive use and care guide and assembly instructions for the PHI VILLA PV-201 7-Piece Rattan Patio Outdoor Dining Set. Includes safety information, assembly steps, parts list, and maintenance tips.</p>

	<p><u>PHI VILLA Furniture Use and Care Guides: PV-023, PV-024, PV-027</u></p> <p>Comprehensive use and care guide for PHI VILLA furniture models PV-023, PV-024, and PV-027, including safety information, warranty details, parts lists, and assembly instructions.</p>
	<p><u>PHI VILLA 7-Piece Outdoor Dining Set Use and Care Guide</u></p> <p>Comprehensive guide for PHI VILLA 7-Piece Outdoor Dining Set, covering assembly, safety, care, and warranty information.</p>
	<p><u>PHI VILLA 4-Piece Cushion Box Rattan Sofa Set Assembly Instructions and User Manual</u></p> <p>Comprehensive assembly instructions and user manual for the PHI VILLA 4-Piece Cushion Box Rattan Sofa Set, detailing parts, hardware, and step-by-step assembly for the sofa, cushion box, and table. Includes customer support information and product overview.</p>