Oraimo OHV-101

Oraimo OHV-101 Cordless Handheld Vacuum User Manual

Model: OHV-101

1. Introduction and Overview

The Oraimo OHV-101 is an ultra-lightweight, cordless handheld vacuum designed for convenient and efficient cleaning in various environments, including homes, kitchens, cars, and upholstery. Its compact design and powerful suction make it suitable for picking up dust, crumbs, pet hair, and other small debris.

This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your Oraimo OHV-101 handheld vacuum.



Image: The Oraimo OHV-101 handheld vacuum in use, demonstrating its ease of handling for various users.

2. Package Contents

Please verify that all items listed below are included in your package:

- Oraimo OHV-101 Handheld Vacuum Unit

- Crevice Tool
- Brush Nozzle
- USB Charging Cable (Type-C)
- User Manual



Image: The Oraimo OHV-101 handheld vacuum and its complete set of accessories.

3. Safety Instructions

To ensure safe operation and prevent damage, please read and adhere to the following safety guidelines:

- Do not use the vacuum to pick up flammable or combustible liquids, hot ashes, or sharp objects.
- Keep the vacuum away from water or other liquids. Do not immerse the unit.
- Ensure the charging cable and port are dry before charging.
- Do not operate the vacuum with a damaged cord or plug.

- Keep hair, loose clothing, fingers, and all body parts away from openings and moving parts.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Only use attachments recommended by the manufacturer.
- Store the vacuum in a dry, indoor location when not in use.

4. Setup

4.1 Initial Charging

Before first use, fully charge the vacuum. Connect the provided USB Type-C charging cable to the vacuum's charging port and plug the other end into a compatible USB power source (e.g., wall adapter, computer, car charger). The charging indicator will illuminate. A full charge typically takes approximately 3.5 hours.







Image: The Oraimo OHV-101 vacuum connected to a USB-C charger.

4.2 Attaching Accessories

To attach an accessory, align it with the vacuum's suction opening and push firmly until it clicks into place. The crevice tool is ideal for narrow spaces, while the brush nozzle can be used for upholstery and delicate surfaces. The brush nozzle is designed to be used in conjunction with the crevice tool for optimal performance.



Image: Proper attachment of the brush nozzle to the crevice tool.

5. Operating Instructions

5.1 Powering On/Off

To turn on the vacuum, press the power button. Due to the soft start motor, wait approximately 3 seconds for the vacuum to reach full operating power. To turn off the vacuum, press the power button again. There is no need to continuously

press the button during cleaning.

5.2 General Cleaning

Hold the vacuum firmly and move the nozzle over the area to be cleaned. The powerful suction is effective for various dry debris.




Image: The vacuum in action, demonstrating its suction capability.

5.3 Using Attachments for Specific Areas

- **Crevice Tool:** Use for tight corners, gaps, and hard-to-reach areas in your car, furniture, or along baseboards.
- **Brush Nozzle:** Attach to the crevice tool for cleaning upholstery, carpets, and delicate surfaces, effectively removing pet hair and crumbs.




Image: Versatile cleaning applications of the vacuum in home and car settings.

5.4 Low Noise Operation

The vacuum operates at a low noise level (70 dB), allowing for cleaning without significant disturbance to your surroundings or others.



Image: The vacuum operating quietly in a living room environment.

6. Maintenance and Cleaning

6.1 Emptying the Dust Bin

To maintain optimal suction, empty the dust bin regularly. Press the dust bin release button to detach the dust bin from the main unit. Dispose of the collected debris.

6.2 Cleaning the Filter

The HEPA filter is washable and reusable. After emptying the dust bin, remove the filter. Rinse the filter under running water until clean. Ensure the filter is completely dry before reinserting it into the dust bin and reattaching the dust bin to the vacuum unit. Do not operate the vacuum without a dry filter.



Image: Step-by-step guide for emptying the dust bin and cleaning the filter.

6.3 Filter Replacement

Over time, the filter may require replacement. Replacement filters can be purchased using ASIN:B0BX9H823W.

7. Troubleshooting

If you encounter issues with your Oraimo OHV-101 vacuum, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Weak suction	Dust bin full; Filter clogged; Nozzle blocked	Empty dust bin; Clean/replace filter; Clear any blockages from the nozzle.
Vacuum does not turn on	Battery depleted; Power button not pressed correctly	Charge the vacuum fully; Ensure the power button is pressed for 3 seconds to activate the soft start motor.
Short battery life	Battery not fully charged; Aging battery	Ensure the vacuum is fully charged before use; Contact customer support if battery performance significantly degrades.
Charging indicator not working	Charging cable or adapter faulty; Charging port damaged	Try a different USB-C cable and power adapter; Contact customer support.

8. Specifications

Feature	Detail
Brand	Oraimo
Model	OHV-101
Weight	1.39 pounds
Dimensions (L x W x H)	13.78" x 3.94" x 4.53"
Wattage	75 watts
Noise Level	70 dB
Battery Life	Up to 18 minutes
Filter Type	Washable HEPA Filter
Connectivity	USB Type-C
Controller Type	Push Button

9. Warranty and Support

The Oraimo OHV-101 handheld vacuum comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

For warranty claims, technical assistance, or any product-related inquiries, please contact Oraimo customer service. Our team is available to provide support and solutions.

Even after the initial warranty period, replacement or warranty service may be provided if deemed reasonable. Oraimo is

committed to ensuring a satisfactory cleaning experience for all customers.

© 2025 Oraimo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question