

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Goplus](#) /
- › [Goplus Inflatable Water Trampoline Instruction Manual](#)

Goplus TW10011

Goplus Inflatable Water Trampoline Instruction Manual

Model: TW10011

Brand: Goplus

1. INTRODUCTION

This manual provides essential instructions for the safe and proper setup, operation, and maintenance of your Goplus Inflatable Water Trampoline. Please read all instructions carefully before use to ensure safety and product longevity.

Safety Warning: Children must be supervised by adults at all times while using this product. Recommended for individuals 14 years old and above. Ensure the water depth is over 6.5 feet (2 meters) for safe operation.



The Goplus Inflatable Water Trampoline provides a fun bouncing surface for water activities.

2. WHAT'S INCLUDED

Verify that all components listed below are present in your package:

- 1 x Water Bouncer (Inflatable Trampoline)
- 1 x 500W Electric Inflator
- 3 x Mooring Ropes
- 1 x Rope Ladder
- 1 x Anchor (Water/Sand Fillable)

All-in-1 Package



The package includes all necessary accessories for setup and use.

3. SETUP INSTRUCTIONS

1. **Unfold the Bouncer:** Lay the deflated water bouncer on a flat, clean surface, free from sharp objects.
2. **Connect the Inflator:** Locate the high-sealed valve on the bouncer. Open the valve cap. Connect the nozzle of the 500W electric inflator to the valve.
3. **Inflate:** Turn on the electric inflator. Inflate the bouncer until it is firm to the touch, but do not over-inflate. The maximum pressure is 3.7 PSI. Inflation typically takes about 10 minutes.
4. **Secure the Valve:** Once inflated, quickly remove the inflator nozzle and securely close the valve cap to prevent air leakage.
5. **Attach Mooring Ropes and Anchor:** Use the provided mooring ropes to secure the trampoline. Fill the anchor with water or sand and attach it to the trampoline to increase stability on the water.
6. **Attach Rope Ladder:** Securely attach the rope ladder to the designated handles on the side of the trampoline for easy boarding.

10 Minutes to Inflate with 500W Powerful Electric Pump


Max Pressure: 3.7 PSI



Take out the bouncer and unfold it



Connect the nozzle and the valve



Keep blowing



Ready to hit the water

Inflation is quick and easy with the included 500W electric inflator.



Key design features ensure safety and durability, including secure valves and handles.

Setup Video

Your browser does not support the video tag.

This video demonstrates the unfolding and inflation process of the Goplus Inflatable Water Trampoline.

4. OPERATING INSTRUCTIONS

The Goplus Inflatable Water Trampoline offers multiple recreational uses:

- **Water Bouncing:** The large jumping surface, made of high-elastic nylon cloth, allows for bouncing activities. The design utilizes durable bungee cords instead of metal springs, making it suitable for water environments.
- **Swim Platform:** Use the trampoline as a stable platform for resting after swimming. The reinforced handles and rope ladder facilitate easy boarding from the water.
- **Sunbathing & Relaxation:** The spacious surface is ideal for sunbathing or simply relaxing on the water.
- **Fishing:** With the anchor properly deployed, the trampoline can serve as a stable base for fishing activities.

The trampoline has a weight capacity of up to 330 pounds, suitable for one adult or two teenagers simultaneously.



HIGH BOUNCY NYLON FABRIC

High Elasticity Water Proof Weather Resistance

The high-elastic, waterproof, and weather-resistant nylon fabric provides a durable bouncing surface.

Premium Rope Ladder

Ensures your safety & comfort



Ours

Sturdy Ladder with
Anti-slip Protection

Others

Unsafe Slippery
Ladder

The sturdy rope ladder with anti-slip protection ensures safe boarding.

Have Bouncy Fun Outdoors

Great for a family summer getaway

Calm Sea

Lake

Pool

Lawn

Enjoy the water trampoline in various outdoor water environments like lakes and pools.

5. MAINTENANCE

- **Cleaning:** After each use, rinse the trampoline with fresh water to remove salt, chlorine, or debris. Use mild soap and water for stubborn dirt.
- **Drying:** Ensure the trampoline is completely dry before deflating and storing to prevent mold and mildew growth.
- **Storage:** Deflate the trampoline and fold it neatly. Store in a cool, dry place away from direct sunlight and extreme temperatures. Protect it from rodents and insects.
- **Inspection:** Regularly inspect the PVC material, nylon cloth, bungee cords, and valves for any signs of wear, punctures, or damage. Address any issues promptly to maintain safety and performance.

6. TROUBLESHOOTING

Trampoline does not hold air:

Check the valve cap to ensure it is securely closed. Inspect the entire surface of the trampoline for any punctures

or leaks. Small leaks can often be repaired with a PVC repair kit (not included).

Difficulty boarding from water:

Ensure the rope ladder is securely attached and positioned correctly. The ladder is designed with anti-slip protection for easier climbing. If the water is too deep or currents are strong, additional assistance may be required.


Trampoline drifts excessively:

Verify that the anchor is properly filled with water or sand and securely attached. In strong currents or windy conditions, additional mooring points or a heavier anchor may be necessary.

7. SPECIFICATIONS

Feature	Detail
Brand	Goplus
Model Name	TW10011
Material	PVC + Oxford Cloth
Color	Blue & Green / Yellow & Green
Frame Size Options	10FT / 12FT / 15FT
Product Dimensions (15FT)	180"L x 180"W x 25.5"H (457cm x 457cm x 65cm)
Diameter of Bouncing Area (15FT)	132" (335cm)
Item Weight (15FT)	65 lbs (29.5 kg)
Maximum Weight Recommendation	330 lbs (150 kg)
Max Pressure	3.7 PSI
Required Water Depth	6.5 ft (2 meters)
Recommended Age	14 years old+

Product Dimensions



Jumping Area Diameter: 11ft/8ft/6ft



Weight Capacity: 330 lbs



1 Adult or 2 Teenagers



Required Water Depth: 6.5 ft

Available in multiple sizes, each designed for specific jumping area diameters and weight capacities.

8. WARRANTY AND SUPPORT

Warranty: This product comes with a 90-day warranty against manufacturer defects.

Customer Support: For any questions, concerns, or assistance with your Goplus Inflatable Water Trampoline, please contact Goplus customer service. Refer to your purchase documentation for specific contact details or visit the official Goplus website.