

## AGARO 33654

# AGARO Signify Handheld Garment Steamer

Model: 33654

[Overview](#)   [Setup](#)   [Operation](#)   [Safety Instructions](#)   [Product](#)  
[Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. SAFETY INSTRUCTIONS

Please read all instructions carefully before using the AGARO Signify Handheld Garment Steamer. Retain this manual for future reference.

- Always ensure the voltage matches your power supply before plugging in the appliance.
- Do not immerse the steamer, power cord, or plug in water or other liquids.
- Keep the steamer out of reach of children and pets.
- Never direct steam towards people, animals, or directly onto electrical appliances. Steam is hot and can cause burns.
- Use only distilled or demineralized water to prevent mineral buildup and prolong the life of the steamer.
- Unplug the steamer from the power outlet when not in use, before filling or emptying the water tank, and before cleaning.
- Do not operate the steamer if it has a damaged cord or plug, or if it has been dropped or damaged.
- Always place the steamer on a stable, heat-resistant surface when not in use.
- Do not overfill the water tank. Fill only up to the MAX level to prevent water dripping.
- The steamer features dry boiling protection and an auto cut-off for overheating. If the water level is too low or empty, the machine will automatically turn off.

## 2. PRODUCT OVERVIEW

The AGARO Signify Handheld Garment Steamer is designed for efficient wrinkle removal and garment refreshing. Its compact and lightweight design makes it ideal for both home use and travel.

## Key Features:

- **Vertical and Horizontal Steaming:** Effectively removes wrinkles from hanging garments and flat fabrics.
- **Fast Heat-up:** Reaches steaming temperature in approximately 40 seconds.
- **Ceramic Coated Steam Plate:** Ensures even heat distribution for optimal results.
- **Large Water Tank:** Detachable 260ml water tank provides up to 15 minutes of continuous steam.
- **Safety Features:** Includes dry boiling protection and auto cut-off for overheating.
- **Versatile Attachments:** Comes with a detachable fabric brush and a lint brush.

## Components:

Familiarize yourself with the parts of your garment steamer:



Image: Labeled diagram of the Agaro Signify Handheld Garment Steamer highlighting its components: Ceramic Coated Plate, Power / Steam Button, LED Power Indicator, Water Tank Opening Button, 260 ml Removable Water Tank, and 1.7 meters Power Cord.

- Ceramic Coated Steam Plate
- Power / Steam Button
- LED Power Indicator

- Water Tank Opening Button
- 260 ml Removable Water Tank
- 1.7 meters Power Cord
- Fabric Brush (Included)
- Lint Brush (Included)



Image: Dimensions of the Agaro Signify Handheld Garment Steamer, showing it is approximately 10 inches tall and 6 inches wide at the head. Also shown are the included Fabric Brush and Lint Brush.

### 3. SETUP

1. **Remove Water Tank:** Press the water tank opening button and pull out the removable 260ml water tank from the main unit.
2. **Fill Water Tank:** Open the rubber stopper on the water tank. Fill the tank with distilled or demineralized water up to the 'MAX' level indicated. Do not overfill.

## REMOVABLE 260ML WATER TANK

Gives you 15 minutes of  
continuous steam



*Image: A hand pouring water into the removable 260ml water tank of the Agaro Signify Handheld Garment Steamer. The MAX and MIN fill lines are visible.*



## CAUTION



Fill the water up to  
“MAX” level only.

(Caution: Do not fill the water beyond the MAX level. Filling more than MAX level will lead to water dripping from the mouth once the water starts to boil)



*Image: A diagram illustrating the correct water level (MAX) for the steamer's tank, with a caution against overfilling to prevent dripping.*

3. **Close and Reattach Tank:** Securely close the rubber stopper and reattach the water tank to the main unit until it clicks into place.
4. **Attach Brush (Optional):** Select the appropriate brush (fabric brush for general garments, lint brush for jackets/blazers) and attach it to the steam plate if desired.

## 4. OPERATING INSTRUCTIONS

1. **Power On:** Plug the steamer into a suitable power outlet. The LED power indicator will illuminate.
2. **Heat Up:** Allow approximately 40 seconds for the steamer to heat up. The LED indicator may change color or stop blinking when ready.
3. **Start Steaming:** Press the Power / Steam button to release steam.

# AGARO

## Garment Steamer

### Model: Signify



Ceramic Coated  
Plate



Automatic  
Continuous Steam



260 ML  
Water Tank



*Image: The Agaro Signify Handheld Garment Steamer in action, emitting steam onto a light green hoodie hanging on a rack, demonstrating vertical steaming.*

# FAST HEATING

The powerful 1500W steamer brush re-heats to steam in 40 seconds



*Image: The Agaro Signify Handheld Garment Steamer emitting steam onto a white shirt, illustrating its fast heating capability.*

#### 4. Steaming Technique:

- For hanging garments, hold the fabric taut with one hand and move the steamer head slowly over the fabric in an up-and-down motion.
- For horizontal steaming, place the garment on a flat, heat-resistant surface and glide the steamer over the fabric.
- Use the fabric brush for general steaming and the lint brush for removing lint and pet hair while steaming.

5. **Finish Steaming:** When finished, release the Power / Steam button and unplug the steamer from the power outlet.

#### Instructional Video:

Your browser does not support the video tag.

*Video: A demonstration of how to set up and use the AGARO Signify Handheld Garment Steamer, including filling the water tank, attaching brushes, and steaming various garments.*

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your steamer.

- **Empty Water Tank:** After each use, unplug the steamer and allow it to cool completely. Remove the water tank and empty any remaining water.
- **Clean Exterior:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Descale (Periodically):** If you notice reduced steam output or mineral residue, descale the steamer. Mix equal parts white vinegar and water, fill the tank to the MIN level, and run the steamer until the tank is empty. Repeat with clean water to rinse.
- **Store:** Store the steamer in a cool, dry place, away from direct sunlight and moisture. Ensure the water tank is empty before storage.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam output	Water tank is empty or low. Steamer not heated up. Mineral buildup.	Fill water tank. Wait for 40 seconds for heat-up. Descale the steamer.
Water dripping from steam plate	Water tank overfilled. Steamer not fully heated.	Do not fill past MAX line. Allow full heat-up before use.
Steamer automatically shuts off	Low water level or overheating protection activated.	Refill water tank. Allow steamer to cool down if it overheated.
Steam is weak or inconsistent	Mineral buildup in the steam vents.	Perform descaling procedure.

## 7. SPECIFICATIONS

- **Brand:** AGARO
- **Model Number:** 33654
- **Color:** Black and Blue
- **Wattage:** 1500 Watts
- **Voltage:** 230 Volts
- **Water Tank Capacity:** 260 Milliliters
- **Heat Time:** Approximately 40 seconds to steam ready
- **Continuous Steam Time:** Up to 15 minutes
- **Steam Output:** 25g/min
- **Item Weight:** 1020 Grams
- **Included Components:** Lint Brush, Fabric Brush
- **Safety Features:** Dry Boiling Protection, Auto Cut-off for Overheating

## 8. WARRANTY & SUPPORT

The AGARO Signify Handheld Garment Steamer comes with a **1-year warranty** from the date of purchase, covering manufacturing defects.



*Image: The Agaro Signify Handheld Garment Steamer displayed with a '1 Year Warranty' badge, highlighting its Ceramic Coated Plate, Automatic Continuous Steam, and 260ml Water Tank features.*

For warranty claims, technical support, or any product-related inquiries, please contact AGARO customer service:

- **Manufacturer:** Universal Corporation Limited, NINGBO CHINA
- **Importer:** Universal Corporation Limited, 4/1 Middleton street, Sikkim commerce house, Kolkata-71
- Refer to your purchase receipt for specific contact details or visit the official AGARO website.