



Manuals.plus /

› Sparkleiot /

› Sparkleiot Zigbee Smart LED Downlight Instruction Manual

Sparkleiot zigbee smart downlight

Sparkleiot Zigbee Smart LED Downlight Instruction Manual

Model: zigbee smart downlight

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Sparkleiot Zigbee Smart LED Downlight. Please read this manual thoroughly before installation and use to ensure proper function and safety.

SETUP

1. Physical Installation

The Sparkleiot Zigbee Smart LED Downlight is designed for recessed installation. Ensure power is off before beginning installation.

1. Use appropriate tools to cut holes in the ceiling according to the lamp size. The recommended hole size is 90-110mm.
2. Connect the reserved wire to the lamp link. This step should be performed by a qualified electrician.
3. Insert the spring buckles at both ends of the product vertically into the holes.
4. Push the product into the ceiling until the spring buckles secure it. Turn on the power for use.

set up easily to zigbee 3.0 hub



Image: Step-by-step guide for installing the downlight, showing cutting the hole, connecting wires, and securing with spring clips.



Image: Visual representation of the easy installation process for the recessed lighting.

2. Pairing with a Zigbee Hub

This smart downlight requires a compatible Zigbee hub for smart functionality. It supports Samsung SmartThings, Hubitat, Sonoff, eWeLink, and Tuya ZigBee 3.0 gateways. No direct connection to 2.4G or 5G Wi-Fi networks is needed.

1. Ensure your Zigbee hub is powered on and in pairing mode.
2. Turn the downlight on and off three times to initiate pairing mode. The light may flash to indicate it is searching for a hub.
3. Instruct your voice assistant (e.g., Alexa) to