



Manuals.plus /

› AIBORS /

› AIBORS 12V High Power Pet Grooming Clippers Instruction Manual (Model PT01)

AIBORS PT01

AIBORS 12V High Power Pet Grooming Clippers

Model: PT01

Brand: AIBORS

INTRODUCTION

Thank you for choosing the AIBORS 12V High Power Pet Grooming Clippers. This manual provides essential information for the safe and effective use, maintenance, and care of your new grooming tool. Please read these instructions thoroughly before first use and retain for future reference.



Figure 1: AIBORS 12V High Power Pet Grooming Clippers in use.

PACKAGE CONTENTS

The AIBORS Pet Grooming Kit includes the following items:

- 1x Pet Electric Clippers
- 4x Guide Combs (3mm, 6mm, 9mm, 12mm)
- 1x Cleaning Brush
- 1x Storage Bag
- 1x User Manual



Figure 2: Contents of the AIBORS Pet Grooming Kit.

FEATURES

- **12V High-Speed High-Power Motor:** Provides strong and stable power for efficient hair trimming without snagging or pulling. Designed for long use life with a plug-and-play cord.
- **Titanium Alloy Blade + Ceramic Detachable Blade:** Features a 35-tooth cutter head for sharpness, durability, and efficient cutting. The safe rounded design helps prevent harm to pet skin.
- **Low Vibration + Low Noise Design:** Operates at approximately 50 decibels to help keep pets calm during grooming.
- **Adjustable Blade Length:** Four levels of adjustable blade size (1.0mm, 1.3mm, 1.6mm, 1.9mm) without guard combs.
- **Four Guide Combs:** Includes 3mm, 6mm, 9mm, and 12mm guide combs for achieving desired hair lengths.

Sharp & Safe




Figure 3: Sharp and Safe Blade Design.

12V Powerful Motor

Stable & Low Noise
Professional Copper-Axis



Figure 4: 12V Powerful Motor.



Figure 5: Adjustable Blade and Guide Combs.

Fit for Different Animals



Figure 6: Suitable for various animals.

SETUP

1. Blade Disassembly and Installation

To disassemble the blade head, hold the clippers with one hand and use your thumb to push the blade down forcefully. Grasp the blade head with your other hand to prevent it from falling and becoming damaged. To install, align the chute of the blade head to the machine and press upward forcefully until you hear a click.

Your browser does not support the video tag.

Video 1: Demonstrates how to install and disassemble the clipper blade for cleaning or replacement.

2. Guide Comb Attachment

Select the desired guide comb (3mm, 6mm, 9mm, or 12mm). Align the guide comb to the machine and push it down until it securely clicks into place. Ensure there is no gap between the cutting head and the posting comb.

OPERATING INSTRUCTIONS

1. Powering On/Off

Connect the power cord to a suitable electrical outlet (AC 110V-240V 50/60Hz). Use the On/Off switch located on the clipper body to turn the device on or off.

2. Adjusting Blade Length

The clippers feature an adjustable blade with settings for 1.0mm, 1.3mm, 1.6mm, and 1.9mm. Use the adjustment lever on the side of the clipper to select the desired cutting length. For longer cuts, attach one of the provided guide combs.

3. Grooming Technique

Before grooming, ensure your pet's coat is clean, dry, and free of tangles. Brush the pet's hair to remove any loose fur. Hold the clippers firmly and move them against the direction of hair growth for an even cut. Use smooth, steady strokes. For sensitive areas, exercise extra caution.

Your browser does not support the video tag.

Video 2: Demonstrates the low noise and strong power of the clippers during pet grooming.

Your browser does not support the video tag.

Video 3: Shows the AIBORS heavy-duty corded dog clippers in action, highlighting ease of use.

MAINTENANCE

1. Cleaning the Blades

After each use, turn off and unplug the clippers. Disassemble the blade head as described in the Setup section. Use the provided cleaning brush to remove any trapped hair from the blades and the clipper body. For thorough cleaning, the blades can be rinsed under running water, but ensure the clipper body remains dry. Allow blades to dry completely before reattaching.

2. Oiling the Blades

Regular oiling of the blades is crucial for optimal performance and longevity. Apply a few drops of clipper oil (not included) to the blades before and after each use. Turn the clippers on for a few seconds to distribute the oil evenly.

TROUBLESHOOTING

- **Clippers not turning on:** Ensure the power cord is securely plugged into both the clippers and a working electrical outlet.
- **Blades pulling hair or cutting poorly:** The blades may be dull, dirty, or improperly oiled. Clean and oil the blades. If the issue persists, consider replacing the blade head.
- **Excessive heat:** Prolonged use can cause the blades to heat up. Turn off the clippers and allow them to cool. Ensure blades are clean and properly oiled.
- **Unusual noise or vibration:** Check if the blade head is correctly installed and secured. Ensure no foreign objects are lodged in the mechanism.

SPECIFICATIONS

Electric Working Voltage	12V
Adaptation Voltage	AC 110V-240V 50/60Hz
Motor Axis Material	Anti-wear brass
Blade Material	Titanium-ceramic Blade
Power Source	Corded Electric
Adjustable Blade Lengths	1.0mm, 1.3mm, 1.6mm, 1.9mm
Guide Comb Sizes	3mm, 6mm, 9mm, 12mm
Item Weight	1.39 pounds
Item Model Number	PT01

WARRANTY AND SUPPORT

AIBORS provides a **12-month warranty** for this product. If you encounter any concerns or issues, please do not hesitate to contact AIBORS customer support. We aim to reply within 24 hours.

For further assistance, please visit the AIBORS Store on Amazon.