

[Manuals.plus](#) /

› [Weehom](#) /

› Weehom Queen Size Metal Platform Bed Frame with Wooden Headboard - Instruction Manual

Weehom B09PTNDJ62

Weehom Queen Size Metal Platform Bed Frame with Wooden Headboard

Model: B09PTNDJ62 | **Brand:** Weehom

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Weehom Queen Size Metal Platform Bed Frame with Wooden Headboard. Please read all instructions carefully before assembly and retain this manual for future reference.

Safety Information

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble the bed frame on a soft, clean surface to prevent scratches.
- Do not fully tighten screws until all components are correctly aligned and in place.
- Keep children and pets away from the assembly area.
- The maximum weight capacity for this bed frame is 600 lbs. Do not exceed this limit.

2. SETUP AND ASSEMBLY

Assembly of this metal platform bed frame is designed to be straightforward. No additional tools are required as all necessary components are included. It is recommended to have two people for assembly.

Components Checklist

Please verify that all parts are included in your package before proceeding.



Figure 2.1: Key features and components of the bed frame, including the non-slip belt, lock design, and superior screws for secure assembly.

Assembly Steps

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a soft, clean surface. Identify each part using the provided diagram (if available).
2. **Assemble Side Rails:** Connect the side rails to the headboard and footboard sections. Ensure the wooden headboard panel is correctly oriented. Insert all bolts loosely at this stage.
3. **Install Center Support:** Attach the middle backbone support beam. This beam features a lock design for stability and can be removed for convenient moving.
4. **Place Slats:** Position the steel slats across the frame. Ensure they are evenly spaced and securely seated in their designated slots. The non-slip belt should be applied to prevent mattress movement.
5. **Final Tightening:** Once all parts are correctly aligned and in place, systematically tighten all screws and bolts using the provided tool. Ensure all connections are firm and secure.



Figure 2.2: Assembled bed frame with key dimensions indicated, showing the overall length, width, and height from the floor to the frame and headboard.



Figure 2.3: Close-up view of a leg and side rail connection, illustrating the secure fastening mechanism.

3. OPERATING INSTRUCTIONS

Mattress Placement

Place your Queen size mattress directly onto the steel slats. A box spring is not required for this platform bed frame. The integrated non-slip belt helps keep the mattress in place.

Under-Bed Storage

The bed frame provides 14 inches of clearance from the ground, offering ample space for under-bed storage. Utilize storage bins or containers to maximize this area.




Figure 3.1: Example of under-bed storage, showcasing the available clearance for bins and other items.

4. MAINTENANCE

Cleaning

- Wipe the metal and wooden surfaces with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Dry immediately with a clean cloth to prevent water spots.

Regular Inspection

- Periodically check all bolts and screws to ensure they remain tight. Re-tighten if necessary to maintain stability and prevent noise.
- Inspect the steel slats for any signs of damage or bending.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed frame is squeaky or unstable.	Loose bolts or connections.	Re-tighten all bolts and screws. Ensure all connections are firm.
Slats are popping out of place.	Incorrect installation or uneven weight distribution.	Ensure slats are fully seated in their holders. Verify the middle backbone is correctly installed. If issues persist, contact support.
Mattress slides on the frame.	Non-slip belt not properly applied or worn.	Ensure the non-slip belt is correctly positioned on the slats.

6. SPECIFICATIONS

- **Model:** B09PTNDJ62
- **Brand:** Weehom
- **Size:** Queen
- **Product Dimensions (L x W x H):** 82" x 62" x 14" (Frame height)
- **Headboard Height:** Approximately 38"
- **Under-Bed Clearance:** 14"
- **Weight Capacity:** 600 lbs
- **Item Weight:** 80.5 pounds
- **Material:** Steel, Wooden (Headboard)
- **Color:** Black Oak
- **Assembly Required:** Yes

7. WARRANTY AND SUPPORT

Warranty Information

Specific warranty details for your Weehom product may vary. Please refer to the documentation included with your purchase or contact Weehom customer support for precise warranty terms and conditions.

Customer Support

For any questions, missing parts, or assistance with assembly or troubleshooting, please contact Weehom customer support. You can often find contact information on the product packaging or by visiting the official Weehom store page:

[Visit the Weehom Store on Amazon](#)

© 2023 Weehom. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09PTNDJ62>

More documents and user manuals: **<https://manuals.plus/>**