

[Manuals.plus](#) /

› [KREAFUNK](#) /

› KREAFUNK aJAZZ Qi Wireless Portable Speaker User Manual

KREAFUNK aJAZZ Qi

KREAFUNK aJAZZ Qi Wireless Portable Speaker User Manual

Model: aJAZZ Qi

1. PRODUCT OVERVIEW

The KREAFUNK aJAZZ Qi is a stylish and functional wireless portable speaker designed to enhance your audio experience. It features Bluetooth 5.0 connectivity, Qi wireless charging capability, and IPX5 water resistance, making it suitable for various environments. Enjoy rich, clear sound and the convenience of True Wireless Stereo (TWS) pairing for an immersive audio setup.



Figure 1: KREAFUNK aJAZZ Qi Wireless Portable Speaker (Dusty Pink)

Key Features:

- **Bluetooth 5.0:** For stable and efficient wireless connection.
- **Qi Wireless Charging:** Conveniently charge your speaker without cables.
- **IPX5 Water Resistance:** Protected against splashes and light rain.
- **True Wireless Stereo (TWS):** Pair two aJAZZ Qi speakers for a stereo sound experience.
- **Extended Playback:** Up to 30 hours of music playback on a single charge.
- **USB Type-C Charging:** Modern and fast wired charging option.
- **Sustainable Design:** Grille fabric made from 98% recycled polyester by Gabriel.
- **Voice Assistant Support:** Integrate with your device's voice assistant.

2. SETUP GUIDE

2.1 Unboxing and Contents

Carefully remove the speaker and all accessories from the packaging. Ensure the following items are present:

- KREAFUNK aJAZZ Qi Wireless Portable Speaker

- USB Type-C Charging Cable
- User Manual (this document)

2.2 Charging the Speaker

Before first use, fully charge your aJAZZ Qi speaker.

- **USB Type-C Charging:** Connect the included USB Type-C cable to the speaker's charging port and a compatible USB power adapter (not included). Charging time is approximately 4-5 hours.
- **Qi Wireless Charging:** Place the speaker on a Qi-compatible wireless charging pad (not included). Ensure the speaker is centered on the pad for optimal charging. Charging time is approximately 6-8 hours.

The LED indicator on the speaker will show charging status (e.g., solid red for charging, off or green for fully charged, refer to specific LED behavior in the full manual if available).

2.3 Power On/Off

- **To Power On:** Press and hold the power button (usually marked with a 'K' or a power symbol) for a few seconds until you hear an audible cue or see the LED indicator light up.
- **To Power Off:** Press and hold the power button again for a few seconds until you hear an audible cue or the LED indicator turns off.

2.4 Bluetooth Pairing

To connect your aJAZZ Qi speaker to a device:

1. Ensure the speaker is powered on and in pairing mode. The LED indicator will typically flash blue rapidly.
2. On your device (smartphone, tablet, computer), go to Bluetooth settings and enable Bluetooth.
3. Search for available devices. The speaker should appear as "aJAZZ Qi" or a similar name.
4. Select "aJAZZ Qi" from the list to connect. Once connected, the LED indicator will usually turn solid blue, and you may hear a confirmation sound.

The speaker is compatible with iOS, Android, Mac OS, Windows, and Linux devices.



Figure 2: KREAFUNK aJAZZ Qi speaker in a home office setting.

3. OPERATING INSTRUCTIONS

3.1 Basic Controls

The aJAZZ Qi speaker features intuitive controls for media playback and calls:

- **Play/Pause:** Press the main function button (often the 'K' button) once to play or pause music.
- **Volume Up/Down:** Use the volume buttons (if present, or long-press the main button for some models) to adjust the volume. Alternatively, control volume directly from your connected device.
- **Next/Previous Track:** Double-press or triple-press the main function button for next or previous track, respectively (refer to specific model instructions for exact button functions).
- **Answer/End Call:** Press the main function button once to answer an incoming call or end an ongoing call.
- **Reject Call:** Press and hold the main function button to reject an incoming call.
- **Activate Voice Assistant:** Press and hold the main function button (or a dedicated button if available) to activate your device's voice assistant.

3.2 True Wireless Stereo (TWS) Pairing

To achieve a wider soundstage, you can pair two KREAFUNK aJAZZ Qi speakers together for True Wireless Stereo (TWS) playback:

1. Ensure both aJAZZ Qi speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be your primary speaker), press and hold the TWS pairing button (or a combination of buttons, refer to specific model instructions) until you hear a pairing tone or see a specific LED pattern (e.g., flashing white).
3. The second speaker will automatically search for the primary speaker and connect. Once connected, you will hear a confirmation sound, and the LED indicators on both speakers will change (e.g., primary speaker flashes blue, secondary speaker shows solid white).

4. Now, connect your device to the primary speaker via Bluetooth as described in Section 2.4. Both speakers will play audio in stereo.



Figure 3: Two aJAZZ Qi speakers ready for TWS pairing.

4. MAINTENANCE

4.1 Cleaning

To maintain the appearance and functionality of your speaker:

- Wipe the exterior with a soft, damp cloth.
- Do not use harsh chemicals, abrasive cleaners, or solvents.
- The speaker is IPX5 water-resistant, meaning it can withstand splashes. Do not submerge it in water.

4.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery to about 50% before storing to prolong battery life.

5. TROUBLESHOOTING

If you encounter issues with your KREAFUNK aJAZZ Qi speaker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker using the USB-C cable or a Qi wireless charger.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device Bluetooth off; speaker already connected to another device.	Ensure speaker is in pairing mode (flashing blue LED). Turn off and on your device's Bluetooth. Disconnect from other devices.

Problem	Possible Cause	Solution
No sound or low volume.	Volume too low on speaker or device; speaker not connected.	Increase volume on both speaker and device. Re-establish Bluetooth connection.
TWS pairing fails.	Incorrect pairing procedure; speakers already connected to other devices; different model versions.	Ensure both speakers are disconnected from all devices before initiating TWS pairing. Follow TWS pairing steps carefully. Verify both speakers are indeed 'aJAZZ Qi' models.
Charging is slow or not working.	Faulty cable/adapter; improper placement on Qi pad.	Try a different USB-C cable and power adapter. For Qi charging, ensure the speaker is correctly centered on the charging pad.

6. SPECIFICATIONS

Feature	Detail
Brand	KREAFUNK
Model Name	aJAZZ Qi
Model Number	18658
Connectivity Technology	Bluetooth 5.0
Audio Output Mode	Stereo (with TWS)
Speaker Output	6W Digital Amplifier (25W Max Output)
Water Resistance	IPX5 (Water Resistant)
Wireless Charging	Qi Compatible
Grille Fabric	Gabriel 98% Recycled Polyester
Playback Time	Up to 30 hours (initial setting)
Charging Time (USB-C)	Approx. 4-5 hours
Charging Time (Wireless)	Approx. 6-8 hours
Dimensions (D x W x H)	10.2 cm x 10.2 cm x 11 cm
Weight	400 g (0.88 lbs)
Compatible Devices	Smartphones, Tablets (iOS, Android, Mac OS, Windows, Linux)
Included Components	Charging cable
Battery Type	1 Lithium Ion Battery

Feature	Detail
---------	--------

GTIN	05713680601089
------	----------------

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The KREAFUNK aJAZZ Qi Wireless Portable Speaker comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

7.2 Customer Support

If you have any questions, require technical assistance, or need to make a warranty claim, please contact your retailer or the official KREAFUNK customer support. Contact details can typically be found on the KREAFUNK website or your purchase documentation.