

Outsunny 84B-637

Outsunny HDPE Adirondack Chair Instruction Manual

Model: 84B-637 | Brand: Outsunny

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Outsunny HDPE Adirondack Chair, Model 84B-637. Designed for outdoor use, this weather-resistant chair offers a comfortable seating solution for various environments such as patios, gardens, backyards, and lawns.



Image 1.1: The Outsunny HDPE Adirondack Chair in Turquoise.

The chair is constructed from High-Density Polyethylene (HDPE), a durable material known for its resistance to weather elements, splintering, cracking, chipping, and peeling. Its design features a waterfall seat, wide armrests, and a high-angled back for enhanced comfort.

Your browser does not support the video tag.

Video 1.1: This video demonstrates the Outsunny Adirondack Chair in various social settings, highlighting its comfort and suitability for outdoor gatherings. It shows people relaxing, conversing, playing games, and enjoying music while seated in the chairs.

2. SAFETY INFORMATION

- Do not exceed the maximum weight capacity of 330 lbs (150 kg).
- Ensure all bolts and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Place the chair on a stable, level surface to prevent tipping.
- Keep small children and pets away during assembly.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. Refer to the parts list included in your product packaging for a detailed inventory. If any parts are missing or damaged, contact customer support.

4. ASSEMBLY INSTRUCTIONS

The Outsunny Adirondack Chair is designed for straightforward assembly with pre-drilled boards. While assembly is generally simple, careful attention to the instructions is recommended.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Identify each component using the provided parts list.
2. **Review Instructions:** Read through the entire assembly guide provided in your product box before starting. Pay close attention to diagrams and step sequences.
3. **Initial Assembly:** Begin by attaching the main structural components as indicated in the manual. Ensure bolts are finger-tightened initially to allow for adjustments.
4. **Secure Connections:** Once all parts are aligned and in place, fully tighten all bolts using the appropriate tools. Avoid over-tightening to prevent damage.
5. **Final Check:** After assembly, gently rock the chair to ensure stability. Re-tighten any loose connections.

SIMPLE AND COMFORTABLE

Embrace the nature and enjoy the sunshine



Image 4.1: Dimensional diagram of the Adirondack Chair, useful for identifying parts during assembly.




Image 4.2: Detailed views of key chair features, aiding in correct component orientation.

5. OPERATING INSTRUCTIONS

Your Outsunny HDPE Adirondack Chair is designed for comfortable outdoor relaxation. Simply sit back and enjoy its ergonomic features.

- **Comfortable Seating:** The chair features a waterfall seat, wide armrests, and a high-angled back, providing a comfortable and supportive lounging experience.
- **Versatile Placement:** Suitable for various outdoor settings including decks, poolside areas, porches, and lawns.



Image 5.1: The Adirondack chair providing comfortable seating in an outdoor setting.

FITS FOR ALL OUTDOOR SPACE




Image 5.2: Examples of the Adirondack chair's versatility in different outdoor environments.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your Outsunny HDPE Adirondack Chair, follow these simple maintenance guidelines:


- **Cleaning:** The chair features a wipe-clean surface. Use mild soap and water with a soft cloth or sponge to clean the chair. Rinse thoroughly with clean water and allow to air dry. Avoid abrasive cleaners or harsh chemicals.
- **Material Benefits:** The HDPE material is designed to be waterproof and resistant to common outdoor wear, including splintering, cracking, chipping, and peeling. The hardware is anti-rust for extended outdoor use.
- **Seasonal Storage:** While weather-resistant, storing the chair in a covered area during extreme weather conditions or off-season can further extend its lifespan.

ALL WEATHER MATERIAL

Protect your lovely lounge chair from all kinds of weathers



High Density Polyethylene



Anti-rust Hardware



Image 6.1: Features of the all-weather HDPE material and anti-rust hardware.

7. TROUBLESHOOTING

- **Wobbly Chair:** If the chair feels unstable after assembly, ensure all bolts are fully tightened. Sometimes, loosening all bolts slightly, placing the chair on a level surface, and then re-tightening them in sequence can resolve wobbling.
- **Difficulty with Assembly:** If you encounter difficulties during assembly, double-check the instruction diagrams and ensure you are using the correct parts for each step. Some users have found it helpful to reverse the order of certain bolt insertions (e.g., inserting from the inside out) for better alignment.
- **Missing Parts:** If any parts are missing from the package, refer to the contact information in the 'Warranty & Support' section to request replacements.

8. SPECIFICATIONS

Brand	Outsunny
Model Name	84B-637

Color	Turquoise
Material	High Density Polyethylene (HDPE)
Product Dimensions (D x W x H)	33" x 26.75" x 35.5"
Seat Height	14.25 Inches
Seat Depth	17.75 inches
Seat Length	19.75 Inches
Arm Height	21.25 Inches
Maximum Weight Recommendation	330 Pounds (150 kg)
Item Weight	30.8 pounds
Indoor/Outdoor Usage	Outdoor

9. WARRANTY & SUPPORT

For warranty information, product support, or to order replacement parts, please refer to the contact details provided with your purchase documentation or visit the official Outsunny website. Keep your purchase receipt for warranty claims.