

[Manuals.plus](#) /

› [ATHLERIA](#) /

› ATHLERIA Magic Flying Orb Ball User Manual

ATHLERIA ATHLERIA

ATHLERIA Magic Flying Orb Ball User Manual

Model: ATHLERIA

INTRODUCTION

The ATHLERIA Magic Flying Orb Ball is a hand-controlled mini drone designed for interactive play. It features vibrant RGB lights and various flight patterns, including boomerang and straight flight, controlled by different throwing angles and speeds. This manual provides essential information for safe and enjoyable use of your flying orb ball.

WHAT'S IN THE BOX

- Flying ball
- USB cable
- User Manual

SAFETY INFORMATION

- Do not fly close to animals or faces.
- Keep your face, ears, and hair away from the Flying Ball.
- Do not put your finger inside the Flying Ball when it is operating.
- This product contains a non-replaceable battery. Do not disassemble it or allow the battery to get damp.
- If the flying ball toy becomes seriously heated, do not charge it. Allow it to cool before charging.
- Do not charge in an extremely hot or cold environment.
- Never charge the product unattended for an extended period.
- Toys should not be used by children under 6 years old.

SETUP

Charging the Flying Orb Ball

The flying orb ball has a built-in rechargeable battery. Use the provided USB cable to connect the orb ball to a power source (e.g., USB wall adapter, computer USB port, power bank). Charging typically takes approximately 20 minutes for 15-20 minutes of playtime.



Image: The flying orb ball charging via a USB cable connected to a power bank. This image illustrates the quick and convenient USB charging method.

Initial Power On

1. Press the on/off button located on the orb ball to turn it on.
2. Gently shake the orb ball to initiate the spinning and light effects. Shake it again to stop the operation.

EASY TO USE



1

Press the on/off button to turn on.



2

Shake the ball to start/stop rotating.



3

Fly back like a boomerang.



4

Fly to the target.

Image: A four-panel diagram illustrating how to turn on the orb ball, shake it to start/stop, and throw it at different angles for boomerang or straight flight effects.

OPERATING INSTRUCTIONS

Basic Flight and Control

The Magic Flying Orb Ball is hand-controlled and responds to different throwing angles and speeds. It can light up, spin, float, glide, and climb through the air.

- **Boomerang Effect:** When you toss the flying toy upwards at approximately a 30-degree angle, it will spin around its axis perpendicular to the direction of flight and return to your hand.
- **Straight Flight:** To achieve straight flight, turn the orb ball downwards at approximately a 30-degree angle and toss it under a horizontal direction.



Image: Two children playing with the flying orb ball, highlighting its ease of use and suitability for children.

Indoor and Outdoor Play

The orb ball is suitable for both indoor and outdoor use. Its built-in RGB lights make it particularly engaging to play with at night, creating a neon shooting star effect. The flexible spherical cage protects the internal components and prevents damage to the toy or surroundings.

COLORFUL RGB LED LIGHTS

Glow in the dark, cool toy to play for activity specially night time.



Image: A hand holding the flying orb ball, showcasing its vibrant and colorful RGB LED lights in a dark setting.



Image: A family enjoying the flying orb ball outdoors, demonstrating its suitability for both day and night play.

Using with a Magic Wand (Sold Separately)

For more precise control and advanced maneuvers, the flying orb ball can be operated with a magic wand (not included, sold separately).

Your browser does not support the video tag.

Video: Demonstrates the flying orb ball being controlled with a magic wand, showcasing enhanced precision and various tricks.

Demonstration Videos

Your browser does not support the video tag.

Video: A short clip showcasing the dynamic light display of the flying orb ball in action.

Your browser does not support the video tag.

Video: An overview of the FlyNova Pro, demonstrating various flight patterns and features.

Your browser does not support the video tag.

Video: Highlights various ways to play with the flying orb ball, suitable for different ages and settings.

MAINTENANCE

Battery Care

To ensure the longevity and safe operation of your flying orb ball's battery:

- Avoid disassembling the product or exposing the battery to moisture.
- If the orb ball becomes excessively hot during use, allow it to cool down completely before attempting to recharge.
- Charge the device in a moderate temperature environment, avoiding extreme heat or cold.
- Do not leave the product charging unattended for extended periods.

Automatic Stop Feature

The flying orb ball is designed with a safety feature that automatically stops its operation upon impact with furniture or other objects. This helps prevent damage to the toy and its surroundings. If the orb ball stops unexpectedly, check for obstructions or impacts, then restart it by shaking it gently.



Image: The flying orb ball demonstrating its durability by bouncing off various surfaces without damage.

SPECIFICATIONS

Product Dimensions	3.7 x 3.7 x 3.7 inches
Item Weight	5.9 ounces
Item Model Number	ATHLERIA
Manufacturer Recommended Age	6 years and up
Batteries	1 Product Specific battery required (included)
Manufacturer	ATHLERIA

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question