

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [Perixx](#) /
- › Perixx PERIBOARD-332 Wired Backlit USB Keyboard User Manual

Perixx PERIBOARD-332

Perixx PERIBOARD-332 Wired Backlit USB Keyboard User Manual

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Perixx PERIBOARD-332 Wired Backlit USB Keyboard. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

SCULPTED KEYS

FEEL LIKE LAPTOP KEYBOARDS



Image: The Perixx PERIBOARD-332 Wired Backlit USB Keyboard, showcasing its compact design.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Perixx PERIBOARD-332 Wired Backlit USB Keyboard
- Integrated USB Cable
- User Manual (this document)



Image: The Perixx PERIBOARD-332 keyboard, its integrated USB cable, the user manual, and the product packaging.

SETUP INSTRUCTIONS

1. **Connect the Keyboard:** Locate an available USB port on your computer (PC, laptop, tablet, or smartphone with appropriate adapter). Insert the USB cable from the PERIBOARD-332 into the USB port.
2. **Driver Installation:** The keyboard is plug-and-play and typically does not require additional drivers for basic functionality on Windows, macOS, Linux, or Chrome OS. Your operating system should automatically detect and configure the device.
3. **Placement:** Place the keyboard on a stable, flat surface. The compact design is ideal for small workspaces.

EFFORTLESS AND QUIET TYPING



Image: A user typing on the Perixx PERIBOARD-332 keyboard, demonstrating its compact size and wired connection on a desk.

OPERATING INSTRUCTIONS

General Use

The Perixx PERIBOARD-332 features a standard US English QWERTY layout with 84 keys. Its low-profile scissor keys provide a quiet and comfortable typing experience, similar to laptop keyboards. The compact design helps optimize desk space.

MINI AND MODERN



Image: A user typing on the Perixx PERIBOARD-332 keyboard, highlighting its compact size and ergonomic placement in a workspace.



Image: Close-up view of the sculpted, low-profile scissor keys of the Perixx PERIBOARD-332, highlighting their design.

Function Keys (Fn Hotkeys)

The keyboard includes integrated Fn hotkeys for quick access to multimedia and system functions. These functions are primarily designed for Windows operating systems. For other operating systems (macOS, Linux, Chrome OS), their functionality may vary or require specific system settings/configurations.

- **Fn + F1:** Fn Lock
- **Fn + F2:** Backlight Brightness Adjustment (Cycle through levels)
- **Fn + F3:** Mute
- **Fn + F4:** Volume Down
- **Fn + F5:** Volume Up
- **Fn + F6:** Previous Track
- **Fn + F7:** Play/Pause
- **Fn + F8:** Next Track
- **Fn + F9:** Pause
- **Fn + F10:** Scroll Lock
- **Fn + F11:** Insert
- **Fn + F12:** Print Screen

INTEGRATED FN HOTKEYS



Image: Diagram illustrating the integrated Fn hotkeys on the Perixx PERIBOARD-332, showing the function of each F-key when pressed with the Fn key.

Backlight Control

The PERIBOARD-332 features white LED backlighting with adjustable brightness. To adjust the backlight brightness, press the **Fn + F2** keys simultaneously. Repeatedly pressing this combination will cycle through different brightness levels (including off).

WHITE BACKLIGHTING



Image: Top-down view of the Perixx PERIBOARD-332 keyboard with its white LED backlighting illuminated, showcasing the clear, large font on the keys.

MAINTENANCE

To ensure the longevity and proper functioning of your keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the keyboard. Avoid excessive moisture. Do not spray cleaners directly onto the keyboard.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keys.
- **Avoid Spills:** Keep liquids away from the keyboard to prevent damage. The keyboard is not water-resistant.
- **Storage:** When not in use, store the keyboard in a clean, dry environment away from extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Perixx PERIBOARD-332, refer to the following common solutions:

Keyboard Not Responding

- **Check USB Connection:** Ensure the USB cable is securely plugged into both the keyboard and the computer's USB port. Try a different USB port.
- **Restart Computer:** Sometimes, a simple computer restart can resolve connectivity issues.
- **Test on Another Device:** Connect the keyboard to another computer or device to determine if the issue is with the keyboard or the original computer.

Backlight Not Working or Adjusting

- **Check Brightness Setting:** Press **Fn + F2** repeatedly to cycle through all brightness levels, including off. Ensure it's not set to the lowest or off setting.
- **Power Source:** Ensure the keyboard is properly connected to a powered USB port.

Keys Not Functioning Correctly

- **Clean Keys:** Check for any debris or obstructions under the affected keys. Use compressed air to clear them.
- **Software Conflicts:** If specific keys are not working, check for any software or driver conflicts on your computer.

Multimedia Keys Not Working on macOS/Linux/Chrome OS

- **Operating System Compatibility:** The multimedia shortcut keys are primarily designed for Windows. On other operating systems, their functionality may vary or require specific system settings/configurations.

SPECIFICATIONS

Feature	Detail
Brand	Perixx
Model Number	PERIBOARD-332
Connectivity Technology	USB (Wired)
Keyboard Description	US English QWERTY
Special Feature	Backlit (White LED)
Switch Type	Scissor Switches
Number of Keys	84
Product Dimensions (L x W x H)	11.22" x 4.57" x 0.83" (28.5 cm x 11.6 cm x 2.1 cm)
Item Weight	0.79 lbs (12.3 Ounces / 350 grams approx.)
Compatible Devices	PC, Laptop, Tablet, Smartphone (with compatible USB port/adapter)
Operating System Compatibility	Windows 7, 8, 10, 11; macOS; Linux; Chrome OS
Material	Plastic

WARRANTY AND SUPPORT

Warranty Information

Your Perixx PERIBOARD-332 keyboard comes with a **12-month limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external factors.

Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, warranty claims, or any questions regarding your Perixx product, please visit the official Perixx website or contact their customer support team. Contact information can typically be found on the Perixx website or in the product packaging.

You can also visit the [Perixx Store on Amazon](#) for more information and support resources.