

[Manuals.plus](#) /

› [ROMP](#) /

› ROMP Pleasure Kit User Manual

## ROMP Pleasure Kit

# ROMP Pleasure Kit User Manual

Your guide to the ROMP Free, ROMP Flip, and ROMP Juke devices.

## 1. INTRODUCTION

---

The ROMP Pleasure Kit is a comprehensive set designed for diverse pleasure experiences. It includes three distinct devices: the ROMP Free clitoral suction toy, the ROMP Flip wand massager, and the ROMP Juke cock ring. All devices are crafted from body-safe silicone, are rechargeable, and waterproof for versatile use and easy cleaning.

## 2. WHAT'S INCLUDED

---

Your ROMP Pleasure Kit contains the following items:

- 1 x ROMP Free Clitoral Suction Toy
- 1 x ROMP Flip Wand Massager
- 1 x ROMP Juke Cock Ring
- 2 x USB Charging Cables (one for ROMP Free/Juke, one for ROMP Flip)
- 1 x Travel Storage Bag
- User Manual



Image: The ROMP Pleasure Kit contents, including the three devices and charging cables, neatly organized within the provided travel bag.

### 3. SETUP AND CHARGING

---

Before first use, fully charge all devices. Each device has a magnetic charging port or a small pinhole port. Use the provided USB charging cables.

#### 3.1 ROMP Free (Clitoral Suction Toy)

- To charge, gently pull apart the two halves of the ROMP Free to reveal the charging port.
- Insert the smaller magnetic charging cable into the port.
- Connect the USB end to a power source. The indicator light will blink while charging and become solid when fully charged.



Image: The ROMP Free clitoral suction toy, shown in hand, highlighting its compact design.

### 3.2 ROMP Juke (Cock Ring)

- Locate the small pinhole charging port on the ROMP Juke.
- Insert the small pin of the magnetic charging cable into the port.
- Connect the USB end to a power source. The indicator light will blink while charging and become solid when fully charged.



Image: The ROMP Juke cock ring, held in hand, showcasing its ergonomic shape.

### 3.3 ROMP Flip (Wand Massager)

- Locate the small pinhole charging port on the ROMP Flip, usually near the base.
- Insert the small pin of the dedicated charging cable into the port.

- Connect the USB end to a power source. The indicator light will blink while charging and become solid when fully charged.



Image: The ROMP Flip wand massager, held in hand, demonstrating its flexible head.

Your browser does not support the video tag.

Video: This official ROMP product video demonstrates the unboxing, charging, and basic operation of the ROMP Pleasure Kit devices.

## 4. OPERATING INSTRUCTIONS

---

Each device in the ROMP Pleasure Kit offers multiple intensity levels and patterns for a personalized experience.

### 4.1 ROMP Free

- **Power On/Off:** Press and hold the power button for 2 seconds.
- **Change Modes:** Press the power button repeatedly to cycle through the various Pleasure Air Technology patterns.
- **Intensity:** The ROMP Free features multiple intensity levels within each pattern.



Image: Usage diagram for the ROMP Free, showing application to different areas.

### 4.2 ROMP Juke

- **Power On/Off:** Press and hold the power button for 2 seconds.
- **Change Modes:** Press the power button repeatedly to cycle through the vibration patterns.
- **Application:** Designed to be worn at the base of the penis for enhanced sensation.




Image: Usage diagram for the ROMP Juke, demonstrating proper placement.

### 4.3 ROMP Flip

- **Power On/Off:** Press and hold the power button (usually the lower button) for 2 seconds.
- **Change Modes:** Press the mode button (usually the upper button) repeatedly to cycle through the vibration patterns.
- **Intensity:** Use the power button to adjust vibration intensity.



Image: Usage diagram for the ROMP Flip, showing different application techniques.

## 5. CLEANING AND MAINTENANCE

All ROMP devices are **100% waterproof (IPX7 rated)**, making them easy to clean and suitable for use in the bath or shower.



Image: All three ROMP devices shown submerged in water, illustrating their waterproof capability.

- Clean your devices thoroughly before and after each use with warm water and a mild soap or a specialized toy cleaner.
- Rinse thoroughly and pat dry with a lint-free cloth.
- Avoid using cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.
- Store devices in the provided travel bag in a cool, dry place, away from direct sunlight and extreme temperatures.

## 6. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Connect it to the charger and check if the indicator light blinks. If it does not, try a different USB port or charging cable.
- **Weak vibrations or short battery life:** The device may need a full charge. Battery performance can decrease over time with repeated charging cycles.
- **Buttons unresponsive:** Ensure the device is not locked (if applicable, refer to specific device instructions for lock functions). Try turning the device off and on again.

- **Water leakage:** While devices are waterproof, ensure charging ports are completely dry before charging. If you suspect water ingress, discontinue use and contact customer support.

If you experience persistent issues, please refer to the Warranty and Support section for contact information.

## 7. SPECIFICATIONS

|                    |                                                 |
|--------------------|-------------------------------------------------|
| Product Dimensions | 9.84 x 5.51 x 2.17 inches (overall kit)         |
| Weight             | 4.94 ounces (overall kit)                       |
| Material           | Body-safe Silicone                              |
| Battery Type       | Lithium Ion (1 required per device)             |
| Charging           | USB Rechargeable                                |
| Waterproof Rating  | IPX7 (Submersible up to 1 meter for 30 minutes) |




Image: Detailed line drawings indicating the dimensions of the ROMP Free, ROMP Flip, and ROMP Juke devices.

## 8. WARRANTY AND SUPPORT

ROMP offers a **2-year warranty** on all its products, including the devices in this Pleasure Kit. This warranty covers manufacturing defects and ensures your product functions as intended.

For warranty claims, technical support, or any questions regarding your ROMP Pleasure Kit, please contact ROMP customer service through the official ROMP website or your retailer's support channels. Please have your proof of purchase ready.

## 9. SAFETY INFORMATION

- This product is intended for adult use only.
- Discontinue use immediately if you experience any discomfort or pain.
- Consult a healthcare professional if you have any pre-existing medical conditions or concerns.
- Keep out of reach of children.
- Do not use if the product appears damaged or compromised.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. (*Note: This is a general disclaimer provided by the manufacturer.*)

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

