

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Umbra](#) /
- › [Umbra Exhibit 9-Opening Picture Frame Gallery Set Instruction Manual](#)

## Umbra 1018092-040

# Umbra Exhibit 9-Opening Picture Frame Gallery Set Instruction Manual

Brand: Umbra | Model: 1018092-040


[Installation](#) [Operation](#) [Maintenance](#) [Overview](#) [Setup &](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

## 1. PRODUCT OVERVIEW

The Umbra Exhibit Photo Display is a wall-mounted gallery set designed to showcase nine pictures. It features a brushed metal ledge with clips and brackets, allowing for flexible arrangement of frames. The design minimizes wall damage, requiring only a few screw holes for installation. Frames can be moved along the ledge and rotated for either landscape or portrait orientation. This set includes four 5x7 inch (13x18 cm) frames and five 8x10 inch (20x25 cm) frames. Its adaptable design makes it suitable for various spaces, including stairways, living rooms, bedrooms, entryways, offices, or studios.



*Image 1.1: The Umbra Exhibit 9-Opening Picture Frame Gallery Set installed on a wall, showcasing a dynamic photo arrangement.*



umbra

Image 1.2: Overall dimensions of the Umbra Exhibit 9-Opening Picture Frame Gallery Set.


## 2. SETUP AND INSTALLATION

The Exhibit Photo Display is designed for straightforward installation with minimal wall damage. Follow these steps to set up your gallery set:

### 2.1 Unpacking and Components

Carefully unpack all components from the box. Ensure all parts are present:

- 1x Metal Ledge/Rail
- 4x 5x7 inch (13x18 cm) Picture Frames
- 5x 8x10 inch (20x25 cm) Picture Frames
- Mounting Hardware (screws, wall anchors)




Dual  
Orientation



5x7" Frames  
(13x18 cm)



8x10" Frames  
(20x25 cm)



## Multi-Photo Wall Display

Display your favorite images in an eye-catching gallery-style frame suspended from a single rail.

Image 2.1: Components of the Umbra Exhibit 9-Opening Picture Frame Gallery Set.

## 2.2 Mounting the Metal Ledge

1. **Choose Location:** Select a desired location on your wall. The ledge can be mounted horizontally or at an angle, such as along a staircase.
2. **Mark Drill Points:** Hold the metal ledge against the wall at the desired height and position. Use a pencil to mark the two screw holes at each end of the ledge.
3. **Drill Holes:** Using a drill, create pilot holes at the marked points. If drilling into drywall, insert the provided wall anchors.
4. **Secure Ledge:** Align the ledge with the drilled holes and secure it to the wall using the provided screws. Ensure the ledge is firmly attached.



*Image 2.2: Steps for mounting the metal ledge to the wall.*

This system requires only two screw holes, minimizing damage to your wall compared to hanging multiple individual frames.



*Image 2.3: Minimal wall damage with the Exhibit system.*

### **2.3 Attaching and Arranging Frames**

1. **Insert Photos:** Open the back of each frame and insert your desired photos or artwork. Close the frame securely.
2. **Hang Frames:** The frames are suspended from the metal ledge using hanging rods. Each rod has a hook that slides into the grooves on the back of the metal ledge.
3. **Customize Layout:** The unique hanging bracket design allows you to easily adjust the position of each frame along the ledge. You can slide them left or right to create your desired arrangement.
4. **Adjust Orientation:** Each frame can be rotated 90 degrees to switch between portrait and landscape orientations as desired.



*Image 2.4: Customizable display by sliding frames along the rail.*



*Image 2.5: Frames support dual orientation (portrait or landscape).*

## 2.4 Installation Video

Your browser does not support the video tag.

*Video 2.1: Official Umbra Exhibit Video demonstrating product features and installation.*

## 3. OPERATION

The Umbra Exhibit Photo Display offers flexibility in showcasing your photos and artwork.

- **Changing Photos:** To change a photo, simply unhook the frame from the hanging rod, open the back, replace the image, and re-hang.
- **Adjusting Layout:** Frames can be slid horizontally along the metal ledge to create new arrangements. The hanging rods can also be interchanged to vary the vertical spacing and overall configuration.

- **Orientation:** Each frame can be rotated 90 degrees to switch between portrait and landscape orientations as desired.

## 4. MAINTENANCE

To ensure the longevity and appearance of your Umbra Exhibit Photo Display, follow these maintenance guidelines:

- **Cleaning Frames:** Use a soft, lint-free cloth to gently wipe dust from the frames and glass. For smudges on the glass, a mild glass cleaner can be applied to the cloth (not directly to the frame) and then wiped clean.
- **Cleaning Metal Ledge:** Wipe the metal ledge with a dry or slightly damp soft cloth. Avoid abrasive cleaners or materials that could scratch the brushed finish.
- **Handling:** When changing photos or adjusting frames, handle them carefully to prevent accidental drops or damage to the glass.

## 5. TROUBLESHOOTING

Here are solutions to common issues you might encounter with your Exhibit Photo Display:

- **Frames are not straight:** Ensure the metal ledge is installed perfectly level. If the ledge is level, adjust individual frames by gently nudging them until they hang straight. For photos inside the frame, use a small piece of double-sided tape on the back of the photo to secure it to the back panel or the glass, preventing it from shifting.
- **Frames feel unsecured/swing:** The design allows frames to move for customization. If excessive movement is a concern, ensure the hanging rods are fully seated in the ledge's grooves. For high-traffic areas, consider placing the display out of direct contact to prevent accidental bumps.
- **Broken glass:** If a glass pane breaks, carefully remove all broken pieces. Contact Umbra customer support for replacement options.
- **Difficulty inserting photos:** Ensure the photo size matches the frame size (5x7 or 8x10 inches). If the photo is slightly too large, trim it carefully.

## 6. SPECIFICATIONS

<b>Brand</b>	Umbra
<b>Model Number</b>	1018092-040
<b>Color</b>	Black
<b>Product Dimensions</b>	87 7/8" W x 30 1/2" H (223 cm x 77 cm)
<b>Frame Material</b>	Metal
<b>Finish Type</b>	Brushed

<b>Mounting Type</b>	Wall Mount
<b>Number of Frames</b>	9 (Four 5x7", Five 8x10")
<b>Item Weight</b>	15.18 pounds (6.9 Kilograms)
<b>Included Components</b>	Umbra Exhibit Set of 9 Frames, Mounting Hardware
<b>Assembly Required</b>	No (minimal installation)

## 7. WARRANTY AND SUPPORT

### 7.1 Warranty Information

The Umbra Exhibit Picture Frame Gallery Set comes with a **5-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

### 7.2 Customer Support

For further assistance, questions, or to report any issues, please contact Umbra customer support through their official website or the retailer where the product was purchased. Have your model number (1018092-040) and proof of purchase ready.