

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 24V AC/DC Adapter User Manual

UPBRIGHT Lifepro AcuCare Tilt VibraCare Power

UpBright 24V AC/DC Adapter User Manual

Model: Lifepro AcuCare Tilt VibraCare Power

Brand: UPBRIGHT

PRODUCT OVERVIEW

This UpBright New Global 24V AC/DC Adapter is designed for compatibility with Lifepro AcuCare Tilt VibraCare LP-VBRCAR-BLU LPVBRCARBLU Heated Electric Foot Massager Machine. It provides a stable 24V DC power supply, ensuring reliable operation for your device.

Key features include:

- World Wide Input Voltage: 100-240VAC 50/60Hz, making it suitable for global use.
- Comprehensive Protection: Equipped with OVP (Over Voltage output Protection), OCP (Over Current output Protection), and SCP (Short Circuit output Protection) to safeguard your devices.
- Tested and Certified: Units are tested and confirmed to be in great working condition, meeting CECCCROHS standards.



Image: The UpBright 24V AC/DC Adapter, showing the main power brick, DC output barrel connector, and AC input cable.

SETUP INSTRUCTIONS

1. **Unpack the Adapter:** Carefully remove the AC/DC adapter and all included cables from its packaging.
2. **Identify Components:** Locate the main adapter unit, the DC output cable with the barrel connector, and the AC input power cord.
3. **Connect AC Power Cord:** Insert the AC input power cord into the designated port on the adapter unit. Ensure it is firmly seated.
4. **Connect to Device:** Plug the barrel connector of the DC output cable into the power input port of your Lifepro AcuCare Tilt VibraCare Foot Massager Machine. Ensure the connection is secure.
5. **Connect to Wall Outlet:** Plug the AC input power cord into a standard wall electrical outlet (100-240VAC, 50/60Hz).



Image: A top-down view of the UpBright AC/DC adapter, showing the main unit, the DC output cable with its barrel connector, and the detachable AC input power cord.

OPERATING INSTRUCTIONS

Once the UpBright AC/DC Adapter is correctly connected to your Lifepro AcuCare Tilt VibraCare Foot Massager Machine and a power outlet, it will supply the necessary 24V DC power to operate your device.

- The adapter provides continuous power to your compatible device.
- Ensure the adapter is placed in a well-ventilated area to prevent overheating.
- Always use the adapter with compatible devices that require 24V DC input. Refer to your device's specifications for power requirements.

UpBright AC Adapter Power Supply Compatible with:



(Machine not Included)

Image: The UpBright AC Adapter shown alongside a Lifepro AcuCare Foot Massager and a Lifepro VibraCare vibration plate, illustrating the compatibility of the adapter with these devices. Note: Machines are not included with the adapter.

MAINTENANCE

To ensure the longevity and optimal performance of your UpBright AC/DC Adapter, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and moisture. Avoid tightly coiling the cables to prevent damage.
- **Cable Care:** Regularly inspect the cables for any signs of fraying, cuts, or damage. Do not use the adapter if the cables are damaged.
- **Ventilation:** Ensure the adapter is placed in an area with adequate airflow to prevent overheating during operation. Do not cover the adapter.

TROUBLESHOOTING

If you encounter issues with your UpBright AC/DC Adapter, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No power to device	◦ Adapter not plugged in ◦ Loose connection ◦ Faulty wall outlet ◦ Device issue ◦ Damaged adapter/cable	◦ Ensure adapter is fully plugged into wall outlet. ◦ Check all connections (AC cord to adapter, DC connector to device) are secure. ◦ Test the wall outlet with another working appliance. ◦ Verify your device is functioning correctly with its original power supply (if available). ◦ Inspect adapter and cables for visible damage. If damaged, discontinue use.
Adapter feels hot	◦ Normal operation (slight warmth) ◦ Poor ventilation ◦ Overload or short circuit	◦ A slight warmth is normal. ◦ Ensure adapter is in a well-ventilated area, not covered. ◦ Disconnect immediately if excessively hot or emitting smoke/smell. Contact support.

SPECIFICATIONS


Attribute	Detail
Product Dimensions	6 x 3 x 1 inches
Item Weight	10 ounces
ASIN	B09Q32VQD1
Item Model Number	Lifepro AcuCare Tilt VibraCare Power
Date First Available	January 7, 2021
Manufacturer	UpBright
Brand	UPBRIGHT
Color	Black
Connector Type	Barrel Connector
Input Voltage	100-240 Volts (AC)
Output Voltage	24 Volts (DC)
Form Factor	Compact

WARRANTY AND SUPPORT

UpBright stands behind the quality of its products. This AC/DC adapter comes with the following warranty and support:

- **Refund Policy:** UpBright offers a 30-day refund policy from the date of purchase.
- **Exchange Policy:** The product is covered by a 24-month exchange policy.
- For any inquiries, technical support, or warranty claims, please contact UpBright customer service. Refer to the packaging or the official UpBright website for contact details.

Come With A Suitable AC Power Cord (Only One) to Fit Your Country/Area



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UpBright® LIMITED WARRANTY



Image: This image displays various international AC power cord types (US, EU, UK, AU) that may be included with the adapter, along with a representation of the UpBright Limited Warranty Certificate.

© 2024 UPBRIGHT. All rights reserved.
For more information, visit the [UPBRIGHT Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09Q32VQD1>

More documents and user manuals: <https://manuals.plus/>