

YESHOMY YH-LR84LMP0

YESHOMY Power Lift Recliner Chair YH-LR84LMP0 User Manual

Detailed instructions for assembly, operation, and maintenance of your YESHOMY Power Lift Recliner Chair.

1. SAFETY INFORMATION

Please read and understand all safety instructions before using the recliner chair. Failure to follow these instructions may result in injury or damage to the product.

- Use with caution for individuals weighing up to 136 kilograms (approximately 300 pounds).
- Clean spills promptly to prevent damage to the PU leather.
- This chair is not intended for activities requiring additional stability or support beyond its designed functions.
- Keep children and pets away from the chair's moving parts.
- Ensure all electrical cords are properly connected and not pinched or damaged.

2. PRODUCT OVERVIEW

The YESHOMY Power Lift Recliner Chair is designed for comfort and convenience, featuring power lift assistance, massage, and heating functions. Its durable PU leather exterior and integrated cup holders enhance the user experience.

Key Features:

- **Power Lift Function:** Assists users in transitioning from a seated to a standing position smoothly and safely.
- **Massage and Heating:** Multiple vibration massage points and a lumbar heating function for

relaxation.

- **Reclining:** Adjustable backrest and leg rest for various comfortable positions.
- **Convenient Design:** Equipped with two cup holders and side pockets for storage.
- **Material:** Smooth and easy-to-clean PU leather surface.



Figure 2.1: The YESHOMY Power Lift Recliner Chair in Dark Black, showcasing its design and features.

3. COMPONENTS LIST

Verify that all components are present before beginning assembly.

- Recliner Base
- Backrest
- Armrests (Left and Right)
- Power Lift Remote Control
- Massage and Heat Remote Control
- Power Adapter
- Assembly Tool Kit

- Instruction Manual (this document)

4. SETUP AND ASSEMBLY

Assembly of the YESHOMY Power Lift Recliner Chair is designed to be straightforward and can typically be completed within 20 minutes with the provided tools and instructions.

4.1 Unpacking

1. Carefully open the packaging and remove all components.
2. Inspect all parts for any signs of damage. Contact customer support immediately if any parts are damaged or missing.
3. Keep packaging materials until assembly is complete and you are satisfied with the product.

4.2 Assembly Instructions

1. Attach the backrest to the recliner base, ensuring it clicks securely into place.
2. Connect all necessary wiring for the power lift, massage, and heating functions. Refer to the included wiring diagram for correct connections.
3. Ensure all connections are firm to prevent malfunction.



Figure 4.1: Product dimensions, useful for planning placement and assembly.

5. OPERATING INSTRUCTIONS

This section details how to use the various functions of your recliner chair.

5.1 Power Lift Function

The power lift function allows for easy transition from a seated to a standing position. Use the dedicated remote control for this feature.

- To activate the lift, press and hold the 'Extended' button on the power lift remote. The chair will slowly and safely tilt forward, assisting you to stand.
- To return to a seated position, press and hold the 'Retracted' button. The chair will gently lower.

Video 5.1: Demonstration of the power lift and recline functions, showing how the chair assists in standing and adjusts for comfort.



Figure 5.1: The recliner chair demonstrating its multiple functions, including assisting a user to stand and various reclining positions for reading, watching, and sleeping.

5.2 Reclining Function

The chair offers adjustable reclining angles for optimal comfort.

- To recline, use the same power lift remote control. The 'Extended' button will also extend the footrest and recline the backrest.
- To return to an upright position, use the 'Retracted' button.

5.3 Massage and Heating Functions

The chair features a vibrating massage system and a lumbar heating element for enhanced relaxation. These functions are controlled by a separate remote.

- **Power:** Press the 'POWER' button to turn the massage and heat functions on/off.
- **Heat:** Press the 'HEAT' button to activate or deactivate the lumbar heating.
- **Intensity:** Adjust massage intensity (High/Low) using the 'INTENSITY' button.
- **Mode:** Cycle through various massage modes (Pulse, Press, Wave, Auto, Normal) using the 'MODE' button.
- **Target Areas:** Select specific massage areas (Back, Lumbar, Thigh, Leg) using the corresponding buttons.
- **Timer:** Set a massage duration (15min, 30min, 60min) using the 'TIMER' button.



Figure 5.2: Visual representation of the 8 massage points and lumbar heating area within the recliner chair.

5.4 Cup Holders and Side Pockets

The chair is equipped with two cup holders and side pockets for convenient storage of beverages, remote controls, books, or other small items.



Figure 5.3: Detail of the integrated cup holders and side pockets for convenient storage.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your recliner chair.

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the PU leather.
- **Spills:** Address spills immediately to prevent staining.
- **Inspection:** Periodically check all connections and moving parts for wear or looseness. Tighten as necessary.

7. TROUBLESHOOTING

If you encounter issues with your recliner chair, refer to the following common problems and solutions.

- **Chair does not power on:**
 - Ensure the power adapter is securely plugged into both the chair and a working wall outlet.
 - Check all internal wiring connections for looseness.
- **Massage/Heat functions not working:**
 - Verify the massage/heat remote control is properly connected and receiving power.
 - Ensure the 'POWER' button on the remote has been pressed.
- **Squeaking noises during operation:**
 - Apply a silicone-based lubricant to any visible pivot points or metal-on-metal contact areas in the reclining mechanism.
 - Ensure all assembly bolts are tightened.

8. SPECIFICATIONS

Brand	YESHOMY
Model Name	Power Lift Recliner Sofa
Item Model Number	YH-LR84LMP0
Color	Dark Black
Product Dimensions	28"D x 32"W x 42"H
Item Weight	107 pounds
Maximum Weight Recommendation	136 Kilograms (300 lbs)
Upholstery Fabric Type	PU Leather
Fill Material	Foam
Special Features	Power Lift, Massage, Heating, Arm Rest, Cup Holders

9. WARRANTY AND SUPPORT

For warranty information, technical support, or to report any issues with your YESHOMY Power Lift Recliner Chair, please contact YESHOMY customer service. Refer to your purchase documentation for specific contact details and warranty terms.

You may also visit the official YESHOMY store for additional product information and support resources: [YESHOMY Store](#)