



Manuals.plus /

› **Fydeamer** /

› Fydeamer Universal Tripod Easel TV Stand Instruction Manual for 32-65 inch TVs

Fydeamer Universal Tripod Easel TV Stand

Fydeamer Universal Tripod Easel TV Stand Instruction Manual

Model: Universal Tripod Easel TV Stand (B09Q3BCGVZ)
For 32-65 inch LED LCD Flat Curved Screens

IMPORTANT SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 44 lbs (20 kg). Ensure your TV's weight is within this limit.
- **TV Size Compatibility:** This stand is designed for TVs between 32 and 65 inches. Verify your TV's size before installation.
- **VESA Compatibility:** Ensure your TV's VESA mounting pattern matches the stand's supported patterns (200x200, 200x300, 200x400, 300x300, 300x400, 400x400, 600x400).
- **Stable Surface:** Always place the tripod stand on a flat, stable, and level surface to prevent tipping.
- **Child Safety:** Keep children away from the stand during assembly and ensure the TV is securely mounted to prevent accidental falls.
- **Professional Installation:** If you are unsure about any part of the assembly process, seek professional assistance.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight and secure.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. Refer to the parts list provided in your product packaging for exact identification.

- Tripod Legs (3x)
- Center Pole
- TV Mounting Plate
- TV Brackets (2x)
- Cable Management Clips

- Hardware Kit (screws, washers, spacers, Allen wrench)
- Instruction Manual



Image: The Fydeamer Universal Tripod Easel TV Stand fully assembled, showcasing its design and stability.

SETUP INSTRUCTIONS

Follow these steps carefully to assemble your Fydeamer Universal Tripod Easel TV Stand.

Step 1: Unpack and Verify Components

Carefully remove all parts from the packaging. Compare the contents with the parts list to ensure everything is present and undamaged. Do not discard packaging until assembly is complete.

Step 2: Assemble the Tripod Base

1. Attach the three tripod legs to the central hub using the provided screws and tools. Ensure each leg is securely fastened.
2. Insert the bottom section of the center pole into the central hub and secure it.



Image: Detailed diagram illustrating the stand's dimensions, features like cable management, non-slip feet, and the sturdy tripod base.

Step 3: Attach the TV Mounting Bracket

1. Slide the TV mounting plate onto the top section of the center pole. Adjust to your desired height and secure it with the locking mechanism.
2. Attach the two TV brackets to the back of your television using the appropriate VESA screws, washers, and spacers from the hardware kit. Ensure the brackets are level and securely tightened.

Step 4: Mount the TV

1. With assistance, carefully lift the television and hook the TV brackets onto the TV mounting plate.
2. Secure the TV to the mounting plate using the safety screws or locking mechanisms provided. Ensure the TV is firmly attached and cannot be accidentally dislodged.



Image: Visual representation of the stand's compatibility with TVs ranging from 32 to 65 inches.

Step 5: Cable Management

Utilize the integrated cable management clips along the center pole and tripod legs to neatly route and conceal TV cables. This helps maintain a clean appearance and prevents tripping hazards.

OPERATING INSTRUCTIONS

Adjusting Height

The TV mounting plate can be adjusted vertically along the center pole. To adjust, loosen the locking mechanism, slide the TV to the desired height (between 45.47" and 55.51"), and securely tighten the locking mechanism. Always ensure the TV is level after adjustment.

Swivel Function

The TV can be swiveled up to 70 degrees left or right ($\pm 70^\circ$). Gently rotate the television to achieve your optimal viewing angle. The swivel mechanism is designed for smooth, controlled movement.



Image: Visual guide demonstrating the stand's swivel range and VESA compatibility.

Cable Management

Utilize the provided cable clips to route power and signal cables along the stand's central pole and legs. This keeps cables organized and out of sight, contributing to a tidy setup.

MAINTENANCE

- **Cleaning:** Wipe the stand with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Periodic Inspection:** Regularly check all screws, bolts, and connections to ensure they are tight. Loose connections can compromise stability.
- **Non-Slip Feet:** Ensure the non-slip rubber feet on the tripod legs are clean and intact to prevent scratches on your floor and maintain stability.

TROUBLESHOOTING

- **Stand is Unstable:**

Solution: Ensure the tripod legs are fully extended and evenly spaced. Verify that all screws are tightened. The stand must be on a flat, level surface.

- **TV is Not Level:**

Solution: Check that the TV brackets are attached evenly to the back of the TV. Adjust the TV mounting plate on the center pole to ensure it is horizontal.

- **Difficulty Swiveling TV:**

Solution: Ensure no cables are obstructing the swivel mechanism. The swivel should operate smoothly without excessive force.

- **Missing Parts:**

Solution: Refer to the package contents list. If parts are missing, contact Fydeamer customer support.

SPECIFICATIONS

Brand	Fydeamer
Model	Universal Tripod Easel TV Stand
Compatible TV Sizes	32 - 65 inches
Maximum Weight Capacity	44 lbs (20 kg)
VESA Compatibility	200x200, 200x300, 200x400, 300x300, 300x400, 400x400, 600x400
Height Adjustment Range	45.47" to 55.51"
Swivel Angle	±70 degrees
Material	Solid Wood and Steel
Item Weight	13.87 lbs
UPC	789007859933

WARRANTY AND SUPPORT

Fydeamer products are manufactured with quality and durability in mind. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For technical support, missing parts, or warranty claims, please contact Fydeamer customer service through the retailer's platform or visit the official Fydeamer website for contact information.

Online Resources: For additional support and frequently asked questions, please visit the Fydeamer brand store on Amazon: [Fydeamer Store](#)