

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Acogedor](#) /

> [Acogedor Bluetooth 5.0 Receiver Wireless Audio Adapter User Manual](#)

Acogedor Acogedordebyv7h1rw1035

Acogedor Bluetooth 5.0 Receiver Wireless Audio Adapter User Manual

Model: Acogedordebyv7h1rw1035

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Acogedor Bluetooth 5.0 Receiver Wireless Audio Adapter. Please read this manual thoroughly before using the product to ensure proper function and to prevent damage.



Image: The Acogedor Bluetooth 5.0 Receiver, highlighting its NFC capability.

SAFETY INFORMATION

- Do not expose the device to water or moisture.
- Avoid extreme temperatures.

- Do not disassemble the device. This will void the warranty.
- Use only the provided or recommended power adapter (DC 5V).
- Keep out of reach of children.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Acogedor Bluetooth 5.0 Receiver
- 3.5mm Audio Cable
- RCA Audio Cable
- USB Power Cable
- User Manual (this document)



Image: The various audio and power cables included with the receiver.

PRODUCT OVERVIEW

Familiarize yourself with the ports and controls of the Acogedor Bluetooth 5.0 Receiver.



Image: Rear panel with power input, USB port, RCA audio output, and 3.5mm AUX output.



Image: Top panel with playback control buttons (Previous, Play/Pause, Next).

1. **DC 5V Input:** Power connection port (Micro USB).
2. **USB Port:** For U disk playback.
3. **Audio Out (RCA):** Red and white RCA jacks for audio output to amplifiers or speakers.
4. **AUX Out:** 3.5mm jack for audio output to speakers or headphones.
5. **Control Buttons:** Previous track, Play/Pause, Next track.
6. **NFC Area:** For near-field pairing with compatible devices.

SETUP

1. Power Connection

1. Connect the provided USB power cable to the **DC 5V Input** port on the receiver.
2. Plug the other end of the USB cable into a 5V USB power adapter (not included) or a USB port on your audio equipment.
3. The indicator light on the receiver will illuminate, indicating it is powered on.

2. Audio Output Connection

Choose one of the following methods to connect the receiver to your audio system:

- **Using RCA Cables:** Connect one end of the RCA audio cable to the **Audio Out (RCA)** ports (red to red, white to white) on the receiver. Connect the other end to the corresponding RCA input ports on your amplifier or active speakers.
- **Using 3.5mm AUX Cable:** Connect one end of the 3.5mm audio cable to the **AUX Out** port on the receiver. Connect the other end to the 3.5mm AUX input port on your speaker, headphones, or amplifier.



Image: The receiver connected to an external speaker and a smartphone, demonstrating a typical setup.

3. Bluetooth Pairing

The receiver will automatically enter pairing mode when powered on. The indicator light will flash.

- **NFC Pairing (Recommended for NFC-enabled devices):**
 - a. Ensure NFC is enabled on your smartphone or other NFC-enabled device.
 - b. Tap your NFC-enabled device gently against the **NFC Area** on the top of the receiver.
 - c. Confirm the pairing request on your device. The receiver will connect automatically.



Image: A smartphone being used to initiate NFC pairing with the receiver.

- **Manual Bluetooth Pairing:**

- a. On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings.
- b. Search for available devices. The receiver will appear as "Acogedor Bluetooth Receiver" or similar.
- c. Select the receiver from the list to connect.
- d. Once connected, the indicator light will become solid blue.

OPERATING INSTRUCTIONS

Bluetooth Audio Playback

1. Ensure the receiver is powered on and successfully paired with your device.
2. Start playing audio on your paired device. The sound will be transmitted wirelessly to the receiver and output through your connected speakers.
3. Use the **Control Buttons** on the receiver or your paired device to manage playback:
 - **Play/Pause:** Press the center button.
 - **Next Track:** Press the right button.
 - **Previous Track:** Press the left button.

U Disk Playback

The receiver supports playing audio files directly from a USB flash drive.

1. Insert a USB flash drive containing audio files into the **USB Port** on the receiver.
2. The receiver will automatically detect the U disk and begin playing audio.
3. Use the **Control Buttons** to navigate tracks.



Image: The receiver demonstrating connections for both Bluetooth audio from a smartphone and direct playback from a USB flash drive.

MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use liquid cleaners or aerosols.
- Keep the ports free of dust and debris.
- Store the receiver in a cool, dry place when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power indicator light.	Power cable not connected or faulty power source.	Ensure the USB power cable is securely connected to both the receiver and a working 5V power source. Try a different USB port or adapter.
Cannot pair via Bluetooth.	Receiver not in pairing mode; Bluetooth disabled on source device; too many paired devices.	Ensure the receiver is powered on and the indicator light is flashing (pairing mode). Enable Bluetooth on your source device. Forget previous pairings on your device and try again. Move closer to the receiver.
No sound output.	Incorrect audio cable connection; volume too low; wrong input selected on amplifier/speaker.	Verify audio cables are correctly connected to the Audio Out ports on the receiver and the correct input on your speaker/amplifier. Increase volume on both the source device and the connected audio system. Ensure the correct input source is selected on your amplifier/speaker.
U Disk playback not working.	U disk not inserted correctly; unsupported file format; U disk corrupted.	Ensure the U disk is fully inserted into the USB Port . Check if audio files are in a supported format (e.g., MP3). Try a different U disk.

SPECIFICATIONS

Feature	Detail
Model	Acogedordebyv7h1rw1035
Bluetooth Version	5.0
Connectivity Technology	Auxiliary, Bluetooth, NFC, RCA, USB
Audio Output Mode	Stereo
Connector Type	3.5mm Jack, RCA, USB
Compatible Devices	Smartphone, Speaker, Amplifier
Power Input	DC 5V (via Micro USB)
Product Dimensions	6.3 x 5.12 x 1.57 inches
Item Weight	5.3 ounces (0.15 Kilograms)
Wireless Range	Up to 15 meters / 49.2 feet (barrier-free)



Image: Key features of the receiver including Bluetooth reception, signal transmission range, USB playback, and decoding chip.

WARRANTY AND SUPPORT

Acogedor products are designed for reliability and performance. For any questions, technical support, or warranty claims, please contact Acogedor customer service through the retailer where the product was purchased.

Please retain your proof of purchase for warranty purposes.