

Bowost J97[New]

Bowost Wireless Earbuds J97 User Manual

Brand: Bowost
Model: J97[New]

PRODUCT OVERVIEW

The Bowost J97 Wireless Earbuds offer a high-fidelity audio experience with advanced Bluetooth 5.2 technology, ensuring stable and low-latency connections. Designed for comfort and durability, these earbuds are IP7 waterproof and feature a compact charging case with dual LED digital display.

Key features include:

- **Bluetooth 5.2 and One-Step Auto Pairing:** Provides fast, stable, and seamless connection with automatic pairing upon removal from the case.
- **Hi-Fi Stereo Sound and Noise Reduction Dual Mics:** Equipped with 10mm speakers and triple-layer composite diaphragms for powerful bass, clear mids, and stunning treble. Built-in mics with call noise cancellation ensure clear conversations.
- **Dual LED Digital Display and USB-C Charging:** The charging case features a digital display to show battery levels for both the case and earbuds. Offers up to 40 hours of total playtime with the charging case, which recharges via USB-C.
- **IP-X7 Waterproof and Ultralight Design:** Designed to withstand sweat and water, making them ideal for sports and outdoor activities. Ergonomic design with multiple ear tip sizes (S/M/L) ensures a secure and comfortable fit for extended use.
- **Simply Control:** Physical buttons on the earbuds allow for easy control of music playback, calls, volume, and Siri activation without needing to access your mobile device.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- 2 x Wireless Earbuds (Left and Right)
- 1 x Fast Charging Case
- 1 x Type-C Charging Cable
- 3 x Pairs of Silicone Earplugs (Sizes S, M, L)
- 1 x User Manual

SETUP

Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided Type-C charging cable to the charging case and a compatible USB power source. The dual LED digital display on the case will show the charging progress, flashing from 1 to 100. Once fully charged, the display will show 100. Place the earbuds into the charging case; they will begin charging automatically, indicated by their respective LED lights.

Pairing with Your Device

1. First Time Use:

1. Open the charging case and take out both J97 earbuds. They will automatically power on and enter pairing mode.
2. On your mobile device, enable Bluetooth and search for "J97" in the list of available devices.
3. Select "J97" to connect. Once connected, you will hear a confirmation tone, and the earbud indicator lights will turn off.

2. Subsequent Use:

Once paired, the J97 earbuds will automatically connect to the last paired device when taken out of the charging case. Ensure Bluetooth is enabled on your device.

3. Mono Mode:

You can use a single earbud independently. Simply take one earbud out of the case, and it will connect to your device. The other earbud can remain in the case or be used with a different device.

Wearing the Earbuds

Choose the silicone ear tips (S/M/L) that provide the most comfortable and secure fit for your ears. Gently insert the earbuds into your ear canal and twist slightly to ensure a snug fit. A proper fit is crucial for optimal sound quality and noise isolation.



Image: The Bowost J97 wireless earbuds, with one earbud placed in its open charging case and the other two earbuds displayed separately, showcasing their design and the charging case's interior.

OPERATING INSTRUCTIONS

Touch Controls

The J97 earbuds feature physical buttons for easy control. Refer to the following table for common operations:

Function	Action
Play/Pause Music	Single press either earbud button.
Next Song	Double press the Right earbud button.
Previous Song	Double press the Left earbud button.
Volume Up	Triple press the Right earbud button.
Volume Down	Triple press the Left earbud button.
Answer/End Call	Single press either earbud button during an incoming call.
Reject Call	Press and hold either earbud button for 2 seconds during an incoming call.
Activate Voice Assistant (Siri, Google Assistant)	Press and hold either earbud button for 3 seconds.

Multiple Modes

- **Mono Mode:** Use one earbud independently for calls or music, connecting it to one device while the other earbud can be used with a different device or remain in the charging case.
- **Sharing Mode:** Share your music or movies with a friend or family member by having each person wear one earbud, connected to the same device.

Battery Life and Charging

The earbuds provide over 8 hours of playtime on a single charge. The charging case extends the total playtime to approximately 40 hours. The case can be fully recharged in about 1 hour using the USB-C cable.

When the earbuds are placed back into the charging case, they will automatically begin to charge. The LED display on the case indicates the current charge level of the case and the individual earbuds.

MAINTENANCE

To ensure the longevity and optimal performance of your Bowost J97 Wireless Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. For ear tips, remove them and clean with a damp cloth, then dry thoroughly before reattaching. Avoid using abrasive materials or harsh chemicals.
- **Water Resistance:** The earbuds are IP-X7 waterproof, meaning they can withstand immersion in up to 1 meter of water for 30 minutes. However, they are not designed for swimming or prolonged submersion. Always ensure the charging port on the case is dry before charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures and direct sunlight.
- **Battery Care:** To preserve battery health, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not in constant use.

TROUBLESHOOTING

If you encounter any issues with your Bowost J97 Wireless Earbuds, please refer to the following common solutions:

- **Only One Earbud Working:**
 1. Ensure both earbuds are fully charged.
 2. Place both earbuds back into the charging case, close the lid, and wait a few seconds. Then, take them out again to re-establish the connection.
 3. Check for any protective plastic film covering the charging contacts on the earbuds. Remove if present.
 4. On your device, forget or delete "J97" from your Bluetooth paired devices list. Then, repeat the pairing process from scratch.
- **Earbuds Not Connecting/Pairing:**

1. Ensure Bluetooth is enabled on your device and the earbuds are within range (typically 10 meters/33 feet).
2. Make sure the earbuds are charged.
3. Turn off and on your device's Bluetooth, then try pairing again.
4. If issues persist, try restarting your mobile device.

- **Low Volume or Poor Sound Quality:**

1. Adjust the volume on both your earbuds and your connected device.
2. Ensure the ear tips are properly sealed in your ear canal. Try different sized ear tips for a better fit.
3. Clean any debris from the earbud speakers and ear tips.
4. Ensure there are no obstructions between your device and the earbuds that could interfere with the Bluetooth signal.

- **Charging Case Not Charging:**

1. Verify the USB-C cable is securely connected to both the case and the power source.
2. Try a different USB-C cable or power adapter.
3. Ensure the power source is active.

If these steps do not resolve the issue, please contact Bowst customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Name	J97[New]
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.2
Headphones Jack	USB-C (for charging case)
Water Resistance Level	IP-X7 Waterproof
Control Type	Physical Button (Call Control, Volume Control, Noise Control, One-Key Control)
Battery Life (Earbuds)	Over 8 hours (single charge)
Total Playtime (with Case)	Up to 40 hours
Charging Time (Case)	Approx. 1 hour (via USB-C)

Feature	Detail
Earbud Weight	2 Grams (each)
Material	Plastic, Silicone
Compatible Devices	All devices with Bluetooth connection (iPhone, iPad, Android, Samsung, Huawei, Xiaomi, etc.)

WARRANTY AND SUPPORT

Bowost products are manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or any product-related inquiries, please refer to the contact information provided on the product packaging or visit the official Bowost website.

Please retain your proof of purchase for warranty claims.