

[Manuals.plus](#) /

› [DEEPOWER](#) /

› DEEPOWER Fishing Hook Quick Remover and Knot Tying Tool Instruction Manual

DEEPOWER FH-122

DEEPOWER Fishing Hook Quick Remover and Knot Tying Tool

Model: FH-122

1. PRODUCT OVERVIEW

The DEEPOWER Fishing Hook Quick Remover and Knot Tying Tool is a versatile fishing accessory designed to simplify hook removal and knot tying. Constructed from high-quality stainless steel and resin, this lightweight tool features a spiral design for efficient hook disengagement and a specialized tail for quick knot tying. It is suitable for various fishing environments, including sea, river, and ice fishing.



This image displays the three color variations of the DEEPOWER Fishing Hook Quick Remover and Knot Tying Tool: orange, black, and red. Each tool features a handle for grip and a metal hook remover tip.

2. FEATURES

- **Simple to Use:** Designed for fast hook removal with a spiral tip, making it easier to access and remove hooks from fish.
- **Quick Knot Tying:** The tail design facilitates quick knot tying in approximately three seconds, ensuring secure connections without damaging the fishing line.
- **Safe and Easy:** Suitable for anglers of all ages and experience levels. Helps prevent fish loss due to faulty knots and is ideal for use in cold weather conditions or by individuals with limited dexterity.
- **Durable Construction:** The head is made of high-quality resin, and the tail features stainless steel fittings, providing resistance to various weather conditions and saltwater corrosion.

- **Easy to Carry:** With a length of 6.69 inches and a weight of 10g, the tool is lightweight and compact for convenient transport in any tackle box.

3. How to Use

3.1. Tying Fishing Knots

The DEEPOWER tool simplifies tying various fishing knots, such as attaching line to a hook or swivel. Follow these steps for a secure connection:

1. **Insert Line:** Thread the fishing line through the eye of the hook or swivel.
2. **Position Tool:** Place the knot-tying end of the DEEPOWER tool (the part with the small hook/groove) against the hook shank or swivel eye, holding the line taut.
3. **Wrap Line:** Wrap the tag end of the fishing line around the tool and the main line several times (typically 5-7 wraps, depending on line type and desired strength).
4. **Secure Knot:** Pass the tag end back through the loop created near the hook/swivel eye.
5. **Tighten:** Moisten the knot with saliva or water, then slowly pull both the main line and the tag end to tighten the knot firmly against the hook or swivel.
6. **Trim Excess:** Use fishing line clippers to trim any excess tag end, leaving a small stub for security.



This image illustrates the four key steps for tying a fishing line to a hook using the DEEPOWER tool's integrated knot-tying feature. It shows how to loop the line, secure it, and tighten the knot.

3.2. Removing Hooks

The spiral hook remover tip is designed for quick and safe hook removal, minimizing harm to the fish and your hands.

1. **Grip Fish:** Securely hold the fish, ensuring its safety and minimizing stress.
2. **Locate Hook:** Identify the embedded hook.
3. **Insert Remover:** Slide the spiral tip of the DEEPOWER tool along the fishing line, down to the hook.

- 4. **Engage Hook:** Gently push the tool forward until the spiral tip engages the bend of the hook.
- 5. **Dislodge Hook:** With a slight twist and push, the spiral design will help dislodge the hook from the fish's mouth.
- 6. **Release Fish:** Once the hook is removed, carefully release the fish back into the water.



A detailed view of the spiral-designed tip of the DEEPOWER tool, used for safely dislodging fishing hooks from fish.

4. SPECIFICATIONS

Attribute	Detail
Brand	DEEPOWER
Model Number	FH-122
Material	Resin, Stainless Steel
Item Weight	10 Grams
Item Dimensions (L x W x H)	6.7 x 1.5 x 0.5 inches
Number of Pieces	2
Target Species	Bass (suitable for various species)

5. MAINTENANCE

To ensure the longevity and optimal performance of your DEEPOWER Fishing Hook Quick Remover and Knot Tying Tool, follow these maintenance guidelines:

- **Rinse After Use:** After each use, especially in saltwater, rinse the tool thoroughly with fresh water to remove salt, dirt, and debris.
- **Dry Completely:** Ensure the tool is completely dry before storing to prevent rust or corrosion, particularly on the stainless steel components.
- **Store Properly:** Store the tool in a dry place, ideally within your tackle box, to protect it from physical damage and environmental elements.
- **Inspect Regularly:** Periodically check the tool for any signs of wear, damage, or corrosion.

6. TROUBLESHOOTING

If you encounter any issues while using your DEEPOWER tool, consider the following common troubleshooting tips:

- **Difficulty Tying Knots:**

- Ensure the line is properly seated in the tool's groove.
- Increase the number of wraps for better grip, especially with slick lines.
- Moisten the line before tightening to allow the knot to cinch smoothly.

- **Difficulty Removing Hooks:**

- Ensure the spiral tip is fully engaged with the hook bend.
- Apply gentle, consistent pressure and a slight twisting motion.
- For deeply embedded hooks, consider cutting the line and retrieving the hook later if the fish's safety is paramount.

- **Tool Feels Stiff:**

- Clean the tool thoroughly to remove any accumulated grime or salt.
- Apply a small amount of silicone-based lubricant to moving parts if applicable, though this tool has minimal moving parts.

7. WARRANTY AND SUPPORT

For detailed information regarding warranty coverage, product support, or to contact customer service, please refer to the product packaging or visit the official DEEPOWER website. Keep your purchase receipt as proof of purchase for any warranty claims.