

[Manuals.plus](#) /

› [ASOFTY](#) /

› ASOFTY Beach Tent ASGR26 Instruction Manual

ASOFTY ASGR26

ASOFTY Beach Tent ASGR26 Instruction Manual

Model: ASGR26

1. INTRODUCTION

Thank you for choosing the ASOFTY Beach Tent ASGR26. This pop-up sun shelter is designed for quick installation and provides UPF 50+ UV protection and water resistance, making it suitable for various outdoor activities such as beach trips, camping, garden use, fishing, and picnics. This manual provides essential information for the safe and effective use, setup, maintenance, and storage of your tent.



The ASOFTY Beach Tent provides shade and protection for outdoor activities.

2. SAFETY INFORMATION

- **Fire Safety:** Keep all flame and heat sources away from this tent fabric. The fabric will burn if left in continuous contact with any flame source.
- **Ventilation:** Ensure adequate ventilation to prevent suffocation. Do not use gas-burning appliances inside the tent.
- **Weather Conditions:** Do not use the tent in extreme weather conditions such as strong winds, heavy rain, or lightning. Secure the tent properly with stakes and ropes in moderate wind.
- **Children:** Children should always be supervised when near or inside the tent.
- **Sharp Objects:** Avoid bringing sharp objects inside the tent that could puncture the fabric.

3. PACKAGE CONTENTS

Please verify that all components are present before attempting to set up the tent:

- 1 x ASOFTY Pop Up Beach Tent
- 8 x Ground Nails (Stakes)
- 4 x Ropes
- 1 x Storage Bag

Perfect Size for 3-4 People



Included components: tent, ground nails, ropes, and storage bag.

4. SETUP INSTRUCTIONS

The ASOFTY Beach Tent features a quick, one-touch pop-up design for easy assembly.

1. **Choose a Location:** Select a flat, clear area large enough for the tent (approximately L200 x W150 x H120 cm).
2. **Unpack:** Remove the tent from its storage bag and lay it flat on the ground.
3. **Pop Up:** Grasp the central mechanism at the top of the tent. Lift it upwards until the tent frame fully expands and locks into place. This is a one-touch operation.

4. **Secure the Tent:** For stability, especially in windy conditions, use the provided ground nails and ropes. Insert the 8 ground nails through the tent's loops into the ground. Attach the 4 ropes to the designated points on the tent and secure them to the ground using additional ground nails, pulling them taut.



Quick Installation and Storage



Choose a big enough area, lift up to open



Collapse the bottom and press to close

The central hub allows for quick and easy pop-up setup.

5. OPERATING INSTRUCTIONS

- **Ventilation:** The tent features mesh windows on both sides and an open design window on the back door for optimal air circulation. Open these windows to enhance airflow and keep the interior cool.
- **Privacy:** The tent offers a fully enclosed design with double zippers. Close the windows and zip up the doors for privacy when needed.
- **UV Protection:** The interior of the tent is coated with UPF 50+ material to protect against harmful UV rays.
- **Water Resistance:** The outer fabric is 170T waterproof material, providing protection against light rain.



The tent's design ensures optimal ventilation for comfort.



Mesh windows provide ventilation while keeping insects out.

6. DISASSEMBLY INSTRUCTIONS

To collapse and pack away your ASOFTY Beach Tent:

1. **Remove Stakes and Ropes:** Detach all ropes and remove the ground nails from the ground.
2. **Collapse:** Locate the central mechanism at the top of the tent. Press down on the mechanism to release the frame and collapse the tent.
3. **Fold:** Gently gather the tent fabric and frame, folding it neatly to fit into the storage bag.
4. **Store:** Place the folded tent, ground nails, and ropes into the provided storage bag.



The central hub allows for quick and easy disassembly by pressing down.

7. MAINTENANCE

- **Cleaning:** Clean the tent with a damp cloth and mild soap. Do not use harsh detergents or abrasive cleaners. Rinse thoroughly and allow to air dry completely before storage.
- **Drying:** Always ensure the tent is completely dry before folding and storing to prevent mold and mildew growth.

- **Storage:** Store the tent in its storage bag in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the tent for any damage, such as tears in the fabric or bent poles. Repair minor damage promptly to extend the tent's lifespan.

8. TROUBLESHOOTING

- **Tent won't pop up:** Ensure the central mechanism is fully lifted and locked. Check for any obstructions in the frame.
- **Tent unstable in wind:** Always use all 8 ground nails and 4 ropes to secure the tent. Ensure ropes are taut and stakes are firmly in the ground. Consider purchasing longer, more robust stakes for very windy conditions.
- **Difficulty folding:** Ensure the central mechanism is fully pressed down to release the frame. Gently guide the poles and fabric to fold them into the compact shape. Do not force.
- **Small holes/stitching issues:** For minor issues, repair kits for tent fabric can be used. For significant defects, refer to warranty information.

9. SPECIFICATIONS

Feature	Detail
Model Number	ASGR26
Brand	ASOFTY
Material	170T Waterproof Fabric
Color	Blue
Occupancy	3-4 Person
Product Dimensions (L x W x H)	78.74 x 59.06 x 47.24 inches (200 x 150 x 120 cm)
Item Weight	4.58 pounds
Packed Dimensions	Approximately 13 x 13 x 67 cm (5.1 x 5.1 x 26.4 inches)
UV Protection	UPF 50+
Assembly Required	No (Pop-up design)

10. WARRANTY INFORMATION

ASOFTY products are manufactured to high-quality standards. For specific warranty details, including coverage period and terms, please refer to the product packaging or visit the official ASOFTY website. Keep your purchase receipt as proof of purchase for any warranty claims.

11. CUSTOMER SUPPORT

If you have any questions, concerns, or require assistance with your ASOFTY Beach Tent ASGR26, please contact ASOFTY customer service. Contact information can typically be found on the product packaging or the official ASOFTY website.

© 2023 ASOFTY. All rights reserved.