Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Parkside PLLA 12 B2

PARKSIDE PLLA 12 B2 LED Work Light Instruction Manual

Model: PLLA 12 B2

1. Introduction

Thank you for choosing the PARKSIDE PLLA 12 B2 LED Work Light. This manual provides important information regarding the safe operation, setup, maintenance, and troubleshooting of your device. Please read these instructions carefully before first use and keep them for future reference. This product is designed for illuminating work areas and is compatible with PARKSIDE X 12V Team series batteries.

Note: The battery and charger are not included with this product and must be purchased separately.

2. Safety Instructions

- Always ensure the work light is switched off before performing any adjustments, maintenance, or cleaning.
- Do not look directly into the LED light. The intense light can cause temporary vision impairment or eye damage.
- Keep the device out of reach of children.
- Use only original PARKSIDE 12V batteries and chargers with this device. Using incompatible accessories may result in fire, electric shock, or injury.
- Protect the device from moisture and extreme temperatures. Do not immerse in water.
- If the device is damaged, do not attempt to repair it yourself. Contact qualified service personnel.
- Ensure adequate ventilation when operating the light, as it may generate some heat.

3. Product Overview

The PARKSIDE PLLA 12 B2 LED Work Light features a robust design with an adjustable head for versatile illumination. It includes multiple LEDs for bright, even lighting and a magnetic base for secure attachment to metallic surfaces.



Figure 1: Main view of the PARKSIDE PLLA 12 B2 LED Work Light, showing the adjustable light head and power button.



Figure 2: Front view of the LED panel, highlighting the individual LED lights.



Figure 3: Side view illustrating the adjustable head, which can be rotated from 0 to 200 degrees.

4. Setup

4.1. Battery Installation

1. Ensure the work light is switched off.
2. Locate the battery compartment at the base of the work light.

3. Align a compatible PARKSIDE X 12V Team series battery with the compartment.
4. Slide the battery into the compartment until it clicks securely into place.
5. To remove the battery, press the release button (if present on your battery model) and slide the battery out.



Figure 4: Illustration showing the battery connection area on the work light.

Figure 5: Visual confirmation that battery and charger are sold separately.

5. Operating Instructions

5.1. Powering On/Off and Brightness Adjustment

1. Press the power button once to turn on the work light at the first brightness level.
2. Press the power button a second time to switch to the second, higher brightness level.

3. Press the power button a third time to turn off the work light.

5.2. Adjusting the Light Head

The light head can be manually adjusted to direct the light beam as needed. It offers an adjustment angle of 0-200 degrees. Gently pivot the light head to the desired position.

5.3. Magnetic Attachment

The work light features a magnetic base, allowing it to be securely attached to metallic surfaces for hands-free operation.

6. Maintenance and Care

6.1. Cleaning

- Before cleaning, ensure the device is switched off and the battery is removed.
- Wipe the device with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure no liquids enter the device housing.

6.2. Storage

Store the work light in a dry, dust-free environment, away from direct sunlight and extreme temperatures.

6.3. Recycling

Information on recycling light bulbs and electronic devices can be found through local recycling programs. Please dispose of the product and its accessories responsibly according to local regulations.

7. Troubleshooting

- **Light does not turn on:** Check if the battery is correctly inserted and fully charged. Ensure the power button is pressed firmly.
- **Light is dim:** The battery might be low. Recharge or replace the battery.
- **Device overheats:** Discontinue use and allow the device to cool down. Ensure it is not covered or operating in an enclosed space. If overheating persists, contact customer support.

8. Specifications

Feature	Specification
Model	PLLA 12 B2
Internal Model Number	IAN-100382052
Brand	Parkside
Light Source	LED (Diode électroluminescente)
Luminous Flux	Max. 480 lm
Color Temperature	6,500 K (Cool White)
Light Head Adjustment Angle	0-200°

Voltage	12 Volts
Dimensions (L x W x H)	22 x 8 x 8 cm
Weight	268 grams
Material	Metal, Plastic
UPC	4055334261715

9. Warranty and Support

This product is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, service inquiries, or spare parts, please contact the PARKSIDE service hotline:

- **Poland:** +48 22 397 4996
- **Lithuania:** +370 880 033 144

When contacting support, please provide the model number (PLLA 12 B2) and the IAN number (IAN-100382052) for faster assistance. The document ID for this manual is IAN 359702_2101.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09Q7G5P4S

More documents and user manuals: **https://manuals.plus/**