



[Manuals.plus](#) /

> [Garden Winds](#) /

> Garden Winds Replacement Canopy for Style Selections Track Arm Rest Swing Model GCS00395A (LCM1870B-RS)

## Garden Winds LCM1870B-RS

# Garden Winds Replacement Canopy Top Instruction Manual

For Style Selections Track Arm Rest Swing Model GCS00395A

## 1. PRODUCT OVERVIEW

---

This document provides instructions for the Garden Winds Reinforced RipLock 350 Replacement Canopy Top Cover, designed specifically for the Style Selections Track Arm Rest Swing, Model GCS00395A (SKU: 4134962). This replacement canopy is crafted from durable RipLock 350 polyester fabric, offering enhanced protection and longevity for your outdoor swing.





Image 1.1: A Style Selections Track Arm Rest Swing with the Garden Winds replacement canopy installed, situated in a landscaped garden.

The canopy features a reinforced grid pattern to help limit tear spread, is UPF 50+ UV resistant, water resistant, and CPAI-84 fire retardant, making it suitable for various outdoor conditions. Please note that this product includes only the replacement canopy top; the metal swing frame is not included.

## 2. COMPATIBILITY

---

This replacement canopy is custom-designed to fit the **Style Selections Track Arm Rest Swing Model GCS00395A**. It is crucial to verify your swing's model number to ensure proper fit. The model number GCS00395A is typically found on a label on the swing frame.

<b>OURS</b> 	<b>GENERIC</b> 
<b>High-denier polyester</b>	<b>Thin polyester</b>
<b>UV-resistant</b>	<b>Minimal UV protection</b>
<b>Reinforced seams</b>	<b>Standard seams</b>
<b>Precision Fit</b>	<b>Universal fit</b>
<b>1 Year Limited Performance Warranty</b>	<b>No Warranty</b>

**THE DIFFERENCE IS IN THE DETAILS**




Image 2.1: Visual guide for checking your swing model and approximate canopy dimensions.

Before installation, compare the design and dimensions of your existing swing frame with the images provided to confirm compatibility. Pay close attention to the armrest style and canopy attachment points.

## VERIFY YOUR FRAME DETAILS



## FRAME IDENTIFICATION



Image 2.2: Detailed views of the swing frame for identification and compatibility verification.

### 3. KEY FEATURES

- **Model-Specific Custom Fit:** Engineered for a precise fit on Style Selections Track Arm Rest Swing Model GCS00395A.
- **RipLock 350 Fabric:** Constructed from 350 denier polyester with a reinforced grid pattern to minimize tear propagation.
- **Outdoor-Rated Protection:** Offers UPF 50+ UV resistance, water resistance, and CPAI-84 fire retardancy.
- **Durable Construction:** Features Ultra Stitch seams and secure Velcro straps for attachment.



Image 3.1: Overview of the premium features integrated into the canopy design.

The RipLock 350 fabric provides superior durability compared to generic alternatives, ensuring a longer lifespan for your canopy.

## PLEASE CHECK YOUR MODEL

Compatible with the following model numbers:  
GCS00395A



## COMPATIBILITY



Image 3.2: Comparison highlighting the quality differences between this product and generic canopies.



Image 3.3: Icons illustrating the canopy's resistance to various outdoor elements.

## 4. INSTALLATION GUIDE

---

Installation of the replacement canopy typically involves removing the old canopy and attaching the new one to the existing swing frame. While specific steps may vary slightly based on the swing's design, the general process is as follows:

1. **Remove Old Canopy:** Carefully detach the old canopy from the swing frame. Note how it was secured, as this will guide the installation of the new one.
2. **Unfold New Canopy:** Gently unfold the new Garden Winds replacement canopy.
3. **Position Canopy:** Place the new canopy over the swing frame, aligning it with the support bars and attachment points.
4. **Secure Attachments:** Secure the canopy using the integrated Velcro straps or other attachment mechanisms on the canopy and frame. Ensure all straps are fastened tightly to prevent wind uplift.
5. **Adjust for Fit:** Adjust the canopy to ensure an even and taut fit across the frame. Due to the precision fit, the canopy may feel snug initially. It may relax slightly after a few days of use, especially after exposure to weather.

It is recommended to have two people for easier installation, especially when positioning the canopy over

the frame.

## 5. USAGE GUIDELINES

---

To maximize the lifespan and performance of your replacement canopy, adhere to the following guidelines:

- **Secure Attachment:** Always ensure the canopy is securely attached to the swing frame to prevent damage from wind.
- **Weather Conditions:** While the canopy is water-resistant and UV-protected, it is advisable to remove it or store the swing during extreme weather conditions, such as heavy storms, high winds, or prolonged periods of snow, to prevent damage.
- **Weight Distribution:** Ensure the swing is used within its recommended weight capacity.

## 6. CARE AND MAINTENANCE

---

Proper care and maintenance will help preserve the appearance and functionality of your canopy:

- **Cleaning:** Clean the canopy regularly with a soft brush or cloth and a mild soap solution. Rinse thoroughly with clean water and allow it to air dry completely before storage or continued use. Do not use harsh chemicals or abrasive cleaners.
- **Stain Removal:** For stubborn stains, a diluted solution of bleach (e.g., 1 part bleach to 10 parts water) can be used on polyester fabric, but test on an inconspicuous area first. Rinse immediately and thoroughly.
- **Storage:** If storing the swing for an extended period, especially during off-season or harsh weather, remove the canopy, clean it, ensure it is completely dry, and store it in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect the canopy for any signs of wear, tear, or damage to the stitching or fabric. Address minor issues promptly to prevent further damage.

## 7. TROUBLESHOOTING

---

If you encounter issues with your replacement canopy, consider the following:

- **Tight Fit:** A new canopy may feel very tight during initial installation. This is often due to the precision fit. Allow a few days for the fabric to stretch and settle, especially after exposure to sunlight and light rain. Ensure all attachment points are correctly aligned and secured.
- **Loose Fit/Sagging:** Double-check all Velcro straps and attachment points to ensure they are fully secured and tightened. The canopy should be taut across the frame.
- **Water Pooling:** Ensure the canopy is installed correctly and taut to allow water to run off. If pooling occurs, check for any misalignments or sagging areas that may need adjustment.
- **Damage:** For any significant damage or manufacturing defects, refer to the warranty information and contact customer support.

## 8. PRODUCT SPECIFICATIONS

---

Feature	Detail
Brand	Garden Winds

Feature	Detail
Model Number (Canopy)	LCM1870B-RS
Compatible Swing Model	Style Selections Track Arm Rest Swing Model GCS00395A (SKU: 4134962)
Color	Beige
Material	RipLock 350 Polyester
Product Dimensions (Approx.)	91"D x 46"W x 10"H
Item Weight	4 Pounds
UV Protection	UPF 50+ UV Resistant
Water Resistance	Water Resistant
Fire Retardancy	CPAI-84 Fire Retardant

## 9. WARRANTY AND CUSTOMER SUPPORT

---

The Garden Winds Reinforced RipLock 350 Replacement Canopy Top Cover is backed by a **1-year limited performance warranty**. This warranty covers manufacturing defects and performance issues under normal use.

For any questions regarding fit, product issues, or warranty claims, please contact our US-based customer support team. Contact information can typically be found on the product packaging or the Garden Winds official website.