Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Black Shark Lucifer T4

Black Shark Lucifer T4 Wireless Earbuds User Manual

Model: Lucifer T4

Introduction

Thank you for choosing the Black Shark Lucifer T4 Wireless Earbuds. These earbuds are designed to provide an immersive audio experience for gaming and music, featuring ultra-low latency, studio-quality sound, and a comfortable fit. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

What's in the Box

- BLACK SHARK Lucifer T4 Wireless Earbuds
- Eartips (various sizes)
- USB-C Charging Cable
- User Manual (this document)



Image: All components included in the Black Shark Lucifer T4 package, neatly arranged.

Product Overview

The Black Shark Lucifer T4 earbuds feature a sleek design with intuitive touch controls and a compact charging case. Each earbud is equipped with a 6mm dynamic driver for rich audio and an ultra-clear microphone for communication.



Image: A close-up view of the Black Shark Lucifer T4 earbuds, showcasing their design and the illuminated Black Shark logo.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C charging cable to the charging port on the case and a power source. The indicator lights on the case will show the charging status.

- A single charge provides up to 6 hours of listening time.
- The charging case provides an additional 18 hours of battery life, totaling up to 24 hours.




Image: The Black Shark Lucifer T4 earbuds and their charging case, illustrating the long-lasting battery feature.

2. Pairing with Your Device

The Lucifer T4 earbuds utilize advanced Bluetooth 5.2 technology for a stable and fast connection.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, PC, Switch, etc.), enable Bluetooth and search for "Black Shark Lucifer T4" in the list of available devices.
3. Select "Black Shark Lucifer T4" to connect. Once connected, a voice prompt will confirm successful pairing.

Note: For Nintendo Switch, ensure your system is updated to the latest version for optimal compatibility.



Image: The Black Shark Lucifer T4 earbuds shown with a variety of compatible devices, highlighting their wide Bluetooth 5.2 compatibility.

3. Finding Your Fit

For optimal comfort, stability, and sound quality, choose the ear tip size that best fits your ears. Three soft silicone ear tip sizes are included.

1. Select the ear tips that provide a snug yet comfortable seal in your ear canal.
2. Gently insert each earbud into your ear, twisting downward until they fit securely.



Image: An illustration demonstrating the correct way to insert the Lucifer T4 earbuds and the different ear tip sizes available for a customized fit.

Operating the Earbuds

Touch Controls

The Lucifer T4 earbuds feature intuitive touch controls on each earbud. The following table outlines the functions:

Action	Function
Triple tap Right earbud	Switch between Gaming / Music Mode
Double tap L/R earbud	Play / Pause
Single tap Right earbud	Volume Up
Single tap Left earbud	Volume Down
Hold Left earbud for 2 seconds	Previous Track
Hold Right earbud for 2 seconds	Next Track
Double tap L/R earbud	Answer / End Call
Triple tap Left earbud	Voice Assistant




Image: A visual guide to the touch controls on the Black Shark Lucifer T4 earbuds, showing various tap and hold functions.

Gaming Mode (35ms Ultra-Low Latency)

Activate Gaming Mode for a highly synchronized audio experience, crucial for competitive gaming. This mode reduces audio latency to an ultra-low 35ms, ensuring that sound effects and dialogue are perfectly in sync with on-screen action.

Your browser does not support the video tag.

Video: This video demonstrates the significant difference in audio latency between the Black Shark Lucifer T4 earbuds in Gaming Mode (35ms) and regular wireless earbuds (200ms), showcasing the improved synchronization for gaming.



Image: The Black Shark Lucifer T4 earbuds highlighting their 35ms ultra-low latency Gaming Mode, designed for synchronized gaming experiences.

Music Mode (Studio-Quality Sound)

Switch to Music Mode to enjoy powerful, deep bass and clear treble. The 6mm dynamic drivers deliver a well-balanced sound quality, enriching your audio journey for music listening.




Image: The Black Shark Lucifer T4 earbuds emphasizing their in-ear studio performance, with expertly-tuned 6mm dynamic drivers for enhanced bass and clear sound.

Maintenance

Water Resistance (IPX5)

The Lucifer T4 earbuds are IPX5 water-resistant, meaning they are protected against low-pressure water jets from any

direction. This makes them suitable for workouts and light rain. However, they are not designed for submersion in water.

- Do not submerge the earbuds in water.
- Wipe the earbuds dry with a soft cloth after exposure to sweat or rain.
- Ensure the charging port is dry before charging.




Image: The Black Shark Lucifer T4 earbuds shown in a wet environment, illustrating their IPX5 water resistance for protection against sweat and rain.

Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Gently clean the charging contacts on both the earbuds and the case with a dry cotton swab.

Troubleshooting

If you encounter any issues with your Black Shark Lucifer T4 earbuds, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget the device in Bluetooth settings and re-pair.
No sound from one earbud	Place both earbuds back in the case, close the lid, wait a few seconds, then take them out again. Check device audio balance settings.
Low volume or poor sound quality	Clean ear tips and earbud mesh. Ensure ear tips provide a good seal. Adjust volume on both earbuds and connected device.
Earbuds not charging	Ensure charging cable is securely connected. Clean charging contacts on earbuds and case. Try a different USB-C cable or power source.
Latency issues (even in Gaming Mode)	Ensure Gaming Mode is activated (triple tap Right earbud). Reduce distance between earbuds and device. Minimize interference from other wireless devices.

For further assistance, please refer to the official Black Shark support resources or contact customer service.

Specifications

Feature	Detail
Model Name	Black Shark Lucifer T4
Connectivity Technology	Wireless (Bluetooth 5.2)
Bluetooth Version	5.2
Bluetooth Range	10 Meters
Audio Latency	35 Milliseconds (Gaming Mode)
Audio Driver Size	6 Millimeters
Battery Life (Earbuds)	Up to 6 Hours
Total Listening Time (with Case)	Up to 24 Hours
Water Resistance Level	IPX5 (Waterproof)

Feature	Detail
Microphones	Built-in ultra-clear mics in each earbud
Control Type	Media Control (Touch)
Charging Port	USB-C
Material	Plastic
Item Weight	0.12 Kilograms (4.2 ounces)
Frequency Range	20 Hz - 20,000 Hz

Warranty and Support

Black Shark products come with a limited warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Black Shark website.
For technical support, troubleshooting, or any other inquiries, please contact Black Shark customer service through their official channels. You can also find additional resources and FAQs on the Black Shark support page.
A digital version of this user manual is available for download at:Black Shark Lucifer T4 User Manual (PDF)

© 2024 Black Shark. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09Q88ZJ7N

More documents and user manuals: **https://manuals.plus/**