GYMAX CA-GM1249

GYMAX Beach Chairs & Table Set User Manual

Model: CA-GM1249 | Brand: GYMAX

1. Important Safety Information

Please read and understand all instructions before using the product. Failure to follow these instructions may result in injury or product damage.

- Always use the chair and table in accordance with the manufacturer's instructions.
- Be cautious when adjusting the position or folding the chair and table to prevent pinching or injury.
- Keep the chair and table on a stable, level surface to prevent tipping.
- Do not exceed the maximum weight capacity of the folding table, which is 22 pounds.
- Ensure the chair's backrest locking mechanism is fully engaged before use.
- Avoid prolonged exposure to direct sunlight when not in use to preserve material integrity.

2. Product Overview

The GYMAX Beach Chairs and Folding Tanning Lounge Chairs with Table Set offers a comfortable and portable solution for outdoor relaxation. This set includes two adjustable lounge chairs and a compact folding table, designed for various outdoor activities.

Key Features:

- **5 Adjustable Positions:** Allows for versatile use, from sitting upright to fully reclining.
- **Foldable & Portable Design:** Both chairs and table fold compactly for easy transport and storage. Chairs include shoulder straps.
- **Integrated Storage:** Each lounge chair features a large zippered storage bag for personal items.
- **Durable Construction:** Made with thickened oxford fabric (soft, breathable, waterproof, easy-to-dry) and a heavy-duty aluminum frame.
- **Versatile Use:** Ideal for beaches, parks, backyards, gardens, poolside, and camping.




Figure 2.1: Overview of the GYMAX Beach Chairs and Table Set.



Figure 2.2: Close-up of the comfortable padded headrest, large zippered storage bag, and folding table.

3. Setup and Assembly

The GYMAX Beach Chairs and Table Set is designed for quick and easy setup. No complex assembly is required.

3.1 Unfolding the Lounge Chairs:

1. Place the folded chair on a flat, stable surface.
2. Gently unfold the chair by extending the main body and the backrest support frame.
3. Ensure the backrest support frame clicks into the desired position.

3.2 Setting Up the Folding Table:

1. Remove the folding table from its carry bag.
2. Unfold the table legs until they lock into place, forming a stable base.
3. Place the table on a flat surface next to your lounge chair.

Video 3.1: Demonstration of unfolding and setting up the beach chairs and table. This video illustrates the ease of deployment and adjustment for optimal comfort.



Figure 3.2: The chairs and table are designed to be lightweight and portable, making them easy to transport and store.

4. Operation

4.1 Adjusting the Backrest Positions:

The lounge chairs feature a 5-position adjustable locking system, allowing you to customize your seating angle for various activities.

1. To adjust, slightly lift the backrest to disengage the current locking position.
2. Move the backrest to your desired angle.
3. Lower the backrest until the support bar securely engages in one of the five notches. Ensure it is fully locked before leaning back.



Figure 4.1: The chair offers 5 adjustable positions for napping, sunbathing, or reading.

4.2 Using the Storage Bag:

Each lounge chair is equipped with a large zippered storage bag located on the backrest. This bag is designed to hold small personal belongings.

- Unzip the bag to store items such as sunglasses, books, phones, or car keys.
- Zip the bag closed to secure your belongings.

4.3 Using the Folding Table:

The included folding table provides a convenient surface for drinks, snacks, or other small items.

- Place the unfolded table on a stable, flat surface between or beside the chairs.
- Do not place items heavier than 22 lbs (10 kg) on the table.

5. Care and Maintenance

Proper care and maintenance will extend the lifespan of your GYMAX Beach Chairs and Table Set.

- **Cleaning:** Wipe clean with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Ensure the fabric is completely dry before folding and storing to prevent mildew.
- **Storage:** When not in use, fold the chairs and table and store them in a cool, dry place, away from direct sunlight and extreme weather conditions. Use the provided carry bag for the table to protect it during storage and transport.
- **Inspection:** Periodically check all components, including the frame, fabric, and locking mechanisms, for any signs of wear or damage. Do not use if damaged.

6. Troubleshooting

If you encounter any issues with your product, please refer to the following common solutions:

- **Chair not locking into position:** Ensure the backrest support bar is properly aligned with the notches. Apply gentle pressure to engage the lock. Check for any obstructions.
- **Difficulty folding/unfolding:** Ensure no fabric or debris is caught in the hinges. Apply even pressure when folding or unfolding.
- **Stability issues:** Verify that the chair and table are placed on a flat, even surface. Ensure all legs and support frames are fully extended and locked.

If the problem persists, please contact customer support for further assistance.

7. Specifications

Attribute	Detail
Brand	GYMAX
Model Name	Floor Lounge Chair Set
Item Model Number	CA-GM1249
Color	Blue Stripe
Product Dimensions (Chair)	60"D x 22"W x 18.5"H
Seat Depth	22 inches
Chair Backrest Width	22 Inches
Item Weight	11 pounds (total set)
Maximum Weight Recommendation (Table)	22 Pounds
Reclining Position Count	5
Material	Thickened Oxford Fabric, Heavy-Duty Aluminum Frame
Included Components	2 Folding Lounge Chairs, 1 Folding Table, 1 Carry Bag
Indoor/Outdoor Usage	Outdoor
Is Foldable	Yes




Figure 7.1: Detailed dimensions of the lounge chair and table.

8. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact GYMAX customer service directly. Keep your purchase receipt for warranty claims.

Customer Service: Please visit the official GYMAX website or contact your retailer for support.

© 2024 GYMAX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question