

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [HOTO](#) /
- > [HOTO Portable Tire Inflator User Manual](#)

HOTO CQB001

HOTO Portable Tire Inflator

MODEL: CQB001



Introduction

The HOTO Portable Tire Inflator is a versatile and compact device designed for quick and precise inflation of various items, including car, motorcycle, and bicycle tires, as well as sports balls. Equipped with a digital pressure gauge and multiple intelligent modes, it ensures accurate inflation and automatic shut-off to prevent overinflation. Its portable design and built-in LED light make it an essential tool for emergencies and everyday use.



Image: The HOTO Portable Tire Inflator shown with its various inflation accessories, including different nozzles and a charging cable.

Package Contents

Please ensure all items listed below are present in your package:

- 1 x HOTO Portable Tire Inflator
- 1 x American Air Tube (Air Tube + American Air Valve)
- 1 x USB Type-C Charging Cable
- 1 x Storage Pouch
- 1 x Presta Valve Adapter
- 1 x Needle Valve Adapter (for balls)

- 1 x Conversion Air Valve



Image: A visual representation of all components included in the HOTO Portable Tire Inflator package.

Setup

1. **Initial Charging:** Before first use, fully charge the inflator using the provided USB Type-C cable. Connect the cable to the Type-C port on the device and a compatible USB power source. The battery indicator on the display will show charging status.
2. **Attach Air Hose:** Screw the air hose securely into the inflation port at the top of the device.
3. **Select Appropriate Nozzle:** Depending on the item you wish to inflate, select the correct adapter (Presta valve, needle valve, or conversion air valve) and attach it to the end of the air hose.

2*2500mAh High-capacity Battery



Fully charged in 3.5 hours, it can inflate 6.8 tires* from 28-35psi
*205/55 R16



Image: Internal view highlighting the 2500 mAh high-capacity battery.

Comprehensive Inflation Accessories

GOOD DESIGN
AWARD 2022

1. Versatile Inflation Accessories
2. 2 Pressure Reading Unit
3. Rotational Adjustment
4. Integrate LED Light
5. Soft Rober Handle



Image: The inflator with its various accessories, including the USB-C cable and different nozzles.

Operating Instructions

1. **Power On:** Press and hold the power button (located on the side) for approximately 3 seconds to turn on the device. The digital display will illuminate.
2. **Select Mode:** Short press the knob button to cycle through the preset inflation modes: Car, Motorcycle, Bike, Ball, and Custom.

3. **Set Pressure:**

- For preset modes, the recommended pressure will be displayed. You can adjust this value by spinning the knob.
- For Custom mode, spin the knob to set your desired pressure value. The maximum pressure is 150 PSI.

4. **Connect to Item:** Securely attach the air hose (with the appropriate nozzle) to the valve of the item you wish to inflate.

5. **Start Inflation:** Once the desired pressure is set and the hose is connected, press the knob button to begin inflation. The device will automatically stop when it reaches the preset pressure.

6. **Change Pressure Unit:** To switch between PSI and Bar, press and hold the adjustment button (knob) for about 3 seconds.

7. **Use LED Light:** Press the light button (next to the power button) to turn on the LED emergency light for use in dimly lit environments. Press again to turn off.

Multifunctional Cordless Tire Inflator



4 Preset Modes: Car/Motorcycle/Bike/Ball Mode



Car Mode

Pressure Range: 28~35psi
Time: 2'25"



Motorbike Mode

Pressure Range: 28~33psi
Time: 26"



Bike Mode

Pressure Range: 35~45psi
Time: 41"



Ball Mode

Pressure Range: 6-8psi
Time: 7"



Custom Mode

Default: 35psi
Range: 3-120psi



Image: Display illustrating the various preset modes for different inflation needs.

Easy to Use

 GOOD DESIGN
AWARD 2022



1. Press and Hold

The  button to turn on.



2. Spin to Select

Short press knob button to switch preset mode, spin button to adjust pressure value in custom mode.



3. Press to Start

Then, kick back, relax, and watch as it pumps with precision!

Image: Visual guide on how to operate the inflator: Press and Hold, Spin to Select, Press to Start.

**Compact, Lightweight
Easy to carry**



Image: Close-up of the rotational knob for easy pressure adjustment.



Image: The inflator in use, demonstrating its automatic stop feature when the preset pressure is reached.

Official Product Videos:

Your browser does not support the video tag.

Video: "HOTO Portable Tire Inflator - Innovative design" - This video showcases the sleek design and key features of the HOTO Portable Tire Inflator.

Your browser does not support the video tag.

Video: "5 Modes - Car, bike, Motorbike, Electric hoverboard, ball.." - This video demonstrates the various inflation modes available for different types of items.

Your browser does not support the video tag.

Video: "HOTO Electric Air Compressor" - A general overview video highlighting the functionality and ease of use of the electric air compressor.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the inflator in a cool, dry place, away from direct sunlight and extreme temperatures. Use the provided storage pouch to protect it from dust and scratches.
- **Battery Care:** To prolong battery life, charge the device regularly, even if not in frequent use. Avoid completely draining the battery before recharging.

- **Hose and Nozzle Inspection:** Periodically check the air hose and nozzles for any signs of wear, cracks, or damage. Replace if necessary to ensure optimal performance and safety.



Package Instruction

- ① American Air Tube (Air Tube + American Air Valve)
- ② Air Pump
- ③ Type-C Charging Cable
- ④ Storage Pouch
- ⑤ Adapting Valve
- ⑥ Needle Valve Adapter
- ⑦ Presta Valve

Image: Internal view illustrating the cooling system designed for heat dissipation.




Image: Close-up of the soft rubber handle, emphasizing portability and ease of carrying.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; Power button not pressed correctly.	Charge the device fully. Press and hold the power button for 3 seconds.
Inflator stops prematurely.	Preset pressure reached; Hose connection loose.	Check the preset pressure. Ensure the hose is securely attached to both the inflator and the item.
Inflation is slow or weak.	Low battery; Hose or nozzle obstruction.	Recharge the device. Check hose and nozzles for blockages.
Display not working.	Device off; Malfunction.	Ensure the device is powered on. If issue persists, contact customer support.

Specifications

Feature	Detail
Brand	HOTO
Model Name	Tire Inflator (CQB001)
Color	Black
Material	Plastic
Product Dimensions	6.2"L x 4.5"W x 1.7"H
Power Source	Battery Powered
Maximum Pressure	150 PSI
Operation Mode	Automatic
Battery Capacity	2500 mAh (x2, 7.2V)
Charging Port	USB Type-C
Accuracy	0.1-bar accurate digital tire pressure measuring

Warranty and Support

For detailed warranty information and customer support, please refer to the official HOTO website or the user manual PDF provided with your product.

You can also download the full user manual in PDF format here [HOTO Portable Tire Inflator User Manual \(PDF\)](#)