



Manuals.plus /

› Funko /

› Funko Pop! Ride: Pilot Mickey Mouse in Walt's Plane 'The Mouse' (Model 66375) Instruction Manual

Funko 66375

Funko Pop! Ride: Pilot Mickey Mouse in Walt's Plane 'The Mouse' Instruction Manual

Model: 66375

[Information](#) [Setup](#) [Operating](#) [Introduction](#) [Safety](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential information for the Funko Pop! Ride collectible figure, featuring Pilot Mickey Mouse in Walt Disney's personal plane, 'The Mouse'. This vinyl figure is designed for display and collection. Please read this manual thoroughly to ensure proper handling and care of your collectible.

1.1. Product Overview

The Funko Pop! Ride collectible captures Pilot Mickey Mouse seated in a stylized representation of Walt Disney's iconic plane, 'The Mouse'. The design is inspired by the original 'I Flew on the 'Mouse'' certificate, making it a unique addition to any collection.



Image 1.1: The Funko Pop! Ride collectible figure, Pilot Mickey Mouse in Walt's Plane 'The Mouse', shown within its original packaging.

1.2. What's in the Box

- One (1) Funko Pop! Ride: Pilot Mickey Mouse in Walt's Plane 'The Mouse' collectible figure.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - SMALL PARTS. This product contains small parts and is not suitable for children under 3 years of age. Adult supervision is recommended for all users, especially those under the manufacturer's recommended age of 6 years and up. Keep away from pets.

3. SETUP

The Funko Pop! Ride figure is designed for immediate display. No assembly is required.

3.1. Unboxing

1. Carefully remove the figure from its packaging. Retain the packaging for future storage or reference, if desired.
2. Inspect the figure for any manufacturing defects or damage.



Image 3.1: The collectible figure removed from its packaging, ready for display.

3.2. Placement

Place the figure on a stable, flat surface away from direct sunlight, extreme temperatures, and high humidity to preserve its condition. Avoid placing it near edges where it could fall and sustain damage.

4. OPERATING

This product is a static collectible figure and does not require any operational procedures. It is intended for display purposes only.

4.1. Display Considerations

- Ensure the display area is clean and free of dust.
 - Handle the figure by its base or main body to avoid damaging smaller details.
 - Avoid dropping or subjecting the figure to impact, as this may cause breakage.
-

5. MAINTENANCE

Proper maintenance will help preserve the appearance and longevity of your collectible figure.

5.1. Cleaning

- To clean the figure, gently wipe it with a soft, dry, lint-free cloth.
- For stubborn dust or smudges, lightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the paint or material.
- Do not submerge the figure in water.

6. TROUBLESHOOTING

This section addresses common concerns regarding collectible figures.

6.1. Common Issues and Solutions

Issue	Possible Cause	Solution
Figure appears dusty	Exposure to air and environmental particles.	Gently wipe with a soft, dry cloth.
Minor scuffs or marks	Accidental contact during handling or display.	For minor marks, a very lightly dampened cloth may help. Avoid rubbing vigorously.
Figure is unstable	Uneven display surface or improper placement.	Ensure the figure is on a flat, level surface. Adjust its position if necessary.

If you encounter significant damage or defects upon unboxing, please refer to the warranty and support section for assistance.

7. SPECIFICATIONS

- **Product Name:** Funko Pop! Ride: Pilot Mickey Mouse in Walt's Plane 'The Mouse'
- **Brand:** Funko
- **Model Number:** 66375
- **Product Dimensions:** 6.5 x 5.5 x 8 inches (approximately)
- **Item Weight:** 1.3 pounds (approximately)
- **Material:** Vinyl
- **Manufacturer Recommended Age:** 6 years and up
- **Release Date:** October 5, 2022

Funko

PRODUCT SIZING

(ALL HEIGHTS ARE APPROXIMATE)




Image 7.1: A visual guide illustrating the approximate sizing of a Pop! Ride figure compared to a standard Pop! figure.

8. WARRANTY & SUPPORT

8.1. Warranty Information

Funko products are typically covered by a limited warranty against manufacturing defects. For specific warranty terms and conditions, please refer to the official Funko website or contact their customer service directly. Proof of purchase may be required for any warranty claims.

8.2. Customer Support

For further assistance, questions, or to report any issues with your Funko Pop! Ride figure, please contact Funko customer support through their official channels. You can typically find contact information on the Funko website (www.funko.com) or on the product packaging.