

[Manuals.plus](#) /

› [Electrolux](#) /

› Electrolux PureA9.2 Air Purifier EP71-76GYA Instruction Manual

Electrolux EP71-76GYA

Electrolux PureA9.2 Air Purifier EP71-76GYA Instruction Manual

Model: EP71-76GYA | Brand: Electrolux

1. INTRODUCTION

Thank you for choosing the Electrolux PureA9.2 Air Purifier. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read it thoroughly before use and keep it for future reference.

2. SAFETY INFORMATION

- Always ensure the power cord is securely plugged into a grounded outlet.
- Do not operate the appliance with a damaged cord or plug.
- Keep the air purifier away from water or other liquids.
- Do not insert objects into the air inlets or outlets.
- Unplug the appliance before cleaning or performing any maintenance.
- This appliance is for indoor use only.
- Keep out of reach of children and pets.

3. PRODUCT OVERVIEW

Key Features:

- **PureSense System:** Real-time indoor air quality measurement and automatic adjustment in Smart Mode.
- **AirSurround System:** Creates a spiral airflow to efficiently circulate air throughout the room.
- **360° Air Intake:** Pentagonal design with a cylindrical HEPA filter for comprehensive air purification.
- **Advanced Filtration:** Captures dust, pollen, PM2.5, and household odors.
- **RFID Filter Tag:** Monitors filter life for timely replacement.
- **Quiet Operation:** Operates almost unnoticed at its lowest fan speed (18 dB).

- **App Control:** Dedicated smartphone application for remote monitoring and control (Wi-Fi 2.4GHz only).
- **Nordic Design:** Aesthetic design with fabric and leather-like handles.

Product Components:

The Electrolux PureA9.2 Air Purifier consists of the main unit, a cylindrical filter (pre-installed), and a power cord. Optional accessories may include different colored handles or additional filters.



Figure 3.1: Electrolux PureA9.2 Air Purifier main unit.



広いスペースに



日本マーケティングリサーチ機構調べ
調査概要:2021年12月期 ブランドのイメージ調査

子供、赤ちゃんのいる家庭が
置きたい空気清浄機※



日本マーケティングリサーチ機構調べ
調査概要:2021年12月期 ブランドのイメージ調査

ホテル・レストラン業界関係者が
選ぶ空気清浄機※



Figure 3.2: The Electrolux PureA9.2 Air Purifier blends seamlessly into various home environments, suitable for large spaces like living rooms or offices.

Pure9.2の4つの特徴

ウイルス・花粉除去率

99.9%

細菌・PM2.5を99%除去
ペット・煙草臭や有害ガスにも対応

子供、赤ちゃんのいる家庭が
おきたい空気清浄機[※]

No.1

ホテル・レストラン業界関係者が
選ぶ空気清浄機[※]

ファンスピード

9 段階

マニュアルモードでは、お好みの
スピードに合わせて9段階で
ファンスピードの切り替えが可能

最大運転音(dB)

18 dB

稼働していることに
気づかないほどの静けさ

[※]日本マーケティングリサーチ機構調べ 調査概要:2021年12月期 ブランドのイメージ調査

Figure 3.3: Overview of the PureA9.2's core features, including high purification efficiency, quiet operation, and multiple fan speeds.

4. SETUP

4.1 Unpacking

1. Carefully remove the air purifier from its packaging.
2. Remove all protective materials and plastic bags.
3. Check that all components are present and undamaged.

4.2 Filter Installation

The cylindrical filter is typically pre-installed. If not, or if replacing, follow these steps:

1. Ensure the appliance is unplugged.
2. Locate the filter compartment (usually at the bottom or by rotating the top section).
3. Insert the cylindrical filter, ensuring it is seated correctly.
4. Close the filter compartment securely.

4.3 Placement

- Place the air purifier on a flat, stable surface.
- Ensure there is adequate space (at least 30 cm) around the unit for optimal airflow.
- Avoid placing it near heat sources, direct sunlight, or in damp environments.

4.4 Power Connection

Plug the power cord into a suitable electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- Press the power button on the top panel to turn the unit on or off.

5.2 Operating Modes

The PureA9.2 offers two main operating modes:

- **Smart Mode:** The PureSense system automatically detects air quality and adjusts fan speed accordingly. The air quality light changes color (Red > Orange > Green > Blue) to indicate air cleanliness.
- **Manual Mode:** Allows you to manually select one of 9 fan speeds.

5.3 Air Quality Indicator Light

The air quality light on the top panel provides a visual indication of the current air quality:

- **Red:** Heavily polluted air.
- **Orange:** Moderately polluted air.
- **Green:** Slightly polluted air.
- **Blue:** Clean air.

Video 5.1: Official product video demonstrating the air purification speed and the air quality indicator light changing colors based on air cleanliness.

5.4 Smartphone App Control

Download the dedicated Electrolux app to your smartphone for advanced control and monitoring:

- Monitor indoor air quality in real-time.
- Switch between Smart and Manual modes.
- Adjust fan speed (9 levels).
- Turn the unit on/off remotely.
- Check filter usage and remaining life.

Note: The app requires a 2.4GHz Wi-Fi connection.

6. MAINTENANCE

6.1 Cleaning the Exterior

- Wipe the exterior of the unit with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.

6.2 Filter Replacement

The filter life is monitored by an RFID tag. Replace the filter when indicated by the appliance or the app.

1. Unplug the air purifier from the power outlet.
2. Open the filter compartment.
3. Remove the old filter and dispose of it properly.
4. Insert a new genuine Electrolux filter, ensuring it clicks into place.
5. Close the filter compartment.
6. Plug in the appliance and reset the filter indicator if necessary (refer to app instructions).

空気中のウイルス・殺菌・カビを99%除去 5ステップでお部屋の空気をキレイに



イオナイザー^{※2}を含む5ステップで、空気中のウイルス^{※3}、細菌^{※3}、カビ^{※4}を99%除去し、お部屋にキレイで新鮮な空気を届けます。

※2 空気清浄機の上部にある装置から空気中へイオンを拡散するものであり、物理的フィルターではありません。イオナイザーは、専用のアプリでオン/オフが可能です。

※3 Guangdong Detection Center of Microbiology (GDDCM)にてJEM1467の附属書Dの試験方法を参考にして30㎡の試験空間で行った除去性能評価試験結果(試験実施日:2021年11月)に基づく。すべてのウイルスに対応するわけではありません。30㎡の密閉した試験空間による約90分後の浮ウイルスへの効果であり、実使用空間での実証結果ではありません。

※4 Guangdong Detection Center of Microbiology (GDDCM)にてJEM1467の附属書Dの試験方法を参考にして30㎡の試験空間で行った除去性能評価試験結果(試験実施日:2021年10月)に基づく。すべての細菌やカビに対応するわけではありません。30㎡の密閉した試験空間による約90分の浮遊細菌、浮遊カビへの効果であり、実使用空間での実証結果ではありません。

Figure 6.1: The 5-step filtration system, including mesh, antibacterial, HEPA, activated carbon, and ionizer layers, ensures thorough air purification.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on	No power; Power cord not connected; Filter not installed correctly.	Check power outlet; Ensure power cord is firmly plugged in; Reinstall filter correctly.
Poor air purification performance	Filter is dirty or expired; Air inlets/outlets are blocked.	Replace the filter; Clear any obstructions from air inlets/outlets.
Unusual noise	Foreign object inside; Unit not on a stable surface.	Unplug and check for foreign objects; Place on a stable, flat surface.
App not connecting	Incorrect Wi-Fi band (only 2.4GHz supported); Poor Wi-Fi signal; App not updated.	Ensure router is on 2.4GHz; Move unit closer to router; Update app to latest version.

8. SPECIFICATIONS

Feature	Detail
Brand	Electrolux
Model Number	EP71-76GYA
Color	Gray
Applicable Area	Up to 58 Tatami (approx. 96 m ²)
Product Dimensions (D x W x H)	31.5 cm x 31.5 cm x 75 cm
Product Weight	8.9 kg
Noise Level (Max)	52 dB
Power Source	Corded Electric
Special Features	PM2.5 compatible, App Control, PureSense System, AirSurround System
Maintenance	Filter replacement





Figure 8.1: Product dimensions of the Electrolux PureA9.2 Air Purifier.



他商品との比較

	Pure A9.2 58畳※1	Pure A9.2 43畳※1	Flow A3 UV	UltimateHome500 (加湿空気清浄機)
特徴	空気清浄機特化 モデル	空気清浄機特化 モデル	使用場所を選ば ない万能モデル	空気清浄 + 加湿機能モデル
推奨畳数(畳)※1	約58(96㎡)まで	約43(71㎡)まで	約15(25㎡)まで	約24(39.6㎡)まで
運転音(dB)※2	18～54※2	17～51※2	27～49.9※2	25～55※2
8畳の清浄時間(分)※3	約5.1※3	約6.9※3	約17.5※3	約12※3
ファンスピード	9段階	9段階	3段階	4段階
質量(kg)	8.9	7.9	2.8	9.6
除湿機能	—	—	—	—
加湿機能	—	—	—	○
キャスター	○	○	—	○

※1 第三者機関にて実施した日本電機工業会規格JEM1467に基づく試験結果(試験実施日:2021/10/18)より算出。
ご使用場所の状況や使い方により結果は異なります。

※2第三者機関にて実施した日本電機工業会規格JEM1467に基づく試験結果(試験実施:2021年10月9日)
音の感じ方は人によって異なります。
※3日本電機工業会規格JEM1467に基づき、第三者機関にて行った試験結果により算出。
ご使用場所の状況や使い方により結果は異なります。

Figure 8.2: A comparison table detailing specifications and features across various Electrolux air purifier models.

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Electrolux website. Keep your proof of purchase for warranty claims.

Online Resources: www.electrolux.com