

[Manuals.plus](#) /

> [ASUS](#) /

> ASUS Laptop L410MA-DS04 Ultra Thin Laptop User Manual

## ASUS L410MA-DS04

# ASUS Laptop L410MA-DS04 Ultra Thin Laptop User Manual

Model: L410MA-DS04

## 1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your ASUS Laptop L410MA-DS04. The ASUS Laptop L410MA is a compact and lightweight 14-inch laptop designed for productivity on the go. It features an Intel processor, long-lasting battery life, eMMC storage, and comes with Windows 11 in S mode.


## 2. PACKAGE CONTENTS

Verify that all items are present in your product package:

- ASUS Laptop L410MA-DS04
- Powercord & Adapter
- Warranty Card

## 3. PRODUCT OVERVIEW AND FEATURES

The ASUS Laptop L410MA-DS04 offers a range of features designed for efficiency and portability.



The ASUS Laptop L410, an ultra-thin laptop designed for portability and style.





Seamless integration with mobile devices for enhanced productivity.

## Key Features:

- **Efficient Intel Celeron N4020 Processor:** (4M Cache, up to 2.8 GHz) for reliable performance.
- **14" Full HD (1920x1080) Display:** Provides clear visuals.
- **128GB eMMC Flash Storage and 4GB DDR4 RAM:** Offers sufficient storage and memory for daily tasks.
- **Windows 11 in S mode:** A secure, app-based version of Windows. Includes One Year Microsoft 365 Personal.
- **Slim and Portable:** Measures 0.72" thin and weighs only 2.87 lbs (battery included).
- **Connectivity:** Features USB 3.2 Gen 1 Type-C, USB 3.2 Gen 1 Type-A, and HDMI ports.
- **Wi-Fi 5 (802.11ac):** For fast wireless internet speeds.
- **NumberPad:** Integrated numeric keypad on the touchpad for convenient data entry.

## 4. SETUP

---

1. **Unpack the Laptop:** Carefully remove the laptop and all accessories from the packaging.
2. **Connect Power:** Plug the AC adapter into the laptop's power port and then into a wall outlet. Allow the battery to charge fully before first use.
3. **Initial Boot:** Open the laptop lid. The laptop may power on automatically. If not, press the power button (usually located on the top right of the keyboard or side).
4. **Windows 11 S Mode Setup:** Follow the on-screen instructions to complete the initial Windows 11 S Mode setup. This includes selecting your region, connecting to Wi-Fi, and creating a user account.
5. **Microsoft 365 Personal Activation:** Your laptop includes a 1-year subscription to Microsoft 365 Personal. Follow the prompts during Windows setup or refer to the included documentation to activate your subscription.

## 5. OPERATING INSTRUCTIONS

---

### Power On/Off

- **To Power On:** Open the lid or press the power button.
- **To Shut Down:** Click the Start button, then Power > Shut down.
- **To Restart:** Click the Start button, then Power > Restart.
- **To Sleep:** Close the lid or click the Start button, then Power > Sleep.

## Using the NumberPad

The ASUS L410MA-DS04 features an innovative NumberPad integrated into the touchpad. To activate or deactivate the NumberPad, press and hold the 'ON/OFF' icon located on the top right corner of the touchpad. When activated, the touchpad functions as a numeric keypad for quick data entry. When deactivated, it reverts to a standard touchpad.

## Windows 11 in S Mode

Windows 11 in S mode is a version of Windows that is streamlined for security and performance, while providing a familiar Windows experience. In S mode, you can only install apps from the Microsoft Store, and you must use Microsoft Edge for safe browsing. If you need to install an app that is not available in the Microsoft Store, you can switch out of S mode for free. This switch is irreversible.

## Connecting Peripherals

- **USB Devices:** Connect USB devices such as external drives, mice, or keyboards to the available USB 3.2 Gen 1 Type-A or Type-C ports.
- **External Display:** Use the HDMI port to connect an external monitor or projector.
- **Audio:** Connect headphones or external speakers to the audio jack. The laptop also supports Bluetooth for wireless audio devices.
- **Wireless Connectivity:** Connect to Wi-Fi networks via Wi-Fi 5 (802.11ac) and pair Bluetooth devices using Bluetooth 5.1.

## 6. MAINTENANCE

---

### Cleaning

- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a screen cleaner. Do not spray liquid directly onto the screen.
- **Keyboard and Chassis:** Use a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used. Avoid harsh chemicals.

### Battery Care

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place if not used for extended periods.
- Periodically calibrate the battery (fully charge, then fully discharge, then fully recharge) to maintain accuracy.

### Software Updates

Regularly check for and install Windows updates to ensure your system has the latest security patches and performance improvements. You can find updates in Windows Settings > Windows Update.

## 7. TROUBLESHOOTING

---

### No Power / Won't Turn On

- Ensure the AC adapter is securely connected to both the laptop and a working power outlet.
- Check if the power outlet is functional by plugging in another device.
- If the battery is completely drained, it may take a few minutes of charging before the laptop can power

on.

## Display Issues

- If the screen is blank, try pressing the function keys (e.g., Fn + F7 or F8) to toggle the display output.
- Ensure external monitors are properly connected and powered on.

## Slow Performance

- Close unnecessary applications running in the background.
- Ensure your Windows operating system is up to date.
- Check for sufficient free storage space.

## Connectivity Problems (Wi-Fi/Bluetooth)

- Ensure Wi-Fi and Bluetooth are enabled in Windows Settings.
- Restart your router/modem for Wi-Fi issues.
- For Bluetooth, try unpairing and re-pairing the device.

## 8. SPECIFICATIONS

Feature	Specification
Brand	ASUS
Model Name	ASUS Laptop L410
Model Number	L410MA-DS04
Screen Size	14 Inches
Display Resolution Maximum	1920x1080 Pixels (Full HD)
CPU Model	Intel Celeron N4020
Processor Speed	2.8 GHz (Maximum)
RAM Memory Installed Size	4 GB DDR4
Hard Disk Size	128 GB eMMC (SSD)
Operating System	Windows 11 Home in S Mode
Graphics Coprocessor	Intel UHD Graphics 600
Item Weight	2.87 Pounds
Item Dimensions L x W x Thickness	12.8"L x 8.54"W x 0.71"Th
Wireless Technology	Wi-Fi 5 (802.11ac), Bluetooth 5.1
Total USB Ports	3 (USB 3.2 Gen 1 Type-C, USB 3.2 Gen 1 Type-A)
Total Number of HDMI Ports	1
Webcam Capability	Yes (VGA camera, 640x480 resolution)

## 9. WARRANTY AND SUPPORT

---

### Product Warranty

Your ASUS Laptop L410MA-DS04 comes with a **1-Year International Limited Warranty**. Additionally, it is eligible for 1-Year free Domestic Accidental Damage Protection (ADP) upon registration. This includes 1-way free shipping for ADP claims and 2-way free shipping for standard hardware warranty repairs.

Please refer to the included Warranty Card for detailed terms and conditions, and instructions on how to register for ADP.

### Microsoft 365 Personal

A 1-year subscription to Microsoft 365 Personal is included with your purchase. Activate it during the initial Windows setup or by following the instructions provided with your laptop.

### Customer Support

For technical assistance, warranty claims, or further support, please visit the official ASUS support website or contact their customer service. Details can be found on the Warranty Card or the ASUS website.