oneisall RFC-676

oneisall Dog Clippers User Manual

Brand: oneisall | Model: RFC-676

1. Product Overview

The oneisall Dog Clippers are engineered for efficient and comfortable grooming of pets, especially those with thick, heavy, or matted coats. Its robust stainless steel blade and high-speed motor ensure a smooth cutting experience, while the low-noise design minimizes stress for your pet. This cordless shaver offers convenience and flexibility for both indoor and outdoor use, complemented by its waterproof design for easy cleaning.



Figure 1: oneisall Dog Clippers, showing the device, various guide combs, and two dogs (Golden Retriever and Border Collie).

Key Features:

- **Powerful Stainless Steel Blade:** Specifically designed for thick and matted hair, providing a firmer, easier, and faster grooming experience compared to ceramic blades.
- **Low Noise & Low Vibration:** Operates at less than 55dB, ensuring a calm grooming session for your pet.
- **Long-lasting Battery:** 2000mAh high-capacity battery provides up to 240 minutes of continuous use after a 2-hour full charge via USB.
- **Cordless Design:** Offers maximum flexibility and ease of use without the restriction of a cord.

- **IPX7 Waterproof:** The entire body of the trimmer is washable for thorough and easy cleaning.
- **Smart Digital LCD Display:** Shows battery percentage, oil drip reminder, and security lock status.
- **10 Detachable Guide Combs:** Includes sizes from 3mm to 25mm (1/8in to 1in) for versatile grooming lengths.

2. Setup and Charging

Initial Charge:

Before first use, fully charge the clippers. Connect the USB charging cable to the clipper's charging port and plug it into a 5V/1A USB adapter or a power bank. The smart digital LCD display will show the charging progress. A full charge typically takes approximately 2 hours, providing up to 240 minutes of operating time.



Figure 2: The smart digital LCD display on the clippers indicates battery level, oil reminder, and security lock.

Safety Information:

- Only charge the hair clippers with the supplied adapter.
- Ensure the hair clippers and adapter remain dry during charging and operation.
- Keep out of reach of children.

3. Operating Instructions

Preparing for Grooming:

Ensure your pet's coat is clean, dry, and free of tangles before grooming. Brushing out loose hair and mats beforehand will improve the clippers' performance and prevent pulling.

Attaching Guide Combs:

Select the desired guide comb (from 3mm to 25mm) based on the desired hair length. Align the comb with the clipper blade and snap it into place securely. The clippers come with 10 different sizes of detachable combs to achieve various grooming styles.



Figure 3: Demonstrating the use of oneisall clippers with various guide comb sizes.

Powering On and Grooming:

Press the power button to turn on the clippers. The low noise and vibration design helps keep your pet calm during the process. Gently glide the clippers through the pet's coat in the direction of hair growth. The stainless steel blade is designed to cut through thick and matted fur with ease, reducing the possibility of pulling hair.



Figure 4: The clippers effectively grooming a dog with matted hair.



Figure 5: The low noise operation of the oneisall clippers helps reduce pet nervousness.



Figure 6: The clippers are effective for trimming thick coats, as shown by the groomed dogs and removed hair.

Security Lock Function:

The clippers feature a special locking function to prevent accidental activation. Long press the power button to activate or deactivate the security lock. The lock icon will appear on the LCD display when engaged.

4. Maintenance

Cleaning the Clippers:

Thanks to its IPX7 waterproof design, the entire body of the pet hair trimmer can be directly washed under running water. Use the special cleaning brush provided to remove any trapped hair from the blade and housing. Rinse thoroughly and wipe dry with a clean cloth.

Blade Maintenance:

Regular oiling of the blade is crucial for optimal performance and longevity. The LCD display will show an oil drip reminder when lubrication is needed. Apply a few drops of the included lubricating oil to the blades. **Note:** The stainless steel blade cannot be disassembled. Do not attempt to remove the blade.

5. Troubleshooting

Common Issues and Solutions:

- **Clippers not turning on:** Ensure the clippers are fully charged. Check if the security lock is engaged (indicated by a lock icon on the LCD display); long-press the power button to unlock.
- **Hair pulling or poor cutting performance:**
  - Clean the blade thoroughly to remove any trapped hair or debris.
  - Apply lubricating oil to the blade as indicated by the oil reminder.
  - Ensure the pet's coat is clean, dry, and detangled before grooming.
  - The blade is designed for thick coats; however, extremely dense or severely matted hair may require multiple passes or professional attention.
- **Battery not holding charge:** Ensure you are using the original USB charging cable and a 5V/1A adapter. If issues persist, the battery may need servicing.

If you encounter problems during the grooming process that cannot be resolved with the above steps, please contact oneisall customer support for assistance.

6. Specifications



Figure 7: Product dimensions and key specifications.

Feature	Detail
Model Name	RFC-676
Item Weight	11 ounces (311 Grams)
Product Dimensions (LxWxH)	7.28 x 2.28 x 1.69 inches
Blade Material	Stainless Steel

Battery Type	1 A battery (included)
Charging Time	Approx. 2 hours
Operating Time	Up to 240 minutes
Waterproof Rating	IPX7 (Whole body washable)
Noise Level	Less than 55dB
Included Components	Clippers, 10 Guide Combs, Cleaning Brush, Lubricating Oil, USB Charging Cable
Country of Origin	China

7. Warranty and Support

Product Warranty:

The oneisall Dog Clippers come with a 24-month product protection plan from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

Customer Support:

For any questions, concerns, or warranty claims, please contact oneisall customer service. Refer to the product packaging or the official oneisall website for the most current contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question