

[Manuals.plus](#) /

› [KPT](#) /

› KPT Electric Smoker Cover User Manual

KPT 42198

KPT Electric Smoker Cover User Manual

Model: 42198

PRODUCT OVERVIEW

The KPT Electric Smoker Cover is designed to provide comprehensive protection for your electric smoker or grill. Constructed from durable 500D Oxford fabric with a water-resistant coating, it offers protection against various outdoor elements including sun, snow, rain, and dirt.

This cover features adjustable Velcro straps at the bottom to ensure a secure fit and prevent displacement by wind. Its design prioritizes durability and ease of maintenance, making it suitable for year-round outdoor use.



Image: The KPT Electric Smoker Cover in black, fitted over an electric smoker, demonstrating its protective design.

SETUP AND INSTALLATION

1. **Preparation:** Ensure your electric smoker or grill is clean and dry before covering. Allow the smoker to cool completely if it has been in use.
2. **Unfold the Cover:** Carefully unfold the KPT Electric Smoker Cover.
3. **Positioning:** Place the cover over the top of your smoker, aligning it so that all sides are evenly covered.
4. **Secure the Cover:** Locate the two adjustable Velcro straps at the bottom of the cover. Fasten these straps securely around the base or legs of your smoker. This will help prevent the cover from being blown off by strong winds.

The cover is suitable for a variety of models

Product size (in)



★ Warm reminder: due to the reasonable error range of manual measurement



Image: A visual representation of the cover's dimensions (21.5"L x 21"W x 32.8"H) and examples of compatible smoker models, highlighting the universal fit.

OPERATING INSTRUCTIONS (USAGE)

The KPT Electric Smoker Cover is designed for passive protection. There are no active "operating" steps beyond proper placement and securing.

- **Daily Use:** For optimal protection, keep the cover on your smoker when it is not in use, especially during periods of inclement weather or prolonged storage.
- **Removal:** When you wish to use your smoker, simply unfasten the Velcro straps and lift the cover off. Fold it neatly for storage to prevent creases and prolong its lifespan.

SUITABLE FOR FOUR SEASONS



Effectively resist long-time
exposure



Effectively resist the invasion
of rainwater acidity



The Velcro is fixed at the
bottom to fit the product
better



Thick material to resist the
penetration of snowflakes


Image: A collage demonstrating the cover's effectiveness in different seasons, including protection from sun, rain, and snow, and the secure fit provided by the Velcro straps.

MAINTENANCE AND CARE

Proper maintenance will extend the life of your KPT Electric Smoker Cover.

- **Cleaning:** To clean the cover, simply wipe it down with a damp cloth. For more stubborn stains, a mild soap solution can be used. Rinse thoroughly with water.

- **Drying:** Allow the cover to air dry completely before folding and storing, especially if it has been exposed to rain or cleaning. This prevents mildew and odors.
- **Storage:** When not in use, fold the cover neatly and store it in a dry place away from direct sunlight. Its compact size allows for easy storage.
- **Inspection:** Periodically inspect the cover for any signs of wear, tear, or damage. While made from durable 500D Oxford fabric, extreme conditions over time may cause wear.



PREFERRED QUALITY VISIBLE




Image: Detailed views illustrating the quality of the cover's construction, including precise stitching and the hydrophobic properties of the fabric, showing water beading on the surface.

TROUBLESHOOTING

This section addresses common concerns regarding the smoker cover.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cover blows off in wind.	Velcro straps not secured or not tight enough.	Ensure both adjustable Velcro straps are tightly fastened around the base of the smoker.
Water pooling on top of cover.	Improper fit or sag in the cover.	Ensure the cover is pulled taut. If pooling persists, consider placing a small object (e.g., an inverted bucket) under the cover to create a peak and allow water to run off.
Cover appears dirty or stained.	Exposure to outdoor elements.	Clean the cover as per the "Maintenance and Care" section.

SPECIFICATIONS

Brand: KPT
Model Number: 42198
Material: 500D Oxford Polyester Canvas Fabric
Color: Black
Product Dimensions (L x W x H): 21.5" x 21" x 32.8" (54.6 cm x 53.3 cm x 83.3 cm)
Closure Type: Adjustable Velcro Straps
Item Weight: 1.54 pounds (0.7 kg)
UPC: 742686688133

WARRANTY AND SUPPORT

KPT is committed to customer satisfaction. Your KPT Electric Smoker Cover comes with the following support:

- Refund Policy:** Unconditional refund within 30 days of purchase.
- Service Warranty:** 12-month service warranty from the date of purchase.
- Customer Service:** If you encounter any problems with the use of your electric smoking cover, please contact KPT customer service for satisfactory after-sales support.

For assistance, please refer to the contact information provided with your purchase or on the official KPT product page.

© 2024 KPT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09QFXSK6G>

More documents and user manuals: <https://manuals.plus/>