

[Manuals.plus](#) /

› [DECAKILA](#) /

› DECAKILA Portable Blender KMJB012P Instruction Manual

DECAKILA KMJB012P

DECAKILA Portable Blender KMJB012P Instruction Manual

Model: KMJB012P

1. PRODUCT OVERVIEW

The DECAKILA Portable Blender KMJB012P is a compact, USB rechargeable personal blender designed for preparing milkshakes, smoothies, fruit and vegetable juices, and baby food. Its cordless design allows for use in various settings such as home, office, sports, outdoor activities, and travel.

Key features include:

- Cordless and portable design for versatile use.
- BPA-free food-grade materials.
- Powerful 3.4V motor and SUS304 stainless steel blades.
- Non-slip cup cover.
- Integrated safety features: power failure protection, overload protection, built-in magnetic safety switch, and a double-click start button to prevent accidental activation.
- Built-in 2400mAh rechargeable battery, providing approximately 10 cups of juice on a full charge (2-hour charging time).
- Easy to use with a double-click start mechanism and simple cleaning process.
- Lightweight (0.98 lbs) and compact with a 10oz/300ml capacity.



Image 1.1: The DECAKILA Portable Blender shown with examples of blended fruit drinks.

2. PRODUCT COMPONENTS

Familiarize yourself with the main components of your DECAKILA Portable Blender:

- **Blender Base:** Contains the motor, battery, control button, and charging port.
- **Blades:** Four SUS304 stainless steel blades integrated into the blender base.
- **Blender Cup:** 10oz/300ml capacity, made from high-quality PCTG material.
- **Non-slip Silicone Sleeve:** Provides a secure grip around the blender cup.
- **Cup Cover:** Non-slip design.

- **USB Magnetic Charging Cable:** For recharging the blender.



Image 2.1: Detailed view of the blender's components, including the ON/OFF button, charging port, 4 stainless steel blades, food-grade ABS base, non-slip silicone, and high-quality PCTG cup material.

3. SETUP AND FIRST USE

Before first use, ensure the blender is fully charged. Refer to the "Charging the Blender" section for instructions.

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the blender cup and lid with warm soapy water. Rinse thoroughly and dry. The blender base containing the motor and blades should be wiped clean with a damp cloth, ensuring no water enters the charging port.
3. **Assemble:** Ensure the blender cup is securely attached to the blender base.

4. OPERATING INSTRUCTIONS

Follow these steps to prepare your beverages:

1. **Prepare Ingredients:** Wash your fruits or vegetables and cut them into small, appropriate-sized pieces (approximately 1 inch or 2.5 cm).

2. **Add Ingredients:** Place the cut ingredients into the blender cup. Add water, milk, or other liquids. Do not exceed 80% of the cup's capacity to prevent overfilling.
3. **Secure Lid:** Ensure the blender base (with blades) is securely screwed onto the cup.
4. **Start Blending:** Invert the blender (flip the cup over so the base is at the bottom) and double-click the power button located on the blender base to start the blending cycle.
5. **Blend Cycle:** The blender will operate for approximately 40 seconds and then automatically stop. For thicker mixtures or desired consistency, you may gently shake the blender during operation.
6. **Enjoy:** Once blending is complete, open the blender and pour your fresh juice or smoothie.



Step 1: Wash the fruit and cut it into appropriate size pieces



Step 2: Put the fruit and water in the juicer, about 80% of the capacity



Step 3: Flip the cup over and double click on the power



Step 4: Wait 40 seconds to drink fresh juice

Image 4.1: Step-by-step guide showing how to prepare ingredients, fill the cup, invert and double-click to start, and wait for 40 seconds to enjoy the blended drink.

Video Demonstration

Your browser does not support the video tag.

Video 4.1: This video demonstrates the preparation and blending process of the DECAKILA Portable Blender, including adding ingredients, starting the blender, and pouring the finished drink. It also highlights the smooth consistency achieved by the blender compared to a "normal" blender.

5. CHARGING THE BLENDER

The DECAKILA Portable Blender features a built-in 2400mAh rechargeable battery and uses a USB magnetic charging system.

1. **Connect:** Attach the magnetic end of the USB charging cable to the charging port on the blender base.
2. **Power Source:** Connect the USB-A end of the cable to any compatible USB power source, such as a laptop, power bank, USB wall charger, or car charger.
3. **Charging Indicator:** The indicator light on the blender base will illuminate to show charging status.
4. **Full Charge:** A full charge typically takes approximately two hours. Once fully charged, the blender can produce up to 10 cups of juice.



Image 5.1: The portable blender connected to a USB power source via its magnetic charging cable.

6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance ensure the longevity and hygiene of your blender.

1. **Quick Clean:** After each use, add a small amount of clean water and a drop of dish soap to the blender cup. Secure the base and double-click the power button to run a short blending cycle. This will clean the blades and interior of the cup.
2. **Thorough Clean:** For a more thorough cleaning, detach the blender cup from the base. Wash the cup and lid with warm soapy water using a brush if necessary. Rinse thoroughly.
3. **Base Cleaning:** Wipe the blender base with a damp cloth.**Do not immerse the blender base in water**, as this can damage the motor and electronic components. Ensure the charging port is dry before charging.
4. **Storage:** Store the blender in a clean, dry place when not in use.



Image 6.1: Demonstrates rinsing the blender blades for easy cleaning.

7. SAFETY INFORMATION

Please read and adhere to the following safety precautions to prevent injury or damage to the appliance:

- Always ensure the blender cup is securely attached to the base before operating.
- Do not operate the blender when empty.
- Keep hands and utensils out of the blender cup during operation.
- The blender features a double-click start mechanism and a magnetic safety switch to prevent accidental activation. Ensure the cup is properly aligned and secured for the blender to operate.
- Do not immerse the blender base in water or any other liquid.
- Keep out of reach of children.
- Do not attempt to blend hot liquids, as pressure buildup can cause injury.
- Do not overload the blender. Adhere to the 80% capacity guideline.
- If the blender stops unexpectedly, check for power failure protection or overload protection activation. Allow the unit to cool down before attempting to restart.
- Use only the provided USB charging cable.

8. TROUBLESHOOTING

If you encounter issues with your DECAKILA Portable Blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Blender does not start.	◦ Low battery. ◦ Cup not securely attached. ◦ Magnetic safety switch not engaged. ◦ Incorrect start procedure (not double-clicked).	◦ Charge the blender fully. ◦ Ensure the cup is twisted on tightly and correctly aligned with the base. ◦ Double-click the power button to start.
Blender stops during operation.	◦ Overload protection activated (too many ingredients, too large pieces, or too little liquid). ◦ Low battery.	◦ Reduce ingredients, cut into smaller pieces, or add more liquid. ◦ Charge the blender. ◦ Allow the motor to cool down for 15-20 minutes before restarting.
Leaking from the cup.	◦ Cup not securely attached. ◦ Seal ring improperly seated or damaged.	◦ Ensure the cup is tightly screwed onto the base. ◦ Check the seal ring for proper placement and any damage. Replace if necessary.
Charging light not working.	◦ Charging cable not properly connected. ◦ Faulty USB power source. ◦ Blender already fully charged.	◦ Reconnect the magnetic charging cable securely. ◦ Try a different USB power source. ◦ If fully charged, the light may turn off or change color.

9. SPECIFICATIONS

Feature	Detail
Brand	DECAKILA
Model Number	KMJB012P
Capacity	300 Milliliters (10oz)
Special Feature	Portable, USB Rechargeable
Power Source	Battery Powered
Voltage	3.7 Volts
Battery Capacity	2400mAh (approx.)
Charging Time	Approx. 2 hours
Blends per Charge	Approx. 10 cups
Number of Speeds	1

Feature	Detail
Material Type Free	BPA Free
Blade Material	Stainless Steel (SUS304)
Product Dimensions	3.35 x 3.35 x 7.28 inches
Item Weight	15.7 ounces (0.98 lbs)
Included Components	1 x Juicer (Blender), 1 x USB Charging Cable

10. WARRANTY AND SUPPORT

Specific warranty details for the DECAKILA Portable Blender KMJB012P are not provided in this manual. Please refer to the product packaging or the manufacturer's official website for warranty information.

For technical support, customer service, or inquiries regarding your product, please contact DECAKILA customer support through their official channels. Contact information can typically be found on the product packaging or the brand's website.