Costzon CL-G08

Costzon 8-in-1 Montessori Indoor Playground (Model CL-G08) Instruction Manual

Model: CL-G08

Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Costzon 8-in-1 Montessori Indoor Playground. This multi-functional play structure is designed for toddlers and children aged 3 years and older, offering a variety of activities including a slide, climbing rock, crawling ladder, climbing net, monkey bars, horizontal bar, drawing board, abacus game, and swing.
The playground is constructed from industrial-grade birch wood and beech wood, with polyester components, ensuring durability. It is designed to comply with ASTM/CPSIA safety standards. Parental supervision is required at all times during use.

Safety Information

- **Adult Supervision:** Always ensure children are supervised by an adult while playing on the indoor playground.
- **Age Recommendation:** Suitable for children aged 3 years and older.
- **Weight Capacity:** The overall weight capacity is 110 lbs. The swing has a separate weight capacity of 55 lbs. Do not exceed these limits.
- **Material Safety:** The product uses FSC-certified wood and is coated with a non-toxic, BPA-free finish.
- **Assembly:** Ensure all parts are correctly assembled and tightened before use. Regularly check for loose components.
- **Placement:** Place the playground on a flat, stable surface. Ensure adequate clear space around the structure to prevent collisions.
- **Inspection:** Periodically inspect the structure for any damage, splinters, or loose parts. All corners and edges are designed to be smooth and free of burrs; if any appear, address them immediately.

Setup Instructions

The Costzon 8-in-1 Montessori Indoor Playground requires assembly. The product is shipped in two packages. Please

ensure all components are present before beginning assembly. A screwdriver or drill may be required for tightening screws.

Your browser does not support the video tag.

Video: Costzon 8-in-1 Climbing Toys Installation Guide. This video demonstrates the step-by-step assembly process for the indoor playground.

General Assembly Steps:

1. Unpack all components and verify against the parts list provided in your packaging.
2. Follow the detailed instructions and diagrams in the included assembly manual.
3. Attach the main frame components using the provided hardware. Ensure all connections are secure.
4. Install the various play elements such as the slide, climbing net, monkey bars, and swing according to the instructions.
5. Confirm all screws and fasteners are tightly secured to prevent wobbling and ensure stability.



Image: Product dimensions for the Costzon 8-in-1 Montessori Indoor Playground, showing overall height, width, and length, as well as slide dimensions and weight capacities.

Operating Instructions

The Costzon 8-in-1 Montessori Indoor Playground offers multiple play configurations to engage children. Encourage children to explore each feature safely and under supervision.

Your browser does not support the video tag.

Video: Overview of the Costzon 8-in-1 Climbing Toys for Toddlers, showcasing various play activities.

Features and Usage:

- **Double-Sided Slide/Climbing Rock:** The reversible ramp can be used as a smooth slide or flipped over for a climbing rock wall. Ensure the ramp is securely attached in the desired position before use.
- **Climbing Net & Crawling Ladder:** These elements provide opportunities for children to develop motor skills and coordination.
- **Monkey Bars & Horizontal Bar:** Designed for upper body strength development.
- **Drawing Board:** A dedicated surface for creative expression. Use chalk only.
- **Abacus Game:** Features 3 colors of abacus beads for early learning and fine motor skill development.
- **Swing:** Provides a gentle swinging motion. Ensure the swing is properly installed and checked for stability before each use.



Image: A visual representation of the eight different play activities available on the Costzon indoor playground.



Image: Demonstrates the two-sided reversible ramp, functioning as both a slide and a climbing wall.

Maintenance

- **Cleaning:** Wipe down wooden surfaces with a damp cloth and mild soap as needed. Avoid harsh chemicals that could damage the finish or be harmful to children.
- **Hardware Check:** Regularly inspect all screws, bolts, and fasteners to ensure they remain tight. Re-tighten any loose hardware to maintain structural integrity.
- **Wood Condition:** Check for any signs of wear, cracks, or splinters on the wooden components. Sand smooth any rough areas if necessary.
- **Rope/Net Condition:** Inspect the polyester rope net for fraying or damage. Replace if significant wear is observed.
- **Storage:** If storing for an extended period, ensure the playground is clean and dry. Store in a climate-controlled environment to prevent wood warping or damage.



Image: Details of the materials and construction, emphasizing smooth edges, solid birch wood, durable polyester rope, and appropriate safety clearances.

Troubleshooting

- **Wobbling Structure:** If the playground feels unstable, re-check all assembly points. Ensure all screws are fully tightened. Verify the playground is on a level surface.
- **Missing Parts:** If any parts are missing upon delivery, contact Costzon customer support immediately.
- **Difficulty Assembling:** Refer to the installation video and the detailed assembly manual. If issues persist, contact customer support for assistance.
- **Damaged Components:** Do not use the playground if any part is damaged. Contact customer support for replacement parts.

Specifications

Feature	Detail
Model Number	CL-G08
Material	Birch Wood, Beech Wood, Polyester
Product Dimensions (L x W x H)	49" x 47" x 54.5"
Slide Dimensions (L x W x H)	47.5" x 16" x 3.5"
Item Weight	63.5 pounds
Overall Weight Capacity	110 pounds
Swing Weight Capacity	55 pounds
Suitable Age	3+ Years (36-120 months)
Certifications	ASTM/CPSIA Compliant, FSC-certified wood

Warranty and Support

For warranty information, returns, or customer support, please refer to the purchase documentation or contact Costzon directly. The product typically includes a 30-day easy return policy. For specific inquiries regarding your product, please provide your model number (CL-G08) and purchase date.

Manufacturer: Costzon

Contact: Refer to the contact information provided at the point of purchase or on the official Costzon website.

© 2026 Costzon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question