

## PHILIPS S4807

# Philips S4807 Wireless Bluetooth Speaker Instruction Manual

Model: S4807

## 1. INTRODUCTION

Thank you for choosing the Philips S4807 Wireless Bluetooth Speaker. This manual provides essential information for the safe and efficient use of your speaker. Please read it thoroughly before operating the device and retain it for future reference.

The Philips S4807 is designed for portability and durability, featuring an IP67 waterproof and dustproof rating, Bluetooth multipoint connection, and stereo pairing capabilities.



*Image 1.1: Philips S4807 Wireless Bluetooth Speaker, showcasing its compact, rugged design with a lanyard strap.*

## 2. PACKAGE CONTENTS

Ensure all items are present in the package:

- Philips S4807 Wireless Bluetooth Speaker
- USB charging cable
- Lanyard strap
- Quick Start Guide
- Warranty Card
- World Wide Warranty leaflet

### 3. SETUP

#### 3.1 Charging the Speaker

Before first use, fully charge the speaker.

1. Connect the supplied USB charging cable to the speaker's charging port.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator lights will show the charging status. A full charge provides approximately 12 hours of playtime.



12 hr



12 hours  
of playtime



Bold sound

*Image 3.1: The Philips S4807 speaker in an outdoor setting, highlighting its 12-hour battery life and bold sound output.*

### **3.2 Powering On/Off**

- To power on, press and hold the power button until the indicator lights illuminate.
- To power off, press and hold the power button again until the indicator lights turn off.

### **3.3 Initial Bluetooth Pairing**

1. Ensure the speaker is powered on and in pairing mode (indicator light will flash).
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "Philips S4807" from the list.
4. Once connected, the indicator light will become solid.

## **4. OPERATING INSTRUCTIONS**

---

### **4.1 Bluetooth Multipoint Connection**

The Philips S4807 supports connecting up to two smart devices simultaneously. This allows you to switch between audio sources without re-pairing.

1. Pair the first device as described in section 3.3.
2. Pair the second device. The speaker will remember both connections.
3. To switch audio, simply pause playback on the first device and start playback on the second.




Image 4.1: The Philips S4807 demonstrating Bluetooth multipoint connection, allowing multiple devices to connect simultaneously.

## 4.2 Stereo Pairing (Twin Speaker Mode)

For an enhanced audio experience, you can pair two Philips S4807 speakers together to create a stereo sound system.

1. Ensure both S4807 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the stereo pairing button (refer to Quick Start Guide for button location).
3. Repeat step 2 on the second speaker.
4. The speakers will connect to each other, indicated by a specific light pattern or audio cue.
5. Now, connect your mobile device to the primary speaker via Bluetooth. Audio will play in stereo through both speakers.



Image 4.2: Multiple Philips S4807 speakers arranged on a beach, demonstrating the stereo pairing feature for a wider soundstage.

### 4.3 Music Playback and Volume Control

- **Play/Pause:** Press the Play/Pause button.
- **Volume Up:** Press the Volume + button.
- **Volume Down:** Press the Volume - button.
- **Next Track:** Press and hold the Volume + button.
- **Previous Track:** Press and hold the Volume - button.

### 4.4 Voice Assistant

To activate your device's voice assistant (e.g., Siri, Google Assistant), press and hold the Play/Pause button.

### 4.5 Hands-Free Calling

The built-in microphone allows you to take calls directly through the speaker when connected to your smartphone.

- **Answer Call:** Press the Play/Pause button.
- **End Call:** Press the Play/Pause button again.
- **Reject Call:** Press and hold the Play/Pause button.

## 5. MAINTENANCE

### 5.1 Cleaning

Due to its IP67 rating, the speaker is resistant to dust and water.

- Wipe the speaker with a soft, damp cloth.
- Do not use abrasive cleaners, alcohol, or solvents.
- Ensure the charging port cover is securely closed before exposing the speaker to water or dust.

- After exposure to saltwater, rinse the speaker with fresh water and dry thoroughly.



Image 5.1: The Philips S4807 speaker positioned on a sandy beach, illustrating its IP67 dustproof and waterproof capabilities.

## 5.2 Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

## 5.3 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Charge the speaker regularly, even if not in use, to maintain battery health.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker using the USB cable.

Problem	Possible Cause	Solution
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; device's Bluetooth is off; speaker is already connected to another device.	Ensure speaker is in pairing mode. Turn Bluetooth on your device. Disconnect from other devices or use multipoint connection.
No sound or low volume.	Volume is too low on speaker or device; device is out of range.	Increase volume on both speaker and device. Ensure device is within Bluetooth range (up to 20 meters).
Stereo pairing fails.	Speakers are already connected to a device; incorrect pairing procedure.	Disconnect both speakers from any Bluetooth devices. Follow the stereo pairing instructions carefully.

## 7. SPECIFICATIONS

- **Model:** S4807
- **Connectivity:** Bluetooth Wireless Technology
- **Bluetooth Range:** Up to 20 meters (66 feet)
- **Water Resistance:** IP67 (Dustproof and Waterproof)
- **Battery Life:** Up to 12 hours playtime
- **Speaker Output Power:** 20 Watts
- **Speaker Type:** Satellite with Dual Passive Radiators
- **Control Method:** Voice, Button
- **Dimensions (L x W x H):** 6.7" x 2.8" x 2.76" (17 cm x 7.1 cm x 7 cm)
- **Weight:** 0.5 kg (1.1 lbs)
- **Power Source:** Battery Powered (1 Lithium Polymer battery included)
- **Included Components:** Lanyard strap, USB charging cable, Quick Start Guide, Warranty Card, World Wide Warranty leaflet



Image 7.1: Detailed view of the Philips S4807 speaker with its dimensions (length, width, height) clearly indicated.

## 8. WARRANTY AND SUPPORT

Your Philips S4807 speaker comes with a full warranty. Please refer to the included "World Wide Warranty leaflet" for detailed terms and conditions.

For technical support, product registration, or further assistance, please visit the official Philips support

website or contact your local Philips customer service.

[Visit Philips Support](#)