Schleich 42587

Schleich Horse Club Sofia's Beauties Pop-Up Boutique

Model: 42587

Introduction

This instruction manual provides essential information for the assembly, operation, and maintenance of your Schleich Horse Club Sofia's Beauties Pop-Up Boutique playset. Please read this manual thoroughly before use to ensure proper handling and to maximize your enjoyment of the product.

Safety Information

Warning! This product contains small parts which may pose a choking hazard. Not suitable for children under 3 years.
Always supervise young children during play. Ensure all components are securely assembled before play begins. Keep packaging materials away from children to prevent suffocation risks.

Package Contents

Your Schleich Horse Club Sofia's Beauties Pop-Up Boutique includes the following items:

- 1x Portable toy case (Pop-Up Boutique structure)
- 1x Quarter Horse figurine with brushable mane and tail
- 1x Fully flexible Mr. Mitchell figurine
- 1x Fully flexible Kim figurine
- 1x Mirror
- 1x Counter
- 2x Shelves
- 1x Display stand
- 1x Potted plant
- 1x Large sales box
- 1x Small sales box
- 2x Riding hats
- 1x Set of hair clips

- 1x Set of hair beads
- 1x Browband
- 2x Horse blankets
- 2x Quarter blankets
- 1x Set of gaiters
- 1x Cash register
- 1x Trophy



Image: The complete Schleich Horse Club Sofia's Beauties Pop-Up Boutique set, showing the packaging and all included accessories laid out.

Setup

1. **Unfolding the Boutique:** Carefully open the portable toy case. The sides of the boutique will fold out to create the play area. Ensure all panels are fully extended and locked into place for stability.



Image: The Pop-Up Boutique fully unfolded, revealing the interior play space with a horse and figures.

2. **Placing Accessories:** Arrange the mirror, counter, shelves, and display stand within the boutique as desired. The shelves can be attached to the designated slots on the walls.
3. **Decorating:** Use the potted plant and sales boxes to enhance the boutique's appearance. Place the various horse accessories (blankets, gaiters, hair items) on the display stand or shelves.



Image: A detailed view of the boutique's interior, showcasing shelves, a counter, and various accessories.

Operating Instructions

Playing with the Horse and Accessories

- **Brushable Mane and Tail:** The Quarter Horse figurine features a brushable mane and tail. Use the included hair accessories like clips and beads to style the horse's hair.



Image: The Quarter Horse figurine with its long, brushable mane and tail, adorned with various accessories.

- **Dressing the Horse:** Place the horse blankets, quarter blankets, and gaiters on the horse figurine to change its appearance.
- **Interacting with Figurines:** The Mr. Mitchell and Kim figurines are fully flexible, allowing for various poses and interactions within the boutique setting. They can hold accessories or ride the horse.



Image: Figurines Mr. Mitchell and Kim interacting with the horse inside the Pop-Up Boutique, showcasing various accessories.

Folding and Storage

To store or transport the boutique, carefully remove all small accessories and figurines. Fold the side panels inwards until the boutique forms a compact case. Ensure all parts are securely contained within the folded structure. The integrated handle allows for easy carrying.



Image: The Pop-Up Boutique in its folded, portable case form, ready for storage or transport.

Maintenance

To maintain the quality and longevity of your playset, follow these guidelines:

- **Cleaning:** Wipe all plastic components with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the paint or plastic.
- **Hair Care:** The horse's brushable mane and tail can be gently combed with a fine-toothed comb if needed. Avoid excessive pulling or harsh brushing to prevent damage.
- **Storage:** Store the playset in a cool, dry place away from direct sunlight to prevent material degradation and color fading.

Troubleshooting

Removable Hair Pieces

If the removable hair pieces on the horse figurine occasionally detach during play, gently reinsert them into their designated slots. Ensure they are firmly seated. This design allows for customization and interchangeability but may require occasional reattachment.

Specifications

Feature	Detail
Product Dimensions (unfolded)	7.3 x 4.6 x 11.1 inches (approximate)
Item Weight	2.91 pounds
Model Number	42587
Manufacturer Recommended Age	5 - 12 years
Material	High-quality, durable plastic

Warranty and Support

Schleich products are manufactured to high-quality standards. For any questions, concerns, or support regarding your product, please refer to the contact information provided on the product packaging or visit the official Schleich website for customer service details. Please retain your proof of purchase for warranty claims, if applicable.

© 2025 Schleich. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question