Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Schleich 42567

Schleich Horse Club Lakeside Riding Center Playset

Model: 42567 | Brand: Schleich

Introduction

Welcome to the world of Schleich Horse Club! This instruction manual provides essential information for the assembly, operation, and maintenance of your new 115-piece Lakeside Riding Center Playset. Designed for imaginative play, this set allows children aged 5-12 to create their own equestrian adventures with horses, riders, and a detailed stable environment.



Image: The complete Schleich Horse Club Lakeside Riding Center Playset, showcasing the stable, horses, and figures.

Important Safety Information

Please read all safety warnings before assembly and play. This product contains small parts which may pose a choking hazard. Not suitable for children under 3 years due to small parts.

- **Warning!** Swallowable small parts. Choking hazard.
- Recommended age: 5 - 12 years.
- Adult supervision is recommended during assembly and initial play.

What's in the Box

Your Schleich Horse Club Lakeside Riding Center Playset includes the following components:

- 1x House
- 3x Horse stall
- 1x Wash station
- 1x Wooden horse
- 2x Cup
- 2x Plate
- 1x Sack of oats
- 2x Riding hat
- 2x Straw bale
- 2x Hay bale
- 1x Silage
- 1x Bucket
- 2x Comb
- 2x Apple
- 2x Carrot
- 1x Cat figurine
- 1x Mouse figurine
- 3x Horse figurines
- 1x Pitchfork
- 1x Broom
- 2x Saddle blanket
- 2x Sleeping bag
- 2x Cushion
- 1x Cowboy hat
- 2x Fully flexible figure (Hannah and Lisa)



Image: The back of the product packaging, illustrating the various components included in the 115-piece set and providing visual cues for assembly.

Setup and Assembly

The Lakeside Riding Center Playset is designed for modular assembly, allowing for flexible arrangement. Follow these general steps to set up your playset:

1. **Unpack Components:** Carefully remove all pieces from the packaging. Refer to the 'What's in the Box' section and the diagrams on the back of the product box to ensure all 115 pieces are present.
2. **Assemble Main Structure:** Connect the main house sections and horse stalls. The pieces are designed to snap together securely. Apply gentle, firm pressure.
3. **Attach Roof and Upper Level:** Place the roof sections and the upper level platform onto the main structure. Ensure they are properly aligned and seated.
4. **Install Accessories:** Attach smaller elements such as fences, windows, doors, and the wash station. These typically click into designated slots.
5. **Arrange Interior Elements:** Place the wooden horse, feed buckets, and other stable accessories within the stalls and main areas.
6. **Position Figurines and Animals:** Place the horse figurines, riders (Hannah and Lisa), and other animal figures (cat, mouse) as desired to begin your play scenario.



Image: A visual representation of the playset's modular design, highlighting how different sections and accessories fit together.

For detailed visual instructions, please refer to the assembly diagrams provided on the product packaging.

Operating and Play Instructions

The Schleich Horse Club Lakeside Riding Center is designed to inspire imaginative play. Here are some ways to interact with your playset:

- **Horse Care:** Use the combs, apples, and carrots to simulate grooming and feeding your horse figurines. The wash station allows for realistic horse bathing scenarios.
- **Riding Adventures:** Place the flexible rider figures onto the horses using the saddle blankets. Create riding lessons, trail rides, or prepare for a horse show.
- **Stable Life:** Arrange the hay bales, straw bales, and oats in the horse stalls. The house section provides a living area for the riders, complete with sleeping bags and cushions for rest.
- **Storytelling:** Utilize all the accessories and figures to develop unique stories and scenarios within the Horse Club world. The modular design allows you to reconfigure the stable layout to suit different play ideas.



Image: A child engaging in imaginative play with the Lakeside Riding Center, demonstrating interaction with the figures and stable elements.

Maintenance

To ensure the longevity of your Schleich Horse Club playset, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down all plastic components with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners, as these can damage the paint and plastic.
- **Drying:** Ensure all parts are thoroughly dry before storing to prevent mold or mildew.
- **Storage:** Store the playset in a clean, dry environment away from direct sunlight and extreme temperatures to prevent material degradation and color fading.
- **Handling:** While durable, avoid excessive force when assembling or disassembling parts to prevent breakage.

Troubleshooting

If you encounter any issues with your playset, consider the following:

- **Missing Pieces:** Double-check the packaging and all corners of the box. Sometimes small accessories can be overlooked. Refer to the 'What's in the Box' list.
- **Parts Not Fitting:** Ensure you are attempting to connect the correct pieces as per the assembly diagrams. Apply gentle, even pressure. Do not force parts together, as this may cause damage.
- **Damaged Parts:** In the event of a damaged component upon unboxing, please contact Schleich customer support for assistance.

Specifications

Product Dimensions	22.09 x 4.09 x 14.69 inches
Item Weight	6.23 pounds
Model Number	42567
Manufacturer Recommended Age	5 - 12 years
Release Date	July 1, 2022
Manufacturer	Schleich

Support

For further assistance, product inquiries, or to explore more Schleich products, please visit the official Schleich store:

Visit the Schleich Store

You can also find more information and contact details on the official Schleich website.

© 2025 Schleich. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09QH9DTFL

More documents and user manuals: **https://manuals.plus/**