

[Manuals.plus](#) /

› [Besia](#) /

› Besia Universal Remote Control for LG Smart TVs (Model AKB76037601) - User Manual

Besia AKB76037601

Besia Universal Remote Control for LG Smart TVs

USER MANUAL - MODEL AKB76037601

Introduction

This manual provides instructions for the Besia Universal Remote Control, designed as a direct replacement for various LG Smart TV remotes, including the AKB76037601 model. This remote offers immediate functionality without the need for complex programming, allowing you to control your LG Smart TV with ease.



Image: Front view of the Besia Universal Remote Control, showcasing its full button layout.

Setup

1. Battery Installation

The Besia Universal Remote Control requires two (2) AAA batteries for operation. To install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) and lift to open the compartment.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back view of the remote control, showing the battery compartment.

2. Initial Use

No programming or setup is required for this remote control. Once fresh batteries are installed, the remote is ready for immediate use with compatible LG Smart TVs.

Use Directly

No programming or setting up is required!



Image: A hand holding the remote control, demonstrating its direct usability with an LG TV.

Operating Instructions

Point the remote control directly at your LG Smart TV. The operational distance is approximately 8 meters (26 feet).



Image: The remote control in use, illustrating its effective operational range of 8 meters.

Button Functions

- **Power Button** (): Turns the TV on or off.
- **Number Pad (0-9)**: For direct channel input.
- **Volume Up/Down** (): Adjusts the TV volume.
- **Channel Up/Down** (↑ ↓): Changes TV channels.
- **Quick Access Buttons**: Dedicated buttons for popular streaming services and LG features:
 - Netflix
 - Prime Video
 - Disney+
 - LG Channels
- **Navigation Pad**: Up, Down, Left, Right arrows and OK button for menu navigation.
- **Back/Return** (↶): Returns to the previous screen or menu.
- **Home** (): Accesses the TV's home screen or smart menu.
- **Guide**: Displays the program guide.

- **Playback Controls:** Play, Pause, Fast Forward, Rewind buttons for media playback.
- **Info ():** Displays information about the current program or input.
- **Settings (⚙️):** Accesses TV settings.



Image: Detailed view of the quick access buttons for streaming services and navigation controls.

Compatibility

This Besia Universal Remote Control is compatible with a wide range of LG Smart TVs. It is designed to replace original LG remote models such as AKB76037601.

Compatible LG TV Models include:

- 32LM577BPUA, 32LM577BZUA, 32LM627BPUA, 32LM637BPUB
- 43LM5770PUA, 43LM6370PUB, 43UP7000PUA, 43UP7670PUC, 43UP8000PUR
- 50UP7670PUC, 50UP8000PUR
- 55UP7670PUC, 55UP8000PUR
- 60UP7670PUB, 60UP8000PUR
- 65UP7670PUC, 65UP8000PUR
- 70UP7670PUB, 70UP8070PUR
- 75UP7670PUB, 75UP8070PUR

- 43UM6950DUB, 49UM7300PUA, 50UN7000PUC, 55UP7000PUA
- 60UM6900PUA, 65UN7000PUD, 65UP7000PUA
- 70UM6970PUA, 75UM6970PUB



Image: Visual representation of the remote's broad compatibility with different LG Smart TV technologies.

Compatible LG Remote Models:

- AKB73715601, AKB75095308, AKB75055702
- AKB74915324, AKB73715603, AKB75675301
- AKB76037605, AKB76037601, AKB75095312
- AKB75675311, AKB76037608, AKB76037603
- AKB76040301, AKB76040302, AKB76040309



One for More

For LG Remote Models

AKB73715601 AKB75095308 AKB75055702
 AKB74915324 AKB73715603 AKB75675301
 AKB76037605 AKB76037601 AKB75095312
 AKB75675311 AKB76037608 AKB76037603
 AKB76040301 AKB76040302 AKB76040309

Image: The Besia remote shown with examples of original LG remote models it is designed to replace.

Specifications

- **Model Number:** AKB76037601 (Replacement Remote)
- **Product Dimensions:** 6 x 2 x 0.5 inches (approximately 15.24 x 5.08 x 1.27 cm)
- **Item Weight:** 2.25 ounces (approximately 63.79 grams)
- **Power Source:** 2 x AAA batteries (not included)
- **Material:** ABS (Acrylonitrile Butadiene Styrene) for durability
- **Special Features:** Ergonomic design, soft buttons, strong signal transmission
- **Max Number of Supported Devices:** 1 (LG Smart TV)



6.69 inch



Image: Front view of the remote control with its length (6.59 inches) and width (1.97 inches) clearly indicated.



Image: An infographic illustrating the remote's key attributes, including durability, soft buttons, strong signal, and ABS material construction.

Troubleshooting

- **Remote Not Responding:**

- Ensure batteries are inserted correctly with the proper polarity (+/-).
- Replace old batteries with new AAA batteries.
- Ensure there is a clear line of sight between the remote control and the TV's infrared (IR) receiver. Obstructions can block the signal.
- Confirm the remote is compatible with your specific LG TV model. Refer to the compatibility list in this manual.

- **Buttons Not Working:**

- Check for any physical damage or debris under the buttons.
- If only specific buttons are not working, it might indicate a fault with the remote.

Support

If you encounter any issues or have questions regarding your Besia Universal Remote Control that are not addressed in this manual, please feel free to contact us for assistance. We are committed to providing support for our products.